


## SCMbus communication protocol



Document revisions		
version	date	description
A	12/11	- Document creation
B	04/17	- Add DVX-C and DVS-C

<b>1</b>	<b>INSTALLATION .....</b>	<b>5</b>
1.1	Connection to RS485 bus .....	5
1.2	Topology, bus length and communication baud rate .....	6
<b>2</b>	<b>USING SCMBUS COMMUNICATION PROTOCOL : .....</b>	<b>7</b>
2.1	Byte format:.....	7
2.2	Frame format :.....	7
2.2.1	Functioning commands, writing commands : .....	7
2.2.2	Reading commands : .....	8
2.2.3	Transmit measurement command : .....	8
2.2.4	Exception frame : .....	10
<b>3</b>	<b>FUNCTIONAL COMMANDS : .....</b>	<b>11</b>
3.1	Functional commands with N = 0 .....	11
3.2	Functional commands with N = 5 : .....	12
<b>4</b>	<b>READING/WRITING COMMANDS LIST : .....</b>	<b>13</b>
<b>5</b>	<b>COMMANDS DESCRIPTION.....</b>	<b>16</b>
5.1	Communication settings : .....	16
5.1.1	Communication protocol and functioning mode: .....	16
5.1.2	Sensor's address : .....	16
5.1.3	Serial & CANbus baud rate selection : .....	17
5.2	Calibration settings .....	17
5.2.1	Calibration load : .....	17
5.2.2	Span adjusting coefficient : .....	17
5.2.3	Maximum capacity : .....	18
5.2.4	Scale interval : .....	18
5.2.5	User zero calibration : .....	18
5.2.6	User zero calibration : .....	18
5.2.7	User scale coefficient : .....	18
5.2.8	Gravity coefficient (g) : .....	19
5.3	Filtering settings.....	19
5.3.1	A/D converter configuration : .....	19
5.3.2	Digital filter order and band-stop filter activation : .....	19
5.3.3	Low-pass filter coefficients : .....	20
5.3.4	Stop-band filter coefficients : .....	20
5.3.5	Self-adaptive filter : .....	21
5.3.6	Stability criterion : .....	21
5.4	Logical inputs/outputs configuration .....	23
5.4.1	Logical inputs assignment : .....	23
5.4.2	Debounce time : .....	23
5.4.3	Logical outputs 1&2 and 3&4 assignment : .....	24
5.4.4	Set points high & low values : .....	25
5.4.5	Set points functioning .....	25
5.5	Legal for trade.....	25
5.5.1	Metrological version number : .....	25
5.5.2	Legal for trade switch : .....	26
5.5.3	Legal for trade counter : .....	26
5.5.4	Legal for trade CRC-16 : .....	26
5.5.5	Zero modes : .....	26
5.6	Checkweigher settings .....	27
5.6.1	Stabilization Time (Ts) in checkweigher mode : .....	27
5.6.2	Measuring Time (Tm) in checkweigher mode: .....	27
5.6.3	Acquisition Time and/or Dynamic zero correction : .....	28
5.6.4	Checkweigher correction coefficient: .....	28
5.6.5	Set point for checkweigher start cycle : .....	28
5.7	Measurements.....	29
5.7.1	Sampling period (transmitter mode) : .....	29


5.7.2	Gross : .....	29
5.7.3	Tare : .....	29
5.7.4	Net : .....	29
5.7.5	A/D converter points : .....	29
5.7.6	Checkweigher result: .....	30
5.7.7	Number of processed cycles : .....	30
5.7.8	Average value : .....	30
5.7.9	Checkweigher running total : .....	30
5.7.10	Standard deviation : .....	30
5.7.11	Checkweigher result quality : .....	30
<b>5.8</b>	<b>Other settings .....</b>	<b>31</b>
5.8.1	Product version : .....	31
5.8.2	Text box : .....	31
<b>6</b>	<b>APPENDIX A : EXAMPLE FOR CODING A SINGLE PRECISION FLOAT PARAMETER.....</b>	<b>32</b>

## 1 INSTALLATION


### 1.1 Connection to RS485 bus

Digital load-cell is equipped with a **RS485** (half-duplex) interface using **Modbus-RTU** and **SCMbus** communication protocols.

Digital load-cell can be connected to a RS485 bus using **TA/RA** and **TB/RB** connections which are differently located depending on the load-cell version :




#### ➤ 2 x 5-pins connectors version :



- **TA/RA** : pin 4 of C2 connector
- **TB/RB** : pin 5 of C2 connector

#### ➤ 2 x 8-pins connectors version :



- **TA/RA** : pin 7 of C1 connector
- **TB/RB** : pin 8 of C1 connector

**Note** : Digital load-cell is also equipped with a CAN2.0A interface. After a reset (hardware or software), digital load-cell automatically communicates through the CAN interface. As soon as a Modbus-RTU or SCMbus valid frame is received on RS485 interface, digital load-cell automatically switches into RS485 communication mode.

By default, the baud rate for RS485 communication is **9600 bauds** and address is **01<sub>H</sub>** . It can be modified during sensor setting up phase with **eNodView** software.


## 1.2 Topology, bus length and communication baud rate

Network topology is a bus topology with resistors at each end (150 Ohms recommended).  
Maximal length of the bus depends on cable quality and baud rate, see following table :

Bit rate	Max bus length
115.2 kbit/s	600 m
57.6 kbit/s	1200 m
38.4 kbit/s	1200 m
19.2 kbit/s	1200 m
9.6 kbit/s	1200 m

**Note :**

- Table corresponds to a bus made with a shielded cable and twisted pair conductors section  $\geq 0.22\text{mm}^2$  (24AWG).
- For bus whose length is greater than 200m, using optocoupler is recommended.
- Line termination :
- 



## 2 USING SCMBUS COMMUNICATION PROTOCOL :

### 2.1 Byte format:

- Format :

- 1 start bit
- 8 data bits without parity
- 2 stop bits

- ASCII bytes:


ASCII numeral characters (30<sub>H</sub>,...39<sub>H</sub>) and ASCII hexadecimal characters (3A<sub>H</sub>,...3F<sub>H</sub>).

- CRC byte :

Generated by the following polynomial :

$$G(x) = x^8 + x^7 + x^4 + x^3 + 1$$

The CRC-8 polynomial result can be determined by programming the algorithm corresponding to the following diagram :



- ❑ **Note :** The frame error detection can be ignored. Value **0xFF** of the CRC-8 always is admitted by digital load-cell and a received frame which is ended by such CRC-8 is considered as a frame without any error.

### 2.2 Frame format :

- Transmission organisation :

- \* Frame : Address first.
- \* Bytes : lsb first.
- \* Multi-bytes data type : MSB first.

#### 2.2.1 Functioning commands, writing commands :

**Request :**

Address	Command	Value	CR	CRC
1 Hex byte	1 Hex byte (command)	N ASCII hex bytes	1 ASCII byte (0D <sub>H</sub> )	1 Hex byte

**Response :**

Each functioning command or writing command is acknowledged by the send back of the same frame as received or an error message.

Address	Command	Value	CR	CRC
1 Hex byte	1 Hex byte (command)	N ASCII Hex bytes	1 ASCII byte (0D <sub>H</sub> )	1 Hex byte

## 2.2.2 Reading commands :

Request :

Address	Command	CR	CRC
1 Hex byte	1 Hex byte (command)	1 ASCII byte (0D <sub>H</sub> )	1 Hex byte

Response :

Address	Command	Value	CR	CRC
1 Hex byte	1 Hex byte (command)	N ASCII Hex bytes	1 ASCII byte (0D <sub>H</sub> )	1 Hex byte

## 2.2.3 Transmit measurement command :

Request :

Address	Command	CR	CRC
1 Hex byte	1 Hex byte (command)	1 ASCII byte (0D <sub>H</sub> )	1 Hex byte

Response :

- *standard format* :

Address	Status	Value	CR	CRC
1 Hex byte	2 Hex bytes	N ASCII Hex bytes	1 ASCII byte (0D <sub>H</sub> )	1 Hex byte

- *fast format* :

This specific format is especially dedicated to very fast measurement transmission. We recommend using the **eNodView** software with this format to save acquisition files. These files can be used for dynamic analysis. It allows the user to define the best settings in relation with his application. This frame is specific, and it can only be applied to gross measurement, net measurement or A/D converter points in transmitter mode :

STX	Status word	Value	Cks	ETX
02 <sub>H</sub>	2 Hex bytes	3 signed Hex bytes (2's complement)	Σ of previous bytes and b7 set to 1	03 <sub>H</sub>

Measurements encoding : Because values are encoded in signed hexadecimal bytes format (2's complement) some bytes can be equal to **STX (02<sub>H</sub>)** or **ETX (03<sub>H</sub>)** or **DLE (10<sub>H</sub>)** so before those specific bytes values a **DLE (10<sub>H</sub>)** byte is inserted. Sensor address is not transmitted in the frame.

- ⇒ The frame starts with **STX (02<sub>H</sub>)** byte and ends with **ETX (03<sub>H</sub>)** byte
- ⇒ Values are encoded in **signed hexadecimal**
- ⇒ Checksum is obtained by summing every previous bytes and setting bit 7 to 1.



**Status bytes :**

bits b15,...b0	Function	Notes
<b>b1, b0</b>		
00	gross measurement	
01	net measurement	
10	A/D converter points	
11	tare value	
<b>b3,b2</b>		
00	measurement within the admissible range	causes an output assigned to ' <i>defective measurement</i> ' function to be set active
01	negative overloading	
10	positive overloading	
11	analog signal out of range	
<b>bit b4</b>		
0	motion	causes an output assigned to ' <i>motion</i> ' function to be set active
1	no motion	
<b>bit b5</b>		
0	measurement out of the zero ¼ of division	
1	zero in the ¼ of division	
<b>bit b6</b>		
0	EEPROM OK	
1	EEPROM failure	
<b>bit b7</b>		
1	reserved	
<b>bit b8</b>		
0	input 1 low level	input 1 logical state
1	input 1 high level	
<b>bit b9</b>		
0	input 2 low level	input 2 logical state
1	input 2 high level	
<b>bit b10</b>		
0	output 1 low level	output 1 logical state
1	output 1 high level	
<b>bit b11</b>		
0	output 2 low level	output 2 logical state
1	output 2 high level	
<b>bit b12</b>		
0	output 3 low level	output 3 logical state
1	output 3 high level	
<b>bit b13</b>		
0	output 4 low level	output 4 logical state
1	output 4 high level	
<b>bit b14</b>		
0	no tare	
1	At least a tare has been processed	
<b>bit b15</b>		
1	reserved	

**2.2.4 Exception frame :**

Address	Error code	CR	CRC
1 Hex byte	1 Hex byte (command)	1 ASCII byte (0D <sub>H</sub> )	1 Hex byte

**Error codes :**

Error code	Name	Description
FE <sub>H</sub>	unknown command	Requested command is not supported by sensor
FF <sub>H</sub>	error during command execution	ex. : write 0x00 forbidden address

### 3 **FUNCTIONAL COMMANDS :**

#### 3.1 **Functional commands with N = 0**

Command	hexa. Code	Description
reset	<b>D0<sub>H</sub></b>	⇒ similar to power-up reset
EEPROM storage	<b>D1<sub>H</sub></b>	⇒ save the whole settings table into the sensor's EEPROM
restores sensor default configuration	<b>D2<sub>H</sub></b>	⇒ <b>WARNING</b> : all default settings are recovered including the calibration
set to zero gross measurement	<b>D3<sub>H</sub></b>	⇒ needs measurement stability, if not reached after 5 second, command is cancelled ⇒ this new zero value is the new current value, but it is not stored into EEPROM ; limited to $\pm 10\%$ range of the maximum capacity or $\pm 2\%$ in legal for trade functioning
tare request	<b>D4<sub>H</sub></b>	⇒ needs measurement stability, if not reached after 5 seconds, command is cancelled
abort calibration	<b>D6<sub>H</sub></b>	⇒ allows to leave the calibration procedure before it ends
User's span adjustment	<b>D7<sub>H</sub></b>	⇒ must be followed by the 'save calibration' command
zero adjustment	<b>D8<sub>H</sub></b>	⇒ must be followed by the 'save calibration' command ⇒ OR by the 'physical calibration' command
save calibration	<b>DE<sub>H</sub></b>	⇒ stores the calibration parameters into EEPROM
clear	<b>DF<sub>H</sub></b>	⇒ stops current dosing cycle and resets all the calculated variables linked to dosing cycles
stop continuous transmission	<b>E3<sub>H</sub></b>	⇒ stop transmitter (see note §3.2)
start CW cycle	<b>E4<sub>H</sub></b>	⇒ starts a CW cycle by unloading cycle (depending on the functioning mode) if start conditions are respected
stop cycle	<b>E5<sub>H</sub></b>	⇒ stops the running CW cycle
cancel tare	<b>E6<sub>H</sub></b>	⇒ erases the current tare value
force output 1 level	<b>E7<sub>H</sub></b>	⇒ transmitter functioning mode only if logical output is set to 'programmed mode'. ⇒ send this command a first time to set the corresponding logical output (according to chosen logic), re-send this command to unset it and so on
force output 2 level	<b>E8<sub>H</sub></b>	
force output 3 level	<b>E9<sub>H</sub></b>	
force output 4 level	<b>EA<sub>H</sub></b>	
erase max peak value	<b>EB<sub>H</sub></b>	⇒ max peak value is set to actual gross value
physical calibration	<b>EC<sub>H</sub></b>	⇒ must be preceded by 'zero adjustment' command ⇒ the calibration load corresponds to the number assigned to 'calibration load'
Dynamic zero	<b>ED<sub>H</sub></b>	⇒ Force to zero without stability criteria after calculating time "dynamic zero time"

### 3.2 Functional commands with N = 5 :

Command	Hex. Code	Description
start gross measurement continuous transmission	<b>E0<sub>H</sub></b>	⇒ gross measurements are transmitted for a duration equal to the transmitted ASCII value coded on N = 5 ⇒ measurement transmission rate is defined by the ' <i>sampling period</i> ' setting
start net measurement continuous transmission	<b>E1<sub>H</sub></b>	⇒ net measurements are transmitted for a duration equal to the transmitted ASCII value coded on N = 5 ⇒ measurement transmission rate is defined by the ' <i>sampling period</i> ' setting
start A/D converter points continuous transmission	<b>E2<sub>H</sub></b>	⇒ A/D converter points measurements are transmitted for a duration equal to the transmitted ASCII value coded on N = 5 ⇒ measurement transmission rate is defined by the ' <i>sampling period</i> ' setting

**Note :** Each of the 3 commands theoretically can be stopped by the command '*stop continuous measurement transmission*' (E3<sub>H</sub>) before the end time has elapsed. Because of half-duplex communication limitations, a collision is possible and the '*stop continuous measurement transmission*' command might be ignored.

#### 4 **READING/WRITING COMMANDS LIST :**

Writing commands are usually followed by a reading command. Both are completed by a coded value up to N bytes. See the commands description the corresponding §.

Command	Writing hex codes	Note	Reading hex codes
<b>Communication settings</b>			
communication protocol, functioning mode and signal processing	21 <sub>H</sub>	N = 2	20 <sub>H</sub>
Sensor address	23 <sub>H</sub>	N = 1 (write) N = 3 (read)	22 <sub>H</sub>
serial & CAN bus baud rate selection	25 <sub>H</sub>	N = 2	24 <sub>H</sub>
<b>Calibration settings</b>			
calibration load	49 <sub>H</sub>	N = 7	48 <sub>H</sub>
span adjusting coefficient	39 <sub>H</sub>	N = 7	38 <sub>H</sub>
maximum capacity	41 <sub>H</sub>	N = 7	40 <sub>H</sub>
scale interval	43 <sub>H</sub>	predefined values	42 <sub>H</sub>
gravity coefficient (g)	45 <sub>H</sub>	N = 8	44 <sub>H</sub>
User scale coefficient	0C <sub>H</sub>	N = 8	0B <sub>H</sub>
User zero calibration	0F <sub>H</sub>	in A/D converter points	0E <sub>H</sub>
<b>Filtering settings</b>			
A/D converter configuration	51 <sub>H</sub>	N = 2	50 <sub>H</sub>
Low-pass filter order & band-stop filter activation	53 <sub>H</sub>	N = 2	52 <sub>H</sub>
low-pass filter 1/A coefficient	55 <sub>H</sub>	N = 8	54 <sub>H</sub>
low-pass filter B coefficient	57 <sub>H</sub>	N = 8	56 <sub>H</sub>
low-pass filter C coefficient	59 <sub>H</sub>	N = 8	58 <sub>H</sub>
low-pass filter D coefficient	5B <sub>H</sub>	N = 8	5A <sub>H</sub>
low-pass filter E coefficient	5D <sub>H</sub>	N = 8	5C <sub>H</sub>
band-stop filter X coefficient	89 <sub>H</sub>	N = 8	88 <sub>H</sub>
band-stop filter Y coefficient	8B <sub>H</sub>	N = 8	8A <sub>H</sub>
band-stop filter Z coefficient	8D <sub>H</sub>	N = 8	8C <sub>H</sub>
Self-adaptive filter	5F <sub>H</sub>	N = 1 (write) N = 2 (read)	5E <sub>H</sub>
<b>Logical inputs/outputs configuration</b>			
logical inputs assignment	61 <sub>H</sub>	N = 4	60 <sub>H</sub>
debounce time	63 <sub>H</sub>	N = 5	62 <sub>H</sub>
logical outputs 1 & 2 assignment	65 <sub>H</sub>	N = 4	64 <sub>H</sub>
logical outputs 3 & 4 assignment	67 <sub>H</sub>	N = 4	66 <sub>H</sub>

set point 4 high value	69 <sub>H</sub>	N = 7	68 <sub>H</sub>
set point 4 low value	6B <sub>H</sub>	N = 7	6A <sub>H</sub>
set point 3 high value	6D <sub>H</sub>	N = 7	6C <sub>H</sub>
set point 3 low value	6F <sub>H</sub>	N = 7	6E <sub>H</sub>
set point 2 high value	71 <sub>H</sub>	N = 7	70 <sub>H</sub>
set point 2 low value	73 <sub>H</sub>	N = 7	72 <sub>H</sub>
set point 1 high value	75 <sub>H</sub>	N = 7	74 <sub>H</sub>
set point 1 low value	77 <sub>H</sub>	N = 7	76 <sub>H</sub>
set points functioning	79 <sub>H</sub>	N = 4	78 <sub>H</sub>
<b>Legal for trade</b>			
metrological version number	-	read only ; N = 5	27 <sub>H</sub>
legal for trade switch	81 <sub>H</sub>	N = 1	80 <sub>H</sub>
legal for trade counter	-	read only ; N = 5	82 <sub>H</sub>
legal for trade checksum	-	read only ; N = 5	84 <sub>H</sub>
Zero modes	87 <sub>H</sub>	N = 1	86 <sub>H</sub>
stability criterion	85 <sub>H</sub>	N = 1 (write) N = 2 (read)	5E <sub>H</sub>
<b>Checkweigher settings</b>			
Stabilization time (Ts)	95 <sub>H</sub>	N = 5	94 <sub>H</sub>
Measuring Time (Tm)	97 <sub>H</sub>	N = 5	96 <sub>H</sub>
Dynamic zero acquisition time	F4 <sub>H</sub>	N = 5	F5 <sub>H</sub>
Checkweigher correction coefficient	F2 <sub>H</sub>	N = 8	F3 <sub>H</sub>
Trigger level	99 <sub>H</sub>	N = 8	98 <sub>H</sub>
Dynamic zero correction range	8F <sub>H</sub>	N = 3	8E <sub>H</sub>
<b>Measures</b>			
Sampling period	CB <sub>H</sub>	N = 5	CA <sub>H</sub>
Gross	-	SCMbus standard & rapide	10 <sub>H</sub>
Tare	-	SCMbus standard & rapide	11 <sub>H</sub>
Net	-	SCMbus standard & rapide	12 <sub>H</sub>
AD converter points	-	SCMbus standard & rapide	13 <sub>H</sub>
Checkweigher results	-	N = 8	14 <sub>H</sub>
Checkweigher numbr of cycles	-	N = 8	15 <sub>H</sub>
Mean	-	N = 8	16 <sub>H</sub>
Checkweigher running	-	N = 8	17 <sub>H</sub>
Checkweigher standard deviation	-	N = 8	18 <sub>H</sub>

Checkweigher quality results	-	N = 8	EF <sub>H</sub>
<b>Other settings</b>			
text box	93 <sub>H</sub>	N = 2	92 <sub>H</sub>
Product version	-	read only ; N = 5	26 <sub>H</sub>

## 5 COMMANDS DESCRIPTION

The data accessible through SCMBus communication protocol are described below. For each one, this document specifies its reading or writing command, its particular format and if the data needs a storage\*.

### Data storage\* :



- Y : The parameter **must** be saved in EEPROM. Its new value **will be taken into account at the next reset**.
- N : The new value of the parameter is **immediately taken into account** and does not need a storage before.
- **NOTE** : The whole parameters except 'read only' data can be stored into EEPROM in all cases. Then, their values are kept if the power supply is disconnected or if a reset is requested.

### 5.1 Communication settings :

#### 5.1.1 Communication protocol and functioning mode:

Reading code	Writing code	N	Data storage *
20 <sub>H</sub>	21 <sub>H</sub>	4	N

N1, N2		Function	
N1 (W)	N1 (R)	Protocol	
30	00	<b>SCMBus</b>	communication protocol
31	01	<b>Modbus RTU</b>	
33	03	<b>SCMBus fast format</b>	
N2 (W)	N2 (R)	functioning mode	
30	00	transmitter	application
31	01	Checkweigher on request	
32	02	Checkweigher auto	
38	08	fast transmitter	

**Note:** in "fast transmitter" functioning mode, the digital low-pass, band-stop and self-adaptive filters as well as the set points management are not taken into account.

To act the protocol change, it is mandatory to:

Store in EEPROM with D1<sub>H</sub> code **AND** Reset probe (power off or D0<sub>H</sub>.code).

#### 5.1.2 Sensor's address :

Reading code	Writing code	N	Data storage *
22 <sub>H</sub>	23 <sub>H</sub>	3	N

*Format* : Writing : All values between 01<sub>H</sub> and FF<sub>H</sub>.

Reading : ASCII format on 3 bytes

*Default value* : 01<sub>H</sub>

*Description* : Sensor address on the network.

00<sub>H</sub> is a broad cast address. Do not use this address when several devices are connected to the same network.



To act the protocol change, it is mandatory to:

Store in EEPROM with D1<sub>H</sub> code **AND** Reset probe (power off or D0<sub>H</sub>.code).

### 5.1.3 Serial & CANbus baud rate selection :

Reading code	Writing code	N	Data storage *
24 <sub>H</sub>	25 <sub>H</sub>	2	Y

Format/description : Coded according to the following table :

N1	RS485 baud rate	
31	9600	by default
32	19200	
33	38400	
34	57600	
35	115200	
N2	CAN bus baud rate	
32	50000	
33	1250000	by default
34	250000	
35	500000	
36	800000	
37	1000000	

To act the protocol change, it is mandatory to:

Store in EEPROM with D1<sub>H</sub> code **AND** Reset probe (power off or D0<sub>H</sub>.code).

## 5.2 Calibration settings

### 5.2.1 Calibration load :

Reading code	Writing code	N	Data storage *
48 <sub>H</sub>	49 <sub>H</sub>	1 to 7	N

Format : Coded in ASCII (non-significant zero are not mandatory), admissible values comprised between 0 and 1000000<sub>d</sub>.

Default value : 10000<sub>d</sub>

Description : Digital load-cell span can be adjusted by learning using a known standard load. The equivalence between the standard load and the corresponding number of points is set by the 'calibration load' value used during the 'physical calibration' procedure execution.

Stored in EEPROM using D1<sub>H</sub> command.

### 5.2.2 Span adjusting coefficient :

Reading code	Writing code	N	Data storage *
38 <sub>H</sub>	39 <sub>H</sub>	1 to 7	N

Format : Coded in ASCII (non-significant zero are not mandatory). The unit is 1/1000000 (1E-6). It means that 1000000<sub>d</sub> = 1. Maximum and minimum values are respectively 1100000<sub>d</sub> and 900000<sub>d</sub> which is corresponding to 1.10 and 0.90.

Default value : 1000000<sub>d</sub>

Description : The original calibration value could be adjusted by the 'span adjusting coefficient'. This correction applies on the whole curve.

Stored in EEPROM using D1<sub>H</sub> command.

### 5.2.3 Maximum capacity :

Reading code	Writing code	N	Data storage *
40 <sub>H</sub>	41 <sub>H</sub>	from 1 to 7	N

*Format* : Coded in ASCII (non-significant zero are not mandatory), admissible values comprised between 0 et 1000000<sub>d</sub>.

*Default value* : 500000<sub>d</sub>

*Description* : The 'maximum capacity' allows to define the gross value delivered by the load-cell at its maximum capacity (ex : 30000 pts for 30 kg). The value of this setting is used as part of the 'user's span adjustment' command.

When the absolute value of the gross measurement plus 9 divisions exceeds the specified capacity, the bit b3 of the status word associated is set to 1.

Stored in EEPROM using D1<sub>H</sub> command.

### 5.2.4 Scale interval :

Reading code	Writing code	N	Data storage *
42 <sub>H</sub>	43 <sub>H</sub>	1 to 3	N

*Format* : Coded in ASCII (non-significant zero are not mandatory). Admissible values : 1, 2, 5, 10, 20, 50, 100.

*Default value* : 1<sub>d</sub>

*Description* : minimal difference between 2 consecutive calibrated measurements.

Stored in EEPROM using D1<sub>H</sub> command.

### 5.2.5 User zero calibration :

Reading code	Writing code	N	Data storage *
0E <sub>H</sub>	0F <sub>H</sub>	1 to 8	N

*Default value* : 0<sub>d</sub>

*Description* : Value in A/D converter points of the zero reference.

This zero value is acquired during a functional command 'zero adjustment'.

Stored in EEPROM using D1<sub>H</sub> command.

### 5.2.6 User zero calibration :

Reading code	Writing code	N	Data storage *
0E <sub>H</sub>	0F <sub>H</sub>	1 to 8	N

*Default value* : 0<sub>d</sub>

*Description* : Value in A/D converter points of the zero reference.

This zero value is acquired during a functional command 'zero adjustment'.

Stored in EEPROM using D1<sub>H</sub> command.

### 5.2.7 User scale coefficient :

Reading code	Writing code	N	Data storage *
0B <sub>H</sub>	0C <sub>H</sub>	8	N

*Default value* : 1.0

*Format* : simple precision float value (32bits).

*Description* : this coefficient is automatically calculated by sensor during one of the calibration procedures : 'Theoretical scale adjustment' or 'physical scale adjustment'.

Stored in EEPROM using D1<sub>H</sub> command.

### 5.2.8 Gravity coefficient (g) :

Reading code	Writing code	N	Data storage *
44 <sub>H</sub>	45 <sub>H</sub>	8	N

*Format* : Coded in ASCII decimal. Actual value multiplied by one million (1000000), for example 9,805 is written 9805000<sub>d</sub>

*Default value* : 9805470<sub>d</sub>

*Description* : As digital load cell is calibrated in Annemasse (France), depending on the terrestrial geographical coordinates where the load cell is used, the gravity difference can affect the measure aptness. In order to compensate this error, it is possible to modify this gravity coefficient to adjust it to the using place. It is expressed without point, and multiplied by one million (for example, 9.805 is traduced by 9805000 in the load cell). This correction is taken into account after a saving in EEPROM followed by a reset, then the span adjustment is automatic.

## 5.3 Filtering settings

### 5.3.1 A/D converter configuration :

Reading code	Writing code	N	Data storage *
50 <sub>H</sub>	51 <sub>H</sub>	2	N

*Format/description* : Coded according to the following table :

N1, N2	Function		
N1	Signal type and rejection		
31	Bipolar signal, 60Hz rejection		
32	<b>Bipolar signal, 50Hz rejection</b>		<b>Default value</b>
33	Unipolar signal, 50Hz rejection		
N2	A/D conversion rate in Meas/s		
	50Hz rejection	60Hz rejection	
34	6,25	7,5	
33	12,5	15	
32	25	30	
31	50	60	
<b>30</b>	<b>100</b>	<b>120</b>	<b>Default value</b>
3C	200	240	
3B	400	480	
3A	800	960	
39	1600	1920	

To act the converter settings change, it is mandatory to:

Store in EEPROM with D1<sub>H</sub> code **AND** Reset probe (power off or D0<sub>H</sub>.code).

### 5.3.2 Digital filter order and band-stop filter activation :

Reading code	Writing code	N	Data storage *
53 <sub>H</sub>	54 <sub>H</sub>	1 (or 2, reading)	N

*Format* : Coded according to the following table :

N1	Function	Note
30	Low-pass filter disabled	
32	2 <sup>nd</sup> order Bessel/Butterworth digital low-pass filter	Default value
33	3 <sup>rd</sup> order Bessel/Butterworth digital low-pass filter	
34	4 <sup>th</sup> order Bessel/Butterworth digital low-pass filter	
<b>N2</b>		
31	2 <sup>nd</sup> order digital stop-band filter enabled	
30	digital stop-band filter disabled	Default value

*Description* : the filter recurrence relations of the filters are as follows :

- **Low-pass filter :**

$$2^{\text{nd}} \text{ order : } S_n = 1/A(e_n + 2e_{n-1} + e_{n-2} - BS_{n-1} - CS_{n-2})$$

$$3^{\text{rd}} \text{ order : } S_n = 1/A(e_n + 3e_{n-1} + 3e_{n-2} + e_{n-3} - BS_{n-1} - CS_{n-2} - DS_{n-3})$$

$$4^{\text{th}} \text{ order : } S_n = 1/A(e_n + 4e_{n-1} + 6e_{n-2} + 4e_{n-3} + e_{n-4} - BS_{n-1} - CS_{n-2} - DS_{n-3} - ES_{n-4})$$

- **Stop-band filter:**

$$2^{\text{nd}} \text{ order : } S_n = X(e_n + e_{n-2}) + Y(e_{n-1} - S_{n-1}) - ZS_{n-2}$$

Both filters coefficients depend on the A/D conversion rate and on cut-off frequencies. The determination of these coefficients can be easily achieved using **eNodView** simulation tools. The order and the coefficients are linked; please modify them at the same time.

### 5.3.3 Low-pass filter coefficients :

Setting	Reading code	Writing code	N	Data storage *
<b>1/A coefficient</b>	<b>54<sub>H</sub></b>	<b>55<sub>H</sub></b>	<b>8</b>	<b>N</b>
<b>B coefficient</b>	<b>56<sub>H</sub></b>	<b>57<sub>H</sub></b>	<b>8</b>	<b>N</b>
<b>C coefficient</b>	<b>58<sub>H</sub></b>	<b>59<sub>H</sub></b>	<b>8</b>	<b>N</b>
<b>D coefficient</b>	<b>5A<sub>H</sub></b>	<b>5B<sub>H</sub></b>	<b>8</b>	<b>N</b>
<b>E coefficient</b>	<b>5C<sub>H</sub></b>	<b>5D<sub>H</sub></b>	<b>8</b>	<b>N</b>

*Format* : Coded in ASCII hexadecimal. Low-pass digital filter coefficients are expressed in simple precision float variables (32 bits). They are coded by dividing the 32 bits in successive quartets (see example in Appendix A).

*Default values* : 1/A = 0.01669952 ; B = -107.652423 ; C = 73.12416882 ; D = -17.35349542 ; E = 0  
these values fit to a 3<sup>rd</sup> order Butterworth low-pass filter with a 10-Hz cut-off frequency at a 100 meas/s A/D conversion rate.

*Description* : The determination of the coefficients can be easily achieved using **eNodView** simulation tools. Be careful to modify the filter order and the coefficient at the same time.

### 5.3.4 Stop-band filter coefficients :

Setting	Reading code	Writing code	N	Data storage *
<b>X coefficient</b>	<b>88<sub>H</sub></b>	<b>89<sub>H</sub></b>	<b>8</b>	<b>N</b>
<b>Y coefficient</b>	<b>8A<sub>H</sub></b>	<b>8B<sub>H</sub></b>	<b>8</b>	<b>N</b>
<b>Z coefficient</b>	<b>8C<sub>H</sub></b>	<b>8D<sub>H</sub></b>	<b>8</b>	<b>N</b>

**Format :** Coded in ASCII hexadecimal. stop-band digital filter coefficients are expressed in simple precision float variables (32 bits). There are coded by dividing the 32 bits in successive quartets (see example in Appendix A).

**Default values :** X = 0.9289047 ; Y = -1.7163921 ; Z = 0.857809, these values fit to a 400 meas/s A/D conversion rate and 50Hz central frequency and a  $\pm 10$ Hz band. By default this filter is disabled, before activating it please set coefficients fitting to the application.

**Description :** The coefficients determination can be easily achieved using **eNodView** simulation tools. Saved in EEPROM using D1H command.

### 5.3.5 Self-adaptive filter :

Reading code	Writing code	N	Data storage *
5E <sub>H</sub>	5F <sub>H</sub>	2 (read) 1 (write)	N

**Format :** although the filter activation is done with N = 1, reading its state is done with N = 2. The filter state is coded on N2. (N1 is dedicated to the stability criterion)

N2	Self-adaptive filter	
30	self-adaptive filter disabled	Default value
31	self-adaptive filter enabled	

**Description : self-adaptive filter :** The self-adaptive filter can be set in cascade with previous filters. The aim of this filter is to eliminate erratic values and to average consistent measurements. It is particularly useful in static measurements, avoid using it in dynamic or dosing process.

### 5.3.6 Stability criterion :

Reading code	Writing code	N	Data storage *
84 <sub>H</sub>	85 <sub>H</sub>	2 (read) 1 (write)	N

**Format ASCII :** although the stability criterion is modified with N = 1, reading is done with N = 2. The stability criterion is coded on N1 (N2 is dedicated to the self-adaptive filter activation cf. § 5.3.5)

**Description :** motion is indicated by bit b4 of the status bytes (b4 = 1 if no motion). The stability criterion can be set according to the following table (d = scale interval) :

N1	Stability interval	Notes
30	no motion detection	⇒ always stable (impossible if legal for trade enabled)
31	0.25 d	<b>by default and if legal for trade enabled</b>
32	0.5 d	⇒ impossible if legal for trade enabled
33	1 d	
34	2 d	

Current measurement is stable if X consecutive measurements following the reference measurement are included in the stability interval else the current measurement becomes the reference. X depends on the A/D conversion rate (see following table) :

A/D conversion rate (meas/s)		X
50 Hz rejection	60 Hz rejection	
6,25	7,5	1
12,5	15	2
25	30	3
50	60	5
100	120	9
200	240	17
400	480	33
800	960	65
1600	1920	129

## 5.4 Logical inputs/outputs configuration

### 5.4.1 Logical inputs assignment :

Reading code	Writing code	N	Data storage *
60 <sub>H</sub>	61 <sub>H</sub>	4	N

*Format/description* : Coded according to the following table :

The bytes N1 and N2 correspond to the logical input 1 and the bytes N3 and N4 correspond to the logical input 2.

N1 and N2 or N3 and N4		Assignment	Function
N1 ou N3			
negative logic	positive logic		
30	38	none	⇒ logical inputs have no effect
31	39	tare	⇒ tare command
32	3A	zero	⇒ limited to $\pm 10\%$ range of the maximum capacity or $\pm 2\%$ in legal for trade functioning.
33	3B	Send measure/ Dynamic zero acquisition	⇒ in transmitter mode, send a measurement on the falling or rising entry edge. ⇒ in CW mode, get a new zero value limited to $\pm 10\%$ of maximum capacity after a time that can be configured.
34	3C	measurement window	⇒ in transmitter mode, send measurements while the input is maintained
35	3D	clear	⇒ in transmitter mode, cancels the tare ⇒ in checkweigher mode, cancel the checkweigher result.
36	3E	start cycle or enable start cycle	⇒ in checkweigher mode, start a cycle on trigger level.
37	3F	stop CW cycle	⇒ on trigger level
N2 or N4			
30		gross	sent measurements are gross measurements
32		net	sent measurements are net measurements
34		A/D converter points	sent measurements are A/D converter points

Note: In CW mode, if 2 inputs are set as “start new cycle”, “stop cycle”, “clear”, Input 1 has priority and input 2 is disabled. For “start cycle”, input has priority on trigger level (which is then disabled). Stored in EEPROM using D1<sub>H</sub> command.

### 5.4.2 Debounce time :

Reading code	Writing code	N	Data storage *
62 <sub>H</sub>	63 <sub>H</sub>	1 to 5	N

*Format* : Coded in ASCII (non-significant zero are not mandatory). Duration expressed in ms, comprised between 0 and 65535 ms.

*default value* : 80<sub>d</sub>

*Description* : Debounce time corresponds to the minimum required stabilization time of the logical inputs before their activation. If the input level varies within this interval, it is ignored.  
Stored in EEPROM using D1H command.

### 5.4.3 Logical outputs 1&2 and 3&4 assignment :

Settings	Reading code	Writing code	N	Data storage *
<b>outputs 1&amp;2</b>	<b>64<sub>H</sub></b>	<b>65<sub>H</sub></b>	<b>4</b>	<b>N</b>
<b>outputs 3&amp;4</b>	<b>66<sub>H</sub></b>	<b>67<sub>H</sub></b>	<b>4</b>	<b>N</b>

*Format* : The bytes N1 and N2 correspond to the output 1 (or 3) and the bytes N3 and N4 correspond to the output 2 (or 4).

*Default values* : logical outputs 1 and 2 = 36313731<sub>H</sub> (1 : positive logic, FF ; 2 : positive logic, CF); logical outputs 3 and 4 = 38313931<sub>H</sub> (positive logic, emptying/reloading ; 4 : positive logic, result out of tolerances)

*Description* : Depending on the version, digital load-cell includes up to 4 logical outputs which can be configured in different way as described in the following table :

**Note** : Digital load-cell in its 2 x 5-pins version connectors does not include logical outputs on the connectors. Nevertheless these outputs are managed and can be accessible by the communication bus.

Stored in EEPROM using D1H command.

N1 or N2		Assignment	Notes
Negative logic	Positive logic		
30	38	set points	⇒ Set point 1 assigned to output 1 ⇒ Set point 2 assigned to output 2 ⇒ Set point 3 assigned to output 3 ⇒ Set point 4 assigned to output 4
31	39	motion	
32	3A	Checkweigher result available	⇒ Checkweigher mode
33	3B	cycle in progress	⇒ Checkweigher mode
34	3C	defective measurement	⇒ errors description contained in the status word associated to the measure
35	3D	logical input1 (or2) image	⇒ Image of the input 1 on outputs 1 and/or 3 ⇒ Image of the input 2 on outputs 2 and/or 4
36	3E	Level on request	⇒ Level on request in transmitter mode (see command register).

**Note :**

- Sensor 2x5-pins connector version does not have available logical output on its connectors. Nevertheless logical outputs are managed and can be accessible by the communication bus.
- When several output are assigned to "cycle in progress" or "available result", only the output with the highest number will be assigned to this function.



#### 5.4.4 Set points high & low values :

Settings	Writing code	Reading code	N	Default value *
set point 1 high level	75 <sub>H</sub>	74 <sub>H</sub>	1 to 8	80000d
set point 1 low level	77 <sub>H</sub>	76 <sub>H</sub>	1 to 8	70000d
set point 2 high level	71 <sub>H</sub>	70 <sub>H</sub>	1 to 8	60000d
set point 2 low level	73 <sub>H</sub>	72 <sub>H</sub>	1 to 8	50000d
set point 3 high level	6D <sub>H</sub>	6C <sub>H</sub>	1 to 8	40000d
set point 3 low level	6F <sub>H</sub>	6E <sub>H</sub>	1 to 8	30000d
set point 4 high level	69 <sub>H</sub>	68 <sub>H</sub>	1 to 8	20000d
set point 4 low level	6B <sub>H</sub>	6A <sub>H</sub>	1 to 8	10000d

Format : Coded in ASCII (non-significant zero are not necessary). Value between 0 and  $\pm 1000000_d$ .

default values : Set point 1 high level = 80000<sub>d</sub> ; set point 1 low level = 70000<sub>d</sub>

Set point 2 high level = 60000<sub>d</sub> ; set point 2 low level = 50000<sub>d</sub>

Set point 3 high level = 40000<sub>d</sub> ; set point 3 low level = 30000<sub>d</sub>

Set point 4 high level = 20000<sub>d</sub> ; set point 4 low level = 10000<sub>d</sub>

Description : these settings give the high and low limits for each set point. The set points state also depends on functioning mode 'window' or 'hysteresis' (see § 5.4.5).

Set point 1 corresponds to output 1, set point 2 to output 2, set point 3 to output 3 and set point 4 to output 4.

#### 5.4.5 Set points functioning

Reading code	Writing code	N	Data storage *
78 <sub>H</sub>	79 <sub>H</sub>	4	N

Format : Coded according to the following table :

The byte N1 corresponds to set point 1 (output 1), N2 to set point 2 (output 2), N3 to set point 3 (output 3) and N4 to set point 4 (output 4).

N1 or N2		Function
Window commutation	Hysteresis commutation	
30	31	set point on gross measurement, any mode
32	33	set point on net measurement, any mode
34	/	set point on CW results in range
36	37	CW running
38	/	set point on CW results out of range

Hysteresis commutation does not apply on "set point on CW results in range" and "set point on CW results out of range".

Stored in EEPROM using D1<sub>H</sub> command.

## 5.5 Legal for trade

#### 5.5.1 Metrological version number :

Reading code	Writing code	N	Data storage *
27 <sub>H</sub>	/	5	/

*Format* : Coded in ASCII.

*Description* : Identify the version of the part of the software that is dedicated to the metrology and the measurement exploitation.

### 5.5.2 Legal for trade switch :

Reading code	Writing code	N	Data storage *
80 <sub>H</sub>	81 <sub>H</sub>	1	Y

*Format* : the activation of the settings related to the use of sensor in compliance with legal for trade use is done by setting N :

- ⇒ 30 : legal for trade disabled (default value)
- ⇒ 31 : legal for trade enabled

*Default value* : 30<sub>H</sub>

*Description* : The activation of legal for trade has the following consequences :

- the legal for trade counter is incremented every time a storage in EEPROM is requested if a metrological setting has been modified
- a new legal for trade CRC-16 value is calculated every time a storage in EEPROM is requested if a metrological setting has been modified
- taring is now impossible if gross measurement is negative.
- reading a measurement during 15 seconds after power-up or a software reset is impossible (digital load-cell returns ????????)
- zero acquisition range is reduced from 10% of the capacity to 2%.
- reading the net value during tare acquisition or the gross value during zero acquisition is impossible (returns ????????)
- The stability criterion is forced to 0.25d and cannot be modified anymore. An attempt to change its value is refused, sensor transmits an error frame.

### 5.5.3 Legal for trade counter :

Reading code	Writing code	N	Data storage *
82 <sub>H</sub>	/	5	/

*Format* : read-only value between 1 et 65535d.

*Description* : if the legal for trade option is switched ON, the legal for trade counter is incremented every time a storage in EEPROM is requested if one (or several) of these settings has been modified :

- Analog to digital configuration
- Span coefficient
- Span adjusting coefficient
- Scale interval
- Maximum capacity
- Zero calibration in converter points
- Legal for trade switch
- Zero modes
- Motion settings

### 5.5.4 Legal for trade CRC-16 :

Reading code	Writing code	N	Data storage *
84 <sub>H</sub>	/	5	/

*Format* : read-only hex. value between 0000H and FFFFH.

*Description* : if the legal metrology option is switched ON, a new legal metrology CRC-16 is calculated every time a storage in EEPROM is requested if one (or several) of the settings listed in § 5.5.3 has been modified.

### 5.5.5 Zero modes :

Reading code	Writing code	N	Data storage *
86 <sub>H</sub>	87 <sub>H</sub>	1	Y

Format/description : Coded according to the following table :

Bits B15 ... b0	Function	Note
<b>bit b0</b>	<b>Zero tracking</b>	
1	zero tracking enabled	⇒ effective on $\pm 10\%$ range of the maximum capacity or $\pm 2\%$ in legal for trade functioning
0	zero tracking disabled	by default
<b>bit b1</b>	<b>Zero after reset</b>	
1	initial zero setting enabled	⇒ effective on $\pm 10\%$ range of the maximum capacity or $\pm 2\%$ in legal for trade functioning
0	initial zero setting disabled	by default
<b>bit b2</b>	<b>CW automatic zero correction</b>	
1	CW automatic zero correction in specified range	cf. description in user manual réf. 195752
0	No automatic correction	by default
<b>b15 ... b8</b>	<b>Correction range</b>	
0 to 255	Positive and negative zero correction in CW mode.	Only if b2 is set to 1 0 by default

The value is between 0 and 255. It defines the correction range from 0 to 255d.  
In legal for trade, this value is automatically limited to  $\pm 5d$ .

The automatic zero correction in checkweigher correct the zero variation on a conveyor belt which get dirty (see User manual ref 195752).

Once the correction is activated (cf sub index 0x01 Zero type) it correct the reference zero (calculated during the calibration or when sensor boot up, in successive time steps and with a defined duration.

In legal for trade, zero is not corrected if the measure is stable.

## 5.6 Checkweigher settings

See user manual (195752) for more information

### 5.6.1 Stabilization Time (Ts) in checkweigher mode :

Reading code	Writing code	N	Data storage *
<b>94<sub>H</sub></b>	<b>95<sub>H</sub></b>	<b>5</b>	<b>Y</b>

Format : Time Ts in milliseconds, between entre 0 et 65 535<sub>d</sub>

Default value: 10000<sub>d</sub>

Description : Stabilization time is effective without EEPROM saving.  
Stored in EEPROM using D1<sub>H</sub> command.

### 5.6.2 Measuring Time (Tm) in checkweigher mode:

<i>Reading code</i>	<i>Writing code</i>	<i>N</i>	<i>Data storage *</i>
<b>96<sub>H</sub></b>	<b>97<sub>H</sub></b>	<b>5</b>	<b>Y</b>

*Format* : Time Tm in milliseconds, between 0 and 65 535<sub>d</sub>

*Default value* : 200<sub>d</sub>

*Description* : Time needed to calculate the checkweigher result. Measuring time is effective without EEPROM saving.

Stored in EEPROM using D1H command.

### 5.6.3 Acquisition Time and/or Dynamic zero correction :

<i>Reading code</i>	<i>Writing code</i>	<i>N</i>	<i>Data storage *</i>
<b>F5<sub>H</sub></b>	<b>F4<sub>H</sub></b>	<b>5</b>	<b>Y</b>

*Format* : Time in ms, between 0 and 65535<sub>d</sub>. In legal for trade mode, this time could not be less than 1000<sub>d</sub> (1s)

*Default value* : 100<sub>d</sub>

*Description* :

- Zero Dynamic acquisition. In checkweigher mode, when an input assigned to the “zero dynamic” function is enabled or when an zero dynamic acquisition command is received, sensor calculate the mean of the measures during the specified time. A new zero is used if the result is in the range  $\pm 10\%$  of the maximum capacity or  $\pm 2\%$  in legal for trade mode. Motion is not necessary.
- Zero Dynamic adjustment. In checkweigher mode, if the automatic zero adjustment is enabled; this time is the time used to calculate the zero adjustment.

Acquisition time is effective without EEPROM saving.

Stored in EEPROM using D1H command.

### 5.6.4 Checkweigher correction coefficient:

<i>Reading code</i>	<i>Writing code</i>	<i>N</i>	<i>Data storage *</i>
<b>F3<sub>H</sub></b>	<b>F2<sub>H</sub></b>	<b>5</b>	<b>Y</b>

*Format* : in hexadecimal, Values between 900 000<sub>d</sub> and 1 100 00<sub>d</sub>

*Default value* : 1 000 000<sub>d</sub>

*Description* : Checkweigher result can be adjusted with a coefficient (unit: 1/1000000). For example, a value of 1000000 means a coefficient of 1.0.

Stored in EEPROM using D1H command.

### 5.6.5 Set point for checkweigher start cycle :

<i>Reading code</i>	<i>Writing code</i>	<i>N</i>	<i>Data storage *</i>
<b>98<sub>H</sub></b>	<b>99<sub>H</sub></b>	<b>5</b>	<b>Y</b>

*Format* : Values between 0 and  $\pm 1\,000\,000$ <sub>d</sub>

*Default value* : 10000<sub>d</sub>

*Description* : Set point is used in checkweigher mode. When the object arrives on the weighing device, weight determination could start either:

- With an input assigned to “cycle start”
- With a threshold value

**Note** : In checkweigher mode, if an input is configured as “start checkweigher cycle”, the “set point” is ignored.

Set point is effective without EEPROM saving.

## 5.7 Measurements

### 5.7.1 Sampling period (transmitter mode) :

Reading code	Writing code	N	Data storage *
CA <sub>H</sub>	CB <sub>H</sub>	from 1 to 5	Y

*Format* : ASCII; duration expressed in ms, comprised between 0 and 65535<sub>d</sub>.

*Default value* : 00<sub>H</sub>

*Description* : the 'sampling period' setting defines the measurements transmission period on the bus when continuous transmission is active ('measurement window' or after a 'start continuous transmission' command).

If this setting is set to 0, **measurements transmissions are synchronized on the A/D conversion period** (for example at a 400 meas/s conversion rate, a measurement is transmitted every 2.5 ms).

Stored in EEPROM using D1H command.

### 5.7.2 Gross :

Reading code	Writing code	N	Data storage *
10 <sub>H</sub>	/	8 or 3	/

*Format* : the current gross measurement is coded on :

- 8 ASCII bytes in **SCMbus standard format**.
- 3 hexadecimal bytes in **SCMbus fast format**.

*Description* : Current gross measurement value.

If the 'legal for trade' option is switched ON, during the **15 seconds** that follow the power-up, this variable is set to ???????? as for a zero request.

### 5.7.3 Tare :

Reading code	Writing code	N	Data storage *
11 <sub>H</sub>	/	8 or 3	/

*Format* : the last tare value is coded on :

- 8 ASCII bytes in **SCMbus standard format**.
- 3 hexadecimal bytes in **SCMbus fast format**.

*Description* : Current tare value.

### 5.7.4 Net :

Reading code	Writing code	N	Data storage *
12 <sub>H</sub>	/	8 or 3	/

*Format* : the current net measurement is coded on :

- 8 ASCII bytes in **SCMbus standard format**.
- 3 hexadecimal bytes in **SCMbus fast format**.

*Description* : Current net measurement value.

If the 'legal for trade' option is switched ON, during the **15 seconds** that follow the power-up, this variable is set to ???????? as for a zero request.

### 5.7.5 A/D converter points :

Reading code	Writing code	N	Data storage *
13 <sub>H</sub>	/	8 or 3	/

*Format* : the measurement in A/D converter points is coded on :

- 8 ASCII bytes in **SCMbus standard format**.
- 3 hexadecimal bytes in **SCMbus fast format**.

*Description* : Current A/D converter points value. Gives a non calibrated measurement.

### 5.7.6 Checkweigher result:

Reading code	Writing code	N	Data storage *
14 <sub>H</sub>	/	8	/

*Format* : signed hexadecimal (two's complement).

*Description* : Checkweigher result is a net result. If the result is not valid, the register contains 0xFFFFFFFF. This value can be initialized thanks to the command "clear" or an input assigned to this function.

### 5.7.7 Number of processed cycles :

Reading code	Writing code	N	Data storage *
15 <sub>H</sub>	/	8	/

*Format* : ASCII.

*Description* : : in dosing functioning modes, the number of complete cycles can be read through this command. This value can be reset by the 'clear' command.

### 5.7.8 Average value :

Reading code	Writing code	N	Data storage *
16 <sub>H</sub>	/	8	/

*Format* : ASCII.

*Description* : : in dosing functioning modes, the average dosing value is calculated at the end of each dosing cycle during the whole process. The average value can be read through this command. This value can be reset by the 'clear' command.

### 5.7.9 Checkweigher running total :

Reading code	Writing code	N	Data storage *
17 <sub>H</sub>	/	8	/

*Format* : ASCII.

*Description* : The sum of obtained CW results is calculated at the end of each cycle during the whole process. In CW functioning modes, the cumulated value of the CW results can be read through this register. This value can be reset by the 'clear' command..

### 5.7.10 Standard deviation :

Reading code	Writing code	N	Data storage *
18 <sub>H</sub>	/	8	/

*Format* : ASCII hexadecimal ; the standard deviation is expressed as single precision float variables (32 bits). Its value is divided into successive quartets (cf. example in appendix A).

*Description* : in dosing functioning modes, the standard deviation on the results is calculated and updated after each complete cycle. This value can be reset by the 'clear' command or a logical input to this function.

### 5.7.11 Checkweigher result quality :

Reading code	Writing code	N	Data storage *
EF <sub>H</sub>	/	8	/

*Format* : simple precision float value.

*Description* : Checkweigher result quality corresponds to the standard deviation of the measures recorded during the acquisition time.

We have a better precision when the Checkweigher result quality is lower.

## 5.8 Other settings

### 5.8.1 Product version :

<i>Reading code</i>	<i>Writing code</i>	<i>N</i>	<i>Data storage *</i>
<b>26<sub>H</sub></b>	/	<b>5</b>	/

*Format* : Coded in ASCII.

*Description* : Identifies sensor firmware version.

### 5.8.2 Text box :

<i>Reading code</i>	<i>Writing code</i>	<i>N</i>	<i>Data storage *</i>
<b>92<sub>H</sub></b>	<b>93<sub>H</sub></b>	<i>from 1 to 2</i>	<b>Y</b>

*Format* : a 16-bytes free memory area for ASCII codes storage.

*Default value* : 2020<sub>H</sub>

*Description* : this is a user memory space that can be used to store some information like the last calibration date.

Stored in EEPROM using D1H command.

## **6 APPENDIX A : EXAMPLE FOR CODING A SINGLE PRECISION FLOAT PARAMETER**

Example of a coefficient to transmit :

- Value (floating) : 1,64780235
- Corresponding value in hexadecimal : 3FD2 EB30

⇒ Coded in SCMBUS : **333F 3D32 3E3B 3330**