



eNod4-B ETHERNET

Digital Process Transmitter



1 ENOD4 PRODUCT RANGE	6
1.1 General presentation.....	6
1.2 Versions	6
1.2.1 Communication protocol versions	6
1.2.2 IO+ version.....	6
1.3 eNodView Software.....	7
2 COMMUNICATION AND FUNCTIONING MODES.....	8
2.1 Communication protocols Modbus RTU and SCMBus	8
2.2 Functioning mode	8
2.3 HMI name	8
2.4 Simultaneous functioning of communications	9
2.4.1 Standard version	9
2.4.2 Profibus version.....	10
2.4.3 Ethernet versions	11
3 MODBUS RTU	12
3.1 Physical interfaces	12
3.2 Byte format.....	12
3.3 Modbus RTU supported functions.....	12
3.4 Frames structure	12
3.4.1 Function (03H/04H) – read N input registers (N = 30 max).....	12
3.4.2 Function (06H) – write single register.....	13
3.4.3 Function (10H) – preset multiple registers (N = 30 max).....	13
3.4.4 Error frames	13
3.5 Address and Baud rate	13
3.6 Product identification.....	13
3.7 Measurement transmission.....	14
3.8 EEPROM error management.....	14
4 SCMBUS / FAST SCMBUS	15
4.1 Physical interfaces	15
4.2 SCMBus and fast SCMBus features	15
4.3 Byte format.....	15
4.4 Frames structure	16
4.4.1 Transmission organization	16
4.4.2 Reading request	16
4.4.3 Functional command request (tare, zero...)	16
4.4.4 Error frame.....	16
4.5 Address and Baud rate	17
4.6 Product identification.....	17
4.7 Measurement transmission.....	17
4.8 Continuous transmission	17
4.9 EEPROM error management.....	17
5 MODBUS TCP	18
5.1 Physical interface	18
5.2 General information.....	18
5.3 Frames structure	20
5.4 Network configuration	20
5.5 Modbus TCP LED	21

5.6 I/O scanning	22
6 ETHERNET/IP	24
6.1 Physical interface	24
6.2 General information	24
6.2.1 EtherNet/IP “Open standard” protocol	24
6.2.2 Common Industrial Protocol (CIPTM)	25
6.2.3 CIPTM Encapsulation Format.....	26
6.3 Network configuration	27
6.4 EtherNet/IP LED	28
6.5 I/O scanning / implicit messaging	28
6.5.1 Standard version (without IO+)	30
6.5.2 IO+ version.....	30
7 PROFINET IO	31
7.1 Physical interface	31
7.2 Network settings	31
7.3 Definition of protocols roles	32
7.4 Main scenario	33
7.5 Alternative scenario: control, maintenance, supervision	34
7.6 Alternative scenario: eNod4 error application detected	34
7.7 PROFINET IO LEDs	34
7.8 Data arrangement.....	35
7.8.1 Cyclic data (IO Data)	35
7.8.2 Acyclic data (Records)	35
7.9 PROFINET IO exchange of cyclic data.....	35
8 ETHERCAT	38
8.1 Physical interface	38
8.2 Network settings	38
8.3 Communication protocol.....	38
8.4 EtherCAT LEDs.....	39
8.5 Data arrangement.....	40
8.5.1 Acyclic data (Objects).....	40
8.5.2 Cyclic data (IO Data)	40
8.6 EtherCAT exchange of cyclic data	40
9 MEASUREMENT AND STATUS	43
9.1 Measurement transmission.....	43
9.1.1 Gross measurement.....	43
9.1.2 Net measurement	43
9.1.3 Tare value	44
9.1.4 Factory calibrated points	44
9.1.5 Preset Tare value	44
9.1.6 Measurement status.....	44
9.2 Weighing diagnosis.....	45
9.2.1 Global weighing diagnosis	45
9.2.2 Sensor input control	46
10 PROCESSING FUNCTIONAL COMMANDS	47
10.1 Principles	47
10.2 Functional commands list.....	48
10.3 Functional commands description.....	49

10.3.1	Reset	49
10.3.2	EEPROM storage	49
10.3.3	Restore default settings	49
10.3.4	Zero	49
10.3.5	Tare	50
10.3.6	Cancel tare	50
10.3.7	Cancel last command	50
10.3.8	Theoretical scaling	50
10.3.9	Zero adjustment	50
10.3.10	Start physical calibration	50
10.3.11	Calibration zero acquisition	50
10.3.12	Segment 1 acquisition	50
10.3.13	Segment 2/3 acquisition	50
10.3.14	Store calibration	51
10.3.15	Logical outputs 1-4 activation/deactivation	51
10.3.16	Zero offset	51
10.3.17	Dynamic zero	51
10.3.18	Preset tare	51
10.3.19	Sensor input reference	51
10.3.20	Sensor input control	51
10.3.21	Init speed sensor calibration	51
10.3.22	End speed sensor calibration	52
10.3.23	Init belt length calibration	52
10.3.24	End belt length calibration	52
10.3.25	Flow rate correction	52
10.3.26	Start (batch/system)	52
10.3.27	Stop (batch/system)	52
10.3.28	Clear totalization & errors counter	52
10.3.29	Calibration of flow rate	53
10.3.30	PID parameters auto-adjustment	53
10.3.31	STOP & RESTART PID	53
10.3.32	Clear great total	53
10.3.33	Clear general total	53
11	CALIBRATION SETTINGS AND PROCEDURES	54
11.1	Principles	54
11.2	Calibration methods	55
11.3	Settings description	55
11.3.1	Maximum capacity	55
11.3.2	Number of calibration segments	55
11.3.3	Calibration loads 1/2/3	55
11.3.4	Sensor sensitivity	55
11.3.5	Scale interval	55
11.3.6	Zero calibration	56
11.3.7	Span coefficients 1/2/3	56
11.3.8	Span adjusting coefficient	56
11.3.9	Calibration place g value / place of use g value	56
11.3.10	Zero offset	56
12	FILTERS	57

12.1 Principles	57
12.2 Settings list.....	57
12.3 Settings description	57
12.3.1 A/D conversion rate.....	57
12.3.2 Filters activation & order	58
12.3.3 Low-pass filter cut-off frequency	58
12.3.4 Limitations	59
12.3.5 Band-stop filter high cut-off frequency	59
12.3.6 Band-stop filter low cut-off frequency	59
12.3.7 Moving average weight filter depth.....	59
12.3.8 Moving average flow rate/speed filter depth.....	59
13 CONFIGURATION OF INPUT/OUTPUT	60
13.1 Principles	61
13.1.1 Logical inputs.....	61
13.1.2 Analog output (IO+ version)	63
13.1.3 Logical outputs	65
13.2 Settings description	67
13.2.1 Logical inputs assignment.....	67
13.2.2 Holding time (debounced time).....	68
13.2.3 Analog output(s) assignment (IO+ version)	69
13.2.4 External value to control analog output (IO+ version).....	69
13.2.5 Logical outputs 1&2 assignment.....	70
13.2.6 Logical outputs 3&4 assignment.....	71
13.2.7 Weight quantity per pulse on logical output.....	71
13.2.8 Set points functioning	72
13.2.9 Set points high and low values	73
13.3 Input/output level.....	74
14 LEGAL FOR TRADE OPTIONS.....	75
14.1 Principles	75
14.2 Settings description	75
14.2.1 Legal for trade switch	75
14.2.2 Legal for trade software version	75
14.2.3 Legal for trade counter.....	76
14.2.4 Legal for trade checksum	76
14.2.5 Zero functions	76
14.2.6 Stability criterion.....	76
14.2.7 Decimal point position.....	77
14.2.8 Weight unit	77
14.2.9 Flow rate time unit.....	78
14.2.10 Save Tare and Zero in non-volatile memory	78
15 BELT OPERATING MODES.....	79
15.1 Settings description	84
16 PROFINET IO	90
17 ETHERNET/IP REGISTER MAP	95
18 ETHERNET/IP ODVA COMMONLY DEFINED REGISTER MAP.....	100
19 MODBUS RTU AND MODBUS TCP REGISTERS TABLE	102
20 CRC-16 CALCULATION ALGORITHM.....	108

1 ENOD4 PRODUCT RANGE

1.1 General presentation

eNod4 is a high speed digital process transmitter with programmable functions and powerful signal processing capabilities. **eNod4** offers operating modes for advanced process control both static and dynamic.

Quick and accurate:

- Analog to digital conversion rate up to 1920 meas/s with maximum scaled resolution of $\pm 500\,000$ points.
- Digital filtering and measurement scaling.
- Measurement transmission up to 1 000 meas/s.

Easy to integrate into automated system:

- **USB, RS485** and **CAN** communication interfaces supporting **ModBus RTU**, **CANopen®** and **PROFIBUS-DPV1** (depending on version) communication protocols.
- Digital Inputs/Outputs for process control.
- Setting of node number by rotary switches and communication baud rate by dip switches.
- Integrated selectable network termination resistors.
- Wiring by plug-in terminal blocs.

1.2 Versions

1.2.1 Communication protocol versions

- Strain gauges load-cell conditioner with **CANopen®** and **ModBus RTU** communication.
- Strain gauges load-cell conditioner with **Profibus DP-V1** and **ModBus RTU** communication.
- Strain gauges load-cell conditioner with **Modbus TCP** and **ModBus RTU** communication.
- Strain gauges load-cell conditioner with **EtherNet/IP** and **ModBus RTU** communication.
- Strain gauges load-cell conditioner with **Profinet IO** and **ModBus RTU** communication.
- Strain gauges load-cell conditioner with **EtherCAT** and **ModBus RTU** communication.

EDS, GSD, ESI and GSDML configuration files for above protocols can be downloaded from our web site: <http://www.scaime.com>

1.2.2 IO+ version

In conjunction with all communication protocol versions, **eNod4** can supports an opto-insulated board fitted with:

- 2 additional digital inputs and 1 speed sensor dedicated input.
- 0-5V or 0-10V analog output voltage.
- 4-20mA, 0-24mA, 0-20mA or 4-20mA with alarm at 3.6mA analog output current.

1.3 eNodView Software

So as to configure **eNod4**, SCAIME provides eNodView software tool. **eNodView** is the software dedicated to eNod devices and digital load cell configuration from a PC. This simple graphical interface allows accessing the whole functionalities of **eNod4** for a complete setting according to the application.

eNodView features and functions:

- eNod4 control from a PC
- Calibration system
- Modification/record of all parameters
- Measure acquisition with graphical display
- Numerical filters simulation
- Frequential analysis FFT
- Process control
- Network parameter

eNodView software is available in English and French version and can be downloaded from our web site: <http://www.scaime.com> or ordered to our sales department on a CD-ROM support.

2 COMMUNICATION AND FUNCTIONING MODES

Name	Modbus address	EtherNet/IP Class/Attribute (hex/dec)	Profinet Record Index	Profinet cyclic Req Code	EtherCAT index/sub-index	Type	Access
Functioning mode / Serial protocol	0x003E	0x64/10	0x008C	R:0x02C2 W:0x02C3	0x2000 / 0x00	Uint	RW
HMI name	0x0034	0x64/21	0x00E0	/	0x3701 / 0x00	String	RW

2.1 Communication protocols Modbus RTU and SCMBus

Modbus RTU, SCMBus, and fast SCMBus communication protocols are accessible through AUX, USB. Modbus RTU or Profibus only depending on version on DB9 connection.

The protocol can be changed via the « Functioning mode/ serial protocol » register (see below).

bits b9b8	Protocol
00	SCMBus
01	Modbus RTU
11	Fast SCMBus

Note: To be applied, any modification of this setting must be followed by an EEPROM back up and device reboots (hardware or software).

2.2 Functioning mode

The « Functioning mode/ serial protocol » register offers the possibility to change the eNod4 application according to the following list:

bits b1b0	Functioning mode				
	eNod4-T	eNod4-C	eNod4-D	eNod4-F	eNod4-B
00	Transmitter	Transmitter	Transmitter	Transmitter	Transmitter
01	/	Checkweigher transmitter on request	Dosing by filling	Dosing	Belt scale
10	/	/	Dosing by unfilling	/	Belt weigh feeder

Note: To be applied, any modification of this setting must be followed by an EEPROM back up and device reboots (hardware or software).


2.3 HMI name

The “HMI name” is a string of 4 characters freely usable to identify the node on any HMI connected to eNod.


2.4 Simultaneous functioning of communications

2.4.1 Standard version

- DIN Version



- BOX Version




Simultaneous Communication	RS485 PLC	RS485 AUX	CAN
USB	Yes*	No	Yes*
RS485 PLC		Yes	No
RS485 AUX			Yes*


(*) Simultaneous use of CAN or RS485 PLC communication with USB or RS485 AUX can reduce performance of this interface.

2.4.2 Profibus version

- DIN Version



- BOX Version




Simultaneous Communication	Profibus	RS485 AUX
USB	Yes*	No
Profibus		Yes*


(*) Simultaneous use of Profibus with USB or RS485AUX can reduce performance of this interface.

2.4.3 Ethernet versions

- DIN Version



- BOX Version



<i>Simultaneous Communication</i>	<i>Ethernet</i>	<i>RS485 AUX</i>
<i>USB</i>	Yes*	No
<i>Ethernet</i>		Yes*

(*)Simultaneous use of Ethernet with USB or RS485 AUX can reduce performance of this interface.

3 MODBUS RTU

3.1 Physical interfaces

Modbus RTU communication protocol can be used either through **eNod4** USB port, AUX port. Modbus RTU or Profibus only depending on version on DB9 connection.

USB port behaves as a full duplex interface whereas the DB9 and AUX ports support half-duplex RS485 communication. Supported baud rates are 9600, 19200, 38400, 57600, and 115200.

For a complete description of the recommendations about **eNod4** RS485 connection, please refer to the user manual “characteristics and functioning” of the **eNod4**.

Note: using **eNod4** through USB requires installing first the necessary USB drivers available on the website <http://www.scaime.com>.

3.2 Byte format

Data transmitted to **eNod4** thanks to Modbus RTU communication protocol must respect following format:

- 1 start bit
- 8 data bits
- no parity
- 2 stop bits

Every Modbus RTU frame is ended by a CRC-16 2-bytes code whose polynomial generator is

$$G(x) = x^{16} + x^{15} + x^2 + 1$$

(cf. CRC-16 calculation algorithm).

3.3 Modbus RTU supported functions

As a Modbus RTU slave, **eNod4** supports following Modbus RTU functions:

Function	Code
<i>read N registers*</i>	03 _H / 04 _H
<i>write 1 register*</i>	06 _H
<i>write N registers*</i>	10 _H

* 1 register = 2 bytes, maximum admitted value for N is 30.

Note: Broadcast addressing is not allowed by **eNod4**.

3.4 Frames structure

During a read or write transaction, the two bytes of a register are transmitted MSB first then LSB.

If a data is coded on **4 bytes** (that means it requires two registers), **the two LSB are stored in the low address register and the two MSB are stored in the high address register.**

3.4.1 Function (03H/04H) – read N input registers (N = 30 max)

- request command sent to the slave :

slave address	03 _H or 04 _H	starting register offset	N registers	CRC16
1 byte	1 byte	2 bytes	2 bytes	2 bytes

- slave response :

<i>slave address</i>	<i>03_H or 04_H</i>	<i>NB *</i>	<i>data 1</i>	<i>...</i>	<i>CRC16</i>
1 byte	1 byte	1 byte	2 bytes	2 bytes	2 bytes

* NB: number of read bytes (= N*2)

3.4.2 Function (06H) – write single register

- request command sent to the slave :

<i>slave address</i>	<i>06_H</i>	<i>register offset</i>	<i>data</i>	<i>CRC16</i>
1 byte	1 byte	2 bytes	2 bytes	2 bytes

- slave response :

<i>slave address</i>	<i>06_H</i>	<i>register offset</i>	<i>data</i>	<i>CRC16</i>
1 byte	1 byte	2 bytes	2 bytes	2 bytes

3.4.3 Function (10H) – preset multiple registers (N = 30 max)

- request command sent to the slave :

<i>slave address</i>	<i>10_H</i>	<i>starting register offset</i>	<i>N registers</i>	<i>NB</i>	<i>Data 1</i>	<i>...</i>	<i>CRC16</i>
1 byte	1 byte	2 bytes	2 bytes	1 byte	2 bytes	2 bytes	2 bytes

- slave response :

<i>slave address</i>	<i>10_H</i>	<i>starting register offset</i>	<i>N registers</i>	<i>CRC16</i>
1 byte	1 byte	2 bytes	2 bytes	2 bytes

3.4.4 Error frames

- frame format in case of a transaction error :

<i>slave address</i>	<i>Function code + 80_H</i>	<i>error code</i>	<i>CRC16</i>
1 byte	1 byte	1 byte	2 bytes

- Error codes meaning :

<i>Error code</i>	<i>Meaning</i>	<i>description</i>
01_H	<i>illegal function</i>	<i>Modbus-RTU function not supported by eNod4</i>
02_H	<i>illegal data address</i>	<i>register address requested out of eNod4 register table</i>
03_H	<i>illegal data value</i>	<i>forbidden data values for the requested register</i>
04_H	<i>eNod4 not ready</i>	<i>eNod4 is not ready to answer (for example measurement request during a taring operation)</i>

3.5 Address and Baud rate

<i>Address Modbus RTU</i>	<i>Meaning</i>	<i>Access</i>	<i>Type</i>
0x0001	<i>Address and Baud rate</i>	RO	Uint

Reads the address and baud rate selected on the front panel via the rotary switches and dipo switches.

3.6 Product identification

Software and product versions of the **eNod4** are accessible via Modbus RTU.

<i>Address Modbus RTU</i>	<i>Meaning</i>	<i>Access</i>	<i>Type</i>
0x0000	SW and product version	RO	Uint

The 12 LSB bits define the software version (073_H = 115) and the 4 MSB bits define the product version (6_H for the **eNod4**).

3.7 Measurement transmission

As a master/slave protocol, measurement transmission in Modbus protocol is only done on master request.

3.8 EEPROM error management

Functioning and calibration parameters are stored in EEPROM. After every reset the entireness of parameters stored in EEPROM is checked. If a default appears, measurements are set to 0xFFFF and default is pointed out in measurement status.

4 SCMBUS / FAST SCMBUS

4.1 Physical interfaces

SCMBus and fast SCMBus communication protocols can be used either through **eNod4** USB port and AUX port.

USB port behaves as a full duplex interface whereas the DB9 and AUX ports support half-duplex RS485 communication. Supported baud rates are 9600, 19200, 38400, 57600, and 115200.

For a complete description of the recommendations about **eNod4** RS485 connexion, please refer to the user manual “characteristics and functioning” of the **eNod4**.

Note : using **eNod4** through USB requires installing first the necessary USB drivers available on the website <http://www.scaime.com>.

4.2 SCMBus and fast SCMBus features

SCMBus and its variant fast SCMBus can be imbricate into ModBus RTU protocol if the setting ‘communication protocol’ is set to SCMBus or fast SCMBus. That means that **eNod4** continues answering Modbus RTU frames but it also allows the device to send frames coded according to SCMBus/fast SCMBus format.

Each protocol has its advantages:

- in SCMBus measurements are transmitted as ASCII with the decimal point and the unit integrated to the frame
- fast SCMBus is dedicated to fast measurement transmission as the frames are the most compact as possible
- both protocols allow to communicate without any master request (continuous transmission or sampling triggered by a logical input)

4.3 Byte format

Data transmitted to **eNod4** thanks to SCMBus or fast SCMBus communication protocol must respect following format:

- 1 start bit
- 8 data bits
- no parity
- 2 stop bits


in SCMBus protocol, data is encoded as ASCII numeral characters (30_H 39_H) and ASCII hexadecimal characters (3A_H 3F_H).

in fast SCMBus protocol, data is encoded as signed hexadecimal (see frame structure paragraph) below.

SCMBus CRC-8 byte is generated by the following polynomial:

$$G(x) = x^8 + x^7 + x^4 + x^3 + 1$$

The CRC-8 polynomial result can be determined by programming the algorithm corresponding to the following diagram:



Note: The frame error detection can be ignored. Value **0xFF** of the CRC-8 always is admitted by **eNod4** and a received frame which is ended by such CRC-8 is considered as a frame without any error.

- Fast SCMBus checksum byte is obtained by summing all the frame previous bytes then setting b7 bit to 1.

4.4 Frames structure

4.4.1 Transmission organization

- frame : **eNod4** address first
- byte : lsb first
- multi-bytes data : MSB first

4.4.2 Reading request

- request

Address	Command	CR	CRC
1 Hex byte	1 Hex byte (command)	1 ASCII byte (0D _H)	1 Hex byte

- SCMBus response

Address	Status	Value	CR	CRC
1 Hex byte	2 Hex bytes	N ASCII Hex bytes	1 ASCII byte (0D _H)	1 Hex byte

If the 'decimal point position' and the 'unit' settings are assigned to a non-null value, the response frame when transmitting measurement contains the decimal point character (2E_H) and the unit that is separated from the measurement value by a space ASCII character (20_H).

- Fast SCMBus response

STX	Status word	Value	Cks	ETX
02 _H	2 Hex bytes	3 signed Hex bytes (2's complement)	Σ of previous bytes and b7 bit set to 1	03 _H

Note: Because values are encoded in signed hexadecimal bytes format (2's complement) some data bytes can be equal to **STX (02_H)** or **ETX (03_H)** or **DLE (10_H)** so before those specific bytes values a **DLE (10_H)** byte is inserted. The **eNod4** address is not transmitted in the frame.

4.4.3 Functional command request (tare, zero...)

- request :

Address	Command	CR	CRC
1 Hex byte	1 Hex byte (command)	1 ASCII byte (0D _H)	1 Hex byte

- response (SCMBus and fast SCMBus) :

Address	Command	CR	CRC
1 Hex byte	1 Hex byte (command)	1 ASCII byte (0D _H)	1 Hex byte

If the command execution is successful, **eNod4** sends back the request frame that has been received as an acknowledgement.

4.4.4 Error frame

In case of an error upon reception of a request, **eNod4** sends back an error frame that contains an error code:

- response (SCMBus and fast SCMBus) :

Address	Error code	CR	CRC
1 Hex byte	1 Hex byte (command)	1 ASCII byte (0D _H)	1 Hex byte

- The error codes are listed below:

<i>Error code</i>	<i>Meaning</i>	<i>Description</i>
<i>FE_H</i>	<i>unknown command</i>	<i>requested command is not supported by eNod4</i>
<i>FF_H</i>	<i>error during command execution</i>	<i>ex. : tare when gross meas.<0</i>

4.5 Address and Baud rate

Address and baud rate identical to Modbus RTU (See § Modbus RTU)

4.6 Product identification

Product identification identical to Modbus RTU (See § Modbus RTU)

4.7 Measurement transmission

Measurement transmission can be triggered by a master request but it might also be triggered and used through the following options:

- transmission triggered by a rising or falling edge on a logical input
- transmission at a configurable period (defined in ms) while a logical input is maintained at a given logical level
- continuous transmission at a configurable period (defined in ms) after a master request. The transmission is then stopped by another master instruction, be careful not to use this mode in half-duplex at a too high rate.

4.8 Continuous transmission

SCMbus and fast SCMbus communication protocols allow **eNod4** to transmit measurements at a user-defined rate without the need for successive master queries. To perform this measurement acquisition mode, it is necessary to set first the 'sampling period' (in ms):

<i>Address SCMbus</i>	<i>Description</i>	<i>Accès</i>	<i>Type</i>
<i>0x003F</i>	<i>SCMbus Measurement transmission period</i>	<i>RW</i>	<i>Uint</i>

A value of 0 implies that measurement transmission is synchronized on the A/N conversion rate. The continuous transmission is triggered and stopped by reception of the following commands:

<i>SCMbus/fast SCMbus functional command</i>	<i>Command code</i>
<i>start net measurement transmission</i>	<i>E0_H</i>
<i>start factory calibrated points transmission</i>	<i>E1_H</i>
<i>start brut measurement transmission</i>	<i>E2_H</i>
<i>stop continuous transmission</i>	<i>E3_H</i>

Note 1: the measurement transmission rate also depends on the baud rate. So, to achieve the fastest transmission, it is necessary to use the highest baud rate.

Note 2: as RS485 is a half-duplex communication medium, it can be a little hard to transmit the 'stop continuous transmission' query if the bandwidth is saturated. Therefore, prefer USB communication channel to reach the highest measurement transmission rate.

4.9 EEPROM error management

EEPROM management identical to Modbus RTU (See § Modbus RTU)

5 MODBUS TCP



When a configuration change occurs (change of Ethernet parameters, set default params via eNodView or eNodTouch) eNod4 Modbus-TCP absolutely must not be reset or power cycled within 10 seconds after send of the change. This could permanently damage the eNod. MS LED blinks green or red cyclically when in this "damaged" state.

5.1 Physical interface

eNod4 is fitted with an Ethernet interface on RJ45 connectors and is galvanically isolated.

The Auto-Crossover function is supported. Due to this fact the signals RX and TX may be switched on ETH1 and ETH2 interfaces.

Because Modbus TCP (or Modbus TCP/IP) shares the same physical and data link layers of traditional IEEE 802.3 Ethernet, physical interface remains fully compatible with the already installed Ethernet infrastructure of cables, connectors, network interface cards, hubs, and switches.


eNod4 allows topologies in tree, line or star network. It also allows ring-shaped topology since **RSTP (Rapid Spanning Tree Protocol)** has been implemented (**eNod4** is a simple node and cannot act as network supervisor).

Every **eNod4** drives two Ethernet ports and has an internal switch and hub functions, respectively the different circuits which are related to the special features of some Real-Time-Ethernet systems to build up a line structure.

5.2 General information

eNod4 is fitted with an Ethernet communication interface that supports protocols TCP (Transmission Control Protocol) and IP (Internet Protocol). These protocols are used together and are the main transport protocol for the internet. When Modbus information is sent using these protocols, the data is encapsulated by TCP where additional information is attached and given to IP. IP then places the data in a packet (or datagram) and transmits it on Ethernet network.

Construction of a Modbus TCP data packet and simplified OSI model communication layers representation:



TCP must establish a connection before transferring data, since it is a connection-based protocol.

The Master (or Client in Modbus TCP) establishes a connection with the Slave (or Server) **eNod4**. The Server **eNod4** waits for an incoming connection for the Client. Once a connection is established, the Server **eNod4** then responds to the queries from the Client until the Client closes the connection.


Modbus TCP/IP uses well-known specific port 502 to listen and receive Modbus messages over Ethernet.

Note: **eNod4** does not support **Modbus RTU over TCP** protocol (simply put, this is a Modbus RTU message transmitted with a TCP/IP wrapper and sent over a network instead of serial lines).

eNod4 supports **Modbus TCP (or Modbus TCP/IP)** protocol: a document **Modbus Messaging on TCP/IP implementation guide** provided by Schneider Automation outlines a modified protocol specifically for use over TCP/IP. The official Modbus specification can be found at **Modbus organization** (www.modbus.org).

ADU (Application Data Unit) and PDU (Protocol Data Unit): aside from the main differences between serial and network connections stated above, there are few differences in the message content between Modbus TCP and Modbus RTU.

Starting with Modbus RTU frame (**ADU**), the checksum disappears. From now on data integrity is granted by Ethernet Data Link layer. Slave ID address is suppressed and supplanted by an identifier (Unit ID) that is a part of a complementary data header called **MBAP** (Modbus Application Protocol) header. The MBAP header is 7 bytes long.



MBAP header: fields are defined below:

fields	Length (bytes)	Description	Client (Master)	Server (Slave)
Transaction Identifier	2	Transaction pairing (request / response Modbus)	Initiated by the Client	Echoed back by the Server
Protocol Identifier	2	0 = MODBUS Protocol	Initiated by the Client	Echoed back by the Server
Length	2	byte count of the remaining fields (Unit ID + Function Code + Data)	Initiated by the Client (request)	Initiated by the Server (response)
Unit Identifier	1	Identification of a remote server (non TCP/IP or other buses), 0x00 or 0xFF otherwise	Initiated by the Client	Echoed back by the Server

Supported functions: identical to Modbus RTU ones.

- Read multiple registers* : **03H / 04H**
- Write single register* **06H**
- Write multiple registers* **10H**

*1 register = 2 bytes

Maximal number of registers = 123

5.3 Frames structure

- By default and as in Modbus RTU, during a read or write transaction, the two bytes of a register are swapped. The MSB is transmitted first and then the LSB. However it may be possible using **eNodView** software to invert the swapping of data in a register.
- if a data is coded on 4 bytes (that means it requires two registers) , the two LSB are stored in the low address register and the two MSB are stored in the high address register Modbus RTU request command example sent to the slave in hexadecimal:

Slave address	03 _H or 04 _H	First register address	N registers	CRC16
1 byte	1 byte	2 bytes	2 bytes	2 bytes
11	03	00 7D	00 03	97 43

- Equivalent request in Modbus TCP:

Transaction Identifier	Protocol Identifier	Message length	Unit Identifier	03 _H or 04 _H	First register address	N registers
2 bytes	2 bytes	2 bytes	1 byte	1 byte	2 bytes	2 bytes
00 01	00 00	00 06	FF	03	00 7D	00 03

Modbus exception codes: like in Modbus RTU a server **eNod4** may generate an exception response to a client request.

- Exception codes table:

Error code	Exception	Description
01	Illegal Function	The function code received by eNod4 in the query is not allowed or invalid.
02	Illegal Data Address	The data address received in the query is not an allowable address for eNod4 or is invalid.
03	Illegal Data Value	A value contained in the query data field is not an allowable value or out of the limits
06	eNod4 Device Busy	eNod4 is not ready to answer (for example measurement request during a taring operation).

5.4 Network configuration

Every **eNod4** is identified on the network by an IP address, a subnet mask and a default gateway address. Network configuration can only be set using **eNodView** software at minimum version V.

IP address: the IP address is comprised of two parts: the network address or Net ID (first part), and the host address or Host ID (last part). This last part refers to a specific machine on the given sub-network identified by the first part. The numbers of bytes of the total four that belong to the network address depend on the Class definition (Class A, B, or C) and this refers to the size of the network.

Class C subnets share the first 3 octets of an IP address, giving 254 possible IP addresses for **eNod4** device. Recall that the first 00_H and last FF_H IP addresses are always used as a network number and broadcast address respectively.

eNod4 default local IP* address is **192.168.0.100**

*if IP static configuration set

Subnet mask: a Subnet Mask is used to subdivide the host portion of the IP address into two or more subnets. The subnet mask will flag the bits of the IP address that belong to the network address, and the remaining bits correspond to the host portion of the address.

The unique subnet to which an **eNod4** IP address refers to is recovered by performing a bitwise AND operation between the IP address and the mask itself, with the result being the sub-network address.

eNod4 subnet mask default value is the default Class C subnet mask **255.255.255.0**

Gateway address: a gateway is being used to bridge Ethernet to other networks like a serial sub-network of Modbus RTU devices in order to provide communication compatibility.

The IP address of the default gateway has to be on the same subnet as the local IP address. The value 0.0.0.0 is forbidden. If no gateway is to be defined then this value is to be set to the local IP address of the **eNod4** device.

Default gateway address has been set to **192.168.0.254**

DHCP functionality (Dynamic Host Configuration Protocol):

It's a protocol that automates network-parameter assignment and allows an **eNod4** device to dynamically configure (without any particular action) an IP address and other information that is needed for network communication. **eNod4** device needs imperatively to be connected on the sub-network to a DHCP server that allocates IP address and also DHCP functionality has to be activated in **eNod4** device.

A label affixed on every **eNod4** contains 6 bytes of its MAC address (Media Access Control Address) which is a unique identifier assigned to network interfaces for communications on any physical network segment.

In DHCP when the Master of the sub-network attributes an IP address to a Slave (**eNod4** device), it associates its unique MAC address to the IP address. So the MAC address is the only way for a Master to identify an **eNod4** device on the sub-network.

DHCP functionality is not activated by default (set to **static IP configuration**).

5.5 Modbus TCP LED

State of the **NS (Network Status)** bicolor LED is described in the table below:

<i>Color</i>	<i>State</i>	<i>Meaning</i>
Green	<i>Blinking 1Hz</i>	<i>Device READY but not CONFIGURED yet</i>
	<i>Blinking 5Hz</i>	<i>Device WAITING for communication</i>
	<i>Always on</i>	<i>CONNECTED (at least one TCP connection is established)</i>
Red	<i>Blinking 2Hz (On/Off rate 25%)</i>	<i>Internal Fault detect (like TCP connection lost)</i>
	<i>Always on</i>	<i>Communication fatal error</i>
-	<i>Always off</i>	<i>Device not powered or defective</i>

State of the **MS (Module Status)** bicolor LED is described in the table below:

Color	State	Meaning
Green	<i>Blinking</i>	Device WAITING FOR CONFIGURATION
	<i>Always on</i>	Device is OPERATING correctly
Red	<i>Blinking</i>	Communication error detected
	<i>Always on</i>	Fatal error detected
Red / Green	<i>Blinking</i>	Autotest at power on
-	<i>Always off</i>	Device not powered or defective

State of the **ACT / LINK** ETH1 and ETH2 network RJ45 connector LED:

Color	State	Meaning
LINK (Eth1 & Eth2) Green	<i>Always on</i>	A physical connection to the Ethernet exist
	<i>Always off</i>	Device not connected to the Ethernet
ACT (Eth1 & Eth2) Yellow	<i>On</i>	The device sends/receives Ethernet frames
	<i>Always off</i>	No traffic on the Ethernet

5.6 I/O scanning

The exchange of application data at a high refreshment rate is only possible in a specific range of Modbus addresses. Specified 49 Input registers that are exchanged in I/O scanning are defined in the table below:

<i>Register address (Hex)</i>	<i>Size in bytes (n)</i>	<i>Type</i>	<i>Name</i>	<i>Access</i>
007D	2	Uint	measurement status	RO
007E	4	long	gross measurement	RO
0080	4	long	tare value	RO
0082	4	long	net measurement	RO
0084	4	long	factory calibrated points	RO
0086	4	Float	instant flow rate	RO
0088	4	Float	average flow rate	RO
008A	4	Float	average belt speed	RO
008C	2	Uint	Belt alarms register	RO
008D	4	Ulong	Totalizer value (Great WU)	RO
008F	2	Uint	Complementary totalizer value	RO
0090	2	Uint	command register	R/W
0091	2	Uint	response register	RO
0092	4	long	Zero offset	R/W
0094	2	Uint	Logical I/O level	RO
0095	4	Float	Dosing weight deviation	RO
0097	4	long	Preset tare	RO
0099	2	Uint	Hardware state register	RO
009A	4	Float	Flow rate control output	RO
009C	4	Float	Dosing quality factor	R/W
009E	2	Uint	Dosing errors counter	RO
009F	4	Float	Integrated weight per length unit	RO
00A1	2	Uint	Control output value	RO
00A3	2	Uint	Belt status register	RO
00A4	4	Float	Totalization per belt revolution	RO
00A6	4	Float	Average flow rate (Great WU)	RO
00A8	2	Uint	Batch progress percent	RO
00A9	4	Ulong	Grand total (Great WU)	RO
00AB	4	Ulong	General total (Great WU)	RO
00AD	4	Ulong	eNod4 1ms counter*	RO

*for possible check of the performances

6 ETHERNET/IP



When a configuration change occurs (change of Ethernet parameters, set default params via eNodView or eNodTouch, change of address « Name of product » after a reset with option « Use rotary switch in product name ») eNod4 EtherNet/IP absolutely must not be reset or power cycled within 10 seconds after send of the change or reset. This could permanently damage the eNod. MS LED blinks green cyclically when in this "damaged" state.

EtherNet/IP uses Ethernet layer network infrastructure. It is built on the TCP (Transmission Control Protocol) and IP (Internet Protocol) protocols, but the "IP" in the name stands for "**Industrial Protocol**" and not an abbreviation for "Internet Protocol". EtherNet/IP is supported by four independent networking organizations

- ControlNet International (CI),
- The Industrial Ethernet Organization (IEA),
- The Open DeviceNet Vendor Association (ODVA),
- The Industrial Automation Open Network Alliance (IAONA).

6.1 Physical interface

eNod4 is fitted with two EtherNet ports on RJ45 connectors that are galvanically isolated.

The Auto-Crossover function is supported. Due to this fact the signals RX and TX may be switched on ETH1 and ETH2 interfaces. Auto-negotiation of link parameters applies to 10/100Mbit and full/half duplex operation.

Because EtherNet/IP shares the same physical and data link layers of traditional IEEE 802.3 Ethernet, physical interface remains fully compatible with already installed Ethernet infrastructure (cables, connectors, network interface cards, hubs, and switches).

EtherNet/IP automatically benefits from all further technology enhancements such as Gigabit Ethernet and Wireless technologies.

Tree, line or star network topologies are allowed by **eNod4**. Ring topology is also supported while Device Level Ring (DLR) protocol is implemented (as **eNod4** is not able to act as a ring supervisor, at least one active ring supervisor is required on the DLR network).


Every **eNod4** drives two Ethernet ports and has an internal switch and hub functions, respectively the different circuits which are related to the special features of some Real-Time-Ethernet systems to build up a line or ring structure.

6.2 General information

6.2.1 EtherNet/IP "Open standard" protocol

EtherNet/IP shares the same lower four layers of the OSI model common to all Ethernet devices. This makes it fully compatible with existing Ethernet hardware, such as cables, connectors, network interface cards, hubs, and switches. The application layer protocol is the Control and Information Protocol (CIP™).

eNod4 is fitted with an Ethernet communication interface that supports protocols **TCP** (Transmission Control Protocol), **UDP** (User Datagram Protocol) and **IP** (Internet Protocol). These protocols are used together and are the main transport protocol for the internet. When **CIP™** information is sent using these protocols, the data is encapsulated by TCP or UDP where additional information is attached and given to IP. IP then places the data in a packet (or datagram) and transmits it on **Ethernet** network.



By using TCP/IP, EtherNet/IP is able to send explicit messages, which are used to perform **client-server** type transactions between nodes. Nodes must interpret each message, execute the requested task and generate responses. Uploading and downloading of configuration data like setpoints and applicative parameters uses **explicit (or Class 3) messaging**.

TCP is connection-oriented and use well known TCP port number 44818 (0xAF12) for EtherNet/IP.

For real-time messaging, EtherNet/IP also employs UDP over IP, which allows messages to be unicast (one to one) or multicast (one to a group of destination addresses) in a **producer-consumer** model. This is how CIP™ I/O data transfers called **implicit (or Class1) messaging** is sent on EtherNet/IP. With implicit messaging, the data field contains no protocol information, only real-time I/O data. Since the meaning of the data is pre-defined at the time the connection is established, processing time is minimized during runtime. UDP is connectionless and makes **no guarantee that data will get from one device to another**; however, UDP messages are smaller and can be processed more quickly than explicit messages. As a result, EtherNet/IP uses UDP/IP to transport I/O messages that typically contain time-critical control data. The CIP™ Connection mechanism provides timeout mechanisms that can detect data delivery problems, a capability that is essential for reliable control system performance.

UDP port used is port 2222 (0x08AE).

TCP/IP/MAC Encapsulation (Explicit Messaging)

Ethernet Header (14 Bytes)	IP Header (20 Bytes)	TCP Header (20 Bytes)	Encapsulation Message(s)	C R C
-------------------------------	-------------------------	--------------------------	--------------------------	-------------

UDP/IP/MAC Encapsulation (Implicit Messaging)

Ethernet Header (14 Bytes)	IP Header (20 Bytes)	UDP Header (8 Bytes)	Encapsulation Message	C R C
-------------------------------	-------------------------	-------------------------	-----------------------	-------------

The process of opening a connection is called Connection Origination, and the node that initiates the connection establishment request is called a Connection Originator, or just an **Originator** (so called Scanner). Conversely, the node that responds to the establishment request is called a Connection Target, or a **Target** (so called Adapter).

6.2.2 Common Industrial Protocol (CIP™)

Common Industrial Protocol (CIP™) has implementations based upon Ethernet with EtherNet/IP, but also through DeviceNet (CIP™ over CAN bus) and ControlNet (CIP™ over a dedicated network).

Most controllers (with appropriate network connections) can transfer data from one network type to the other, leveraging existing installations, yet taking advantage of Ethernet.

CIP™ is an object oriented protocol. Each CIP™ **object** has **attributes** (data), **services** (commands) and **behaviors** (reactions to events). Objects are also named **classes**. An object **instance** refers to one implementation of a class. Each instance of a class has the same attributes, but its own particular set of attribute values.

We use attributes to refer to the data of an object. You use methods to operate on the data. Every attribute of an object will have a corresponding method and you invoke a method by sending a service to it. Services are the

communication mechanism between objects. CIP™ object models will use “**get**” and “**set**” messages as the methods to access their data.

The behavior of an object is what the object can do and this behavior is contained within its methods.

An integer ID value is assigned to each object **class**, each **instance** of the same class, each class **attribute** and each class **service**. There is only one assigned instance for **eNod4** application-specific classes.

CIP™ provides many standard services for control of network devices and access to their data via implicit and explicit messages. The key thing to remember about implicit messages is that there can be many consumers of a single network packet and this requires UDP, while TCP is instead reserved for point-to-point messages.

CIP™ also includes "device types" for which there are "device profiles". **eNod4** does not follow any device profile because functionality is specific. CIP™ already includes a large collection of commonly defined objects or object classes and only two objects referring to Ethernet, TCP/IP Interface Object & Ethernet Link Object.

Additional **eNod4**-specific objects (EtherNet/IP-compliant) have been defined in order to support the functional requirements of particular applications.

eNod4 EtherNet/IP devices supports the following ODVA commonly defined objects:

- An Identity Object (ID 0x01 class),
- A Connection Manager Object (ID 0x06 class),
- A TCP/IP Interface Object (ID 0xF5 class),
- An Ethernet Link Object (ID 0xF6 class),
- A DLR Object (ID 0x47 class),
- A Quality of Service Object (ID 0x48 class).


eNod4 application-specific objects are defined below:

- A Metrology and Identification Object (ID 0x64 class),
- A Calibration Object (ID 0x65 class),
- A Filtering Object (ID 0x66 class),
- A Logical Inputs/Outputs Object (ID 0x67 class),
- A Command / Response Object (ID 0x68 class).

Corresponding Class Attributes and Services supported are described in **Appendix**.

6.2.3 CIPTM Encapsulation Format

The CIP™ Encapsulation Message (the data portion of the TCP or UDP frame) includes a 24 byte header followed by its own data (optional) and is limited to a total length of 65535 bytes. This packet takes the following format:



For any data to exchange, the encapsulated data format is **most significant bit (MSB) transmitted first**.

Access to the object model of a device is controlled by one of two objects: the Connection Manager, and the UnConnected Message Manager (**UCMM**). We have already stated that EtherNet/IP is a connection-based network

and that most CIP™ messages are accomplished through connections. CIP™ also allows multiple connections to coexist in a device at any given time.

eNod4 allows up to 4 simultaneous EtherNet/IP connections (sum of explicit and implicit connections). In addition, it is not possible on the same module to access to different device application-specific Class for multiple explicit connections. For implicit connection, **eNod4** accepts 1 exclusive owner and up to 2 listener only. **eNod4** supports only cyclic connection CIP™ trigger.

6.3 Network configuration

Every **eNod4** is identified on the network by an IP address, a subnet mask and a default gateway address. Network configuration can only be set using **eNodView** software at minimum version V.

IP address: the IP address is comprised of two parts: the network address or Net ID (first part), and the host address or Host ID (last part). This last part refers to a specific machine on the given sub-network identified by the first part. The numbers of bytes of the total four that belong to the network address depend on the Class definition (Class A, B, or C) and this refers to the size of the network.

Class C subnets share the first 3 octets of an IP address, giving 254 possible IP addresses for **eNod4** device. Recall that the first 00_H and last FF_H IP addresses are always used as a network number and broadcast address respectively.

eNod4 default local IP* address is **192.168.0.100**

*if IP static configuration set

Subnet mask: a Subnet Mask is used to subdivide the host portion of the IP address into two or more subnets. The subnet mask will flag the bits of the IP address that belong to the network address, and the remaining bits correspond to the host portion of the address.

The unique subnet to which an **eNod4** IP address refers to is recovered by performing a bitwise AND operation between the IP address and the mask itself, with the result being the sub-network address.

eNod4 subnet mask default value is the default Class C subnet mask **255.255.255.0**

Gateway address: a gateway is being used to bridge Ethernet to other networks like a serial sub-network of Modbus RTU devices in order to provide communication compatibility.

The IP address of the default gateway has to be on the same subnet as the local IP address. The value 0.0.0.0 is forbidden. If no gateway is to be defined then this value is to be set to the local IP address of the **eNod4** device.

Default gateway address has been set to **192.168.0.254**

DHCP functionality (Dynamic Host Configuration Protocol):

It's a protocol that automates network-parameter assignment and allows an **eNod4** device to dynamically configure (without any particular action) an IP address and other information that is needed for network communication.

eNod4 device needs imperatively to be connected on the sub-network to a DHCP server that allocates IP address and also DHCP functionality has to be activated in **eNod4** device.

A label affixed on every **eNod4** contains 6 bytes of its MAC address (Media Access Control Address) which is a unique identifier assigned to network interfaces for communications on any physical network segment.

In DHCP when the Master of the sub-network attributes an IP address to a Slave(**eNod4** device), it associates its unique MAC address to the IP address. So the MAC address is the only way for a Master to identify an **eNod4** device on the sub-network.

DHCP functionality is not activated by default (set to **static IP configuration**).

6.4 EtherNet/IP LED

State of the **NS (Network Status)** bicolor LED is described in the table below:

Color	State	Meaning
Green	<i>Blinking</i>	NO CONNECTIONS: device has no connections established, but has obtained an IP address
	<i>Always on</i>	CONNECTED (at least one connection is established)
Red	<i>Blinking</i>	CONNECTION TIMEOUT: one or more of the connections in which this device is a target has timed out. This shall be left only if all timed out connections are reestablished or if the device is reset.
	<i>Always on</i>	DUPLICATE IP: the device has detected that its IP address is already in use
Red / Green	<i>Blinking</i>	Autotest at power on
-	<i>Always off</i>	Device not powered or defective

State of the **MS (Module Status)** bicolor LED is described in the table below:

Color	State	Meaning
Green	<i>Blinking</i>	STANDBY: the device has not been configured
	<i>Always on</i>	DEVICE OPERATIONAL: Device is operating correctly
Red	<i>Blinking</i>	MINOR FAULT: the device a detected a recoverable minor fault
	<i>Always on</i>	MAJOR FAULT: the device a detected a non-recoverable major fault
Red / Green	<i>Blinking</i>	Autotest at power on
-	<i>Always off</i>	Device not powered or defective

State of the **ACT / LINK** ETH1 and ETH2 network RJ45 connector LED:

Color	State	Meaning
LINK (Eth1 & Eth2) Green	<i>Always on</i>	A physical connection to the Ethernet exist
	<i>Always off</i>	Device not connected to the Ethernet
ACT (Eth1 & Eth2) Yellow	<i>On</i>	The device sends/receives Ethernet frames
	<i>Always off</i>	No traffic on the Ethernet

6.5 I/O scanning / implicit messaging

eNod4 Target (Adapter) depending version could consume up to two registers (4 bytes without header) of Output data (from the network's point of view) through Assembly Instance 0x64 (100) with a Cyclic transport trigger type and point to point connection type.

In **standard version**, data exchanged is the command register which is the attribute 1 of device application-specific 0x68 class.

In **IO+ version**, data exchanged are the command register and an External value to control analog output which is the attribute 16 of device application-specific 0x67 class.

eNod4 produces Input data (from the network's point of view) through Assembly Instance 0x65 (101) with a Cyclic transport trigger type. Multicast or point to point connection type, connection rate, size and priority are defined when the connection is established by the Originator (Scanner) through the connection manager Object using the *Forward_open* Service (Connection is closed using the *Forward_close* Service).

Find in the table below the specified registers (**84 bytes** without header) that are produced through Assembly Instance 0x65 (101):

<i>Register Modbus Address (Hex)</i>	<i>Offset in bytes (without header)</i>	<i>Type</i>	<i>Name</i>
/	0	long	eNod4 1ms counter*
0094	4	Uint	Input / Output levels
007D	6	Uint	Measurement status
007E	8	long	Gross measurement
0080	12	long	Tare value
0082	16	long	Net measurement
0084	20	long	Factory calibrated points
0090	24	Uint	Command register
0091	26	Uint	Response register
0086	28	Float	instant flow rate
0088	32	Float	average flow rate
009A	36	Float	Flow rate control output
008A	40	Uint	Control output value
00A1	42	Float	average belt speed
009F	46	Float	Integrated weight per length unit
00A4	50	Float	Totalization per belt revolution
008D	54	Ulong	Totalizer value (Great WU)
008F	58	Uint	Complementary totalizer value
00A9	60	Ulong	Grand total (Great WU)
00AB	64	Ulong	General total (Great WU)
008C	68	Uint	Belt alarms register
00A3	70	Uint	Belt status register
009E	72	Uint	Dosing errors counter
00A8	74	Uint	Batch progress percent
0095	76	Float	Dosing weight deviation
009C	80	Float	Dosing quality factor

*for possible check of the performances

6.5.1 Standard version (without IO+)

Find in the table below the specified register (**2 bytes without header**) that is consumed through Assembly Instance 0x64 (100):

Register Modbus Address (Hex)	Offset in bytes (without header)	Type	Name
0090	0	Uint	Command register

The register “Command register” uses the mechanism of **eNod4** functional commands defined in another chapter.

Note: “reset” and “Restore default settings” commands cannot be sent via cyclic and acyclic exchanges immediately after a restart of **eNod4**. To be able to use these commands, it must first be processed another command (“cancel Tare” for example).

Note: The “Command register” data **must be** set to 0x0000 before each new command.

6.5.2 IO+ version

Find in the table below the specified register (**4 bytes without header**) that is consumed through Assembly Instance 0x64 (100):

Functional commands register works in same way whatever IO+ version or not.

Register Modbus Address (Hex)	Offset in bytes (without header)	Type	Name
0090	0	Uint	Command register
0032	2	Uint	External value to control analog output

The register “External value to control analog output”

External device (e.g PLC) could drive **eNod4** analog output through this register. In **IO+ version** and when analog output is set to “level on request” function, **eNod4** will copy the value of this register to analog output *in current* or *in voltage*. Analog output value is expressed in **0.01%** of maximum current or voltage level.

7 PROFINET IO



When a configuration change occurs (change of Ethernet parameters, set default params via eNodView or eNodTouch, change of address «Name of the station » after a reset with option « Use rotary switch in name of the station») eNod4 Profinet absolutely must not be reset or power cycled within 10 seconds after send of the change or reset. This could permanently damage the eNod. MS LED blinks green cyclically when in this "damaged" state.

PROFINET is the communication standard created by the PROFIBUS International organization. It allows use of an industrial Ethernet network for real time data exchange between automation components. Whereas PROFINET CBA variant allows splitting intelligence of the application over network components, the PROFINET IO variant allows the exchange of I/O data between an IO-controller (e.g. PLC (Programmable Logic Controller)) that contains the intelligence of the application and IO-devices. **eNod4 ETH Profinet** is an IO-device and can exchange data only with one IO-controller.

7.1 Physical interface

eNod4 is fitted with two Ethernet ports on RJ45 connectors that are galvanically isolated. They support the switch or hub functions, specific functions of real time Ethernet systems and facilitate the implementation of line or ring topology.

The function of automatic crossing of emission line and reception line (Auto-Crossover Rx/Tx) on ETH1 and ETH2 interfaces is supported. Auto-negotiation of Ethernet link layer settings applies to the choice of the 10/100Mbit speed as well as Full or Half-Duplex operations.

As PROFINET IO communicates on Ethernet II type frames, **eNod4** is compatible with most of the existing network infrastructures (cards, connectors, network, hub and switches).

Each **eNod4** has a hardware **MAC** address (Media Access Control address). A label affixed to each **eNod4** includes the 6-bytes MAC address. It is a unique identifier of any Ethernet network hardware.


7.2 Network settings

All PROFINET IO network settings and options are configurable using the eNodView software to V version minimum.

IP settings: IP address, subnet mask and default gateway. Default values of these parameters are (192.168.0.100, 255.255.255.0, 192.168.0.254). Configuration of these settings via eNodView is of little interest. Usually it is the IO-Controller which assigns to each IO-Device its IP settings using the name of the station.

Name of the station: The name of the station is the primary key that allows the identification of the PROFINET IO node. So, it must be unique for each node on PROFINET IO subnet. It can only contain lowercase characters, figures, dashes and dots. The default value of this parameter is based upon (configurable option) the rotary switches located in front of **eNod4**. It is set to:


"enod4-t-0x'address_on_rotary_switches_in_lowercase_hexadecimal" for **eNod4-T**.



PROFINET IO network and names of **eNod4-T** stations in factory configuration. Only rotary switches have been reconfigured.

Byte order: The byte order defines the order in which the application data are emitted on the network. The two possibilities are "Big Endian" or "Little-Endian". With AA as least significant byte, data of 2 or 4 bytes length are coded for each possibility in this way: "Big Endian" 2 bytes: AA BB, 4 bytes: AA BB CC DD; "Little Endian" 2 bytes: BB AA, 4 bytes: DD CC BB AA. The default value of this parameter is "Little Endian".

7.3 Definition of protocols roles



PROFINET IO protocols stack inside **eNod4**.

Protocols involved in setting up an IO-Device (**eNod4**) and the establishment and maintenance of a cyclic data connection are described below:

- LLDP (Link Layer Discovery Protocol). The LLDP messages are sent regularly on the network and inform other nodes about the identity of **eNod4**.
- IP (Internet Protocol) allows routing of packets on the sub network by using IP address.
- ARP (Address Resolution Protocol). This protocol allows the creation of a resolution table of MAC addresses from an IP address. This table will be used in each node when a layer protocol based on IP (which uses an IP address) may wish to send a packet to another node on the Ethernet (MAC address) network.
- ICMP (Internet Control Message Protocol). Allows the 'Ping' command on the **eNod4**.

- UDP (User Datagram Protocol) allows specification of a port number for an IP packet. The port number is associated with a higher level protocol.
- SNMP V1 (Simple Network Management Protocol) allows the network administrator to manage and oversee the whole network, including **eNod4**.
- DCP (Discovery and Configuration Protocol). Enables the discovery and configuration of PROFINET nodes. The main functionality is similar to the more commonly used protocol DHCP (unsupported). Main available services are:
 - o Identify: Allows an application to identify all PROFINET nodes present on the network, including **eNod4**.
 - o Signal: Allows the user to flash an LED on a specified node to identify the corresponding hardware equipment.
 - o Set IP (remanent or not). Allows the assignment of IP parameters (IP address, subnet mask, default gateway) for a node. Remanent means that parameters will keep their values after a power cycle, in non-remanent that they will be recovered to their previous values.
 - o Set Name Of Station (remanent or not). Allows the allocation of the name of the station for a node. Used in remanent, this service disables the option “use rotary switches for name of the station”; to reactivate it you can use eNodView.
 - o Set Reset Factory Settings: Allows the reset of all settings (application and networks) from **eNod4** to their default values. It places the IP settings to (0.0.0.0, 0.0.0.0, 0.0.0.0), turns the current name of the station into an empty field and disables the option to use rotary switches for name of the station.
- RPC (Remote Procedure Call): Allows the management of connections (called **AR (Application relation)** and CR (Communication relation)) for the exchange of cyclic data (IO Data) between the IO-Controller (PLC) and the Device-IO (**eNod4**). Allows also acyclic exchanges (called read/write Records).
- Profinet IO Data: Cyclic PROFINET IO data, these carrying data also contain status informations on the transported data. Compared with other communication standards based on Ethernet, useful cyclic data goes through fewer layers before reaching their destination. For example the IP network layer is not crossed by cyclic data (IO Data).
- Alarms: PROFINET IO alarms are sent by a node whenever a significant event occurs. **eNod4** sends an alarm on every appearance and disappearance of diagnostic that reports an application error. Error types corresponding to **eNod4** diagnostics are described in the appendix and in the GSDML file. This file can be imported into the engineering software used for the network monitoring.
- MRP (Media Redundancy Protocol): This Protocol allows ring topology. **eNod4** acts as a **MRP client** and is not able to act as manager. At least one manager (MRP Manager) is required on the network if the ring topology is desired.

7.4 Main scenario

The main scenario applies to PROFINET IO network; it can be used to diagnose possibly encountered problems on the network.

1. *PROFINET IO network is powered on.*
2. *IO-Devices emit LLDP frames to inform all nodes on the subnet of their presence and identity.*
3. *Network nodes resolve the IP addresses of the stations with which they wish to communicate in peer-to-peer using the ARP protocol.*

4. With DCP services, IO-Controller identifies IO-Devices involved in its application. It configures their IP settings. ARP tables are updated consequently.
5. Using RPC, the IO-Controller opens and configures cyclic connections (AR) for data exchange with IO-Devices and if needed reads and writes application parameters.
6. Cyclic data exchanges begin between IO-Devices and the IO-Controller in both directions.
7. The application of IO-Controller operates with the data provided by IO-Devices and supplies data to IO-Devices to advance the process of the application.

7.5 Alternative scenario: control, maintenance, supervision

On point 4 of the main scenario:

- 4 A. If the network manager wants to control, maintain or supervise the network
 4. A.1. The network manager Ping the **eNod4**.
 4. A.2. The network manager consults the network information base of the **eNod4** with SNMP V1.

7.6 Alternative scenario: eNod4 error application detected

On point 7 of the main scenario:

- 7 A. **eNod4** detects an application error
 7. A.1. **eNod4** sends an alarm of appearance of diagnostic to the IO-Controller which opened and configured a data exchange connection with it.
 7. A.2. The network manager consults diagnostics, determines the cause of the problem and fixes it.
 7. A.3. **eNod4** sends an alarm of disappearance of diagnostic to the IO-Controller which opened and configured a data exchange connection with it.

7.7 PROFINET IO LEDs

State of the **BF (Bus Fault) labeled NS (Network Status)** bicolor LED is described in the table below:

<i>Color</i>	<i>State</i>	<i>Meaning</i>
Green	<i>Blinking</i>	<i>A data connection is established and the DCP Signal service was initiated via the bus.</i>
Red	<i>Blinking</i>	<i>No exchange of data.</i>
	<i>Always on</i>	<i>Ethernet physical connection low speed detected or no physical connection detected.</i>
Red/Green	<i>Blinking</i>	<i>Self-test on power up</i>
-	<i>Always off</i>	<i>No error</i>

State of the **SF (System Fault) labeled MS (Module Status)** bicolor LED is described in the table below:

<i>Color</i>	<i>State</i>	<i>Meaning</i>
Green	<i>Blinking</i>	STANDBY: the device has not been configured
	<i>Always on</i>	DEVICE OPERATIONAL: Device is operating correctly
Red	<i>Blinking</i>	MINOR FAULT: the device detected a recoverable minor fault
	<i>Always on</i>	MAJOR FAULT: the device detected a non-recoverable major fault
Red/Green	<i>Blinking</i>	Self-test on power up
-	<i>Always off</i>	Device not powered or defective

State of the **ACT / LINK** ETH1 and ETH2 network RJ45 connector LED:

<i>Color</i>	<i>State</i>	<i>Meaning</i>
LINK (Eth1 & Eth2) Green	<i>Always on</i>	A physical connection to the Ethernet exist
	<i>Always off</i>	Device not connected to the Ethernet
ACT (Eth1 & Eth2) Yellow	<i>On</i>	The device sends/receives Ethernet frames
	<i>Always off</i>	No traffic on the Ethernet

7.8 Data arrangement

The provision model of data is very similar to the one used in PROFIBUS DP, this will allow users of **eNod4 Profibus** an easy recycling of their application.

7.8.1 Cyclic data (IO Data)

Cyclic exchanged data are either provided by the IO-Device and consumed by the IO-Controller or provided by the IO-Controller and consumed by the IO-Device.

Data are contained in input or input/output modules (from the point of view of the IO-Controller). These modules are defined in the GSDML file and are presented in a separate chapter.

The designer can select modules that he needs and place them in communication slots. Thus, the slots contain modules. Slots are numbered. Slot 0 is not usable for data exchange, it contains DAP (Device Access Point) informations which defines, among other, which data module can be contained in which slots.

7.8.2 Acyclic data (Records)

Acyclic data are available in read-only or read/write access. They are accessed by using a slot, a sub slot and an **index**. **eNod4** acyclic data are accessible with any slot and sub slot. Indexes for the **eNod4** specific application data are presented in appendix.

7.9 PROFINET IO exchange of cyclic data

Acyclic data modules are described in GSDML file. This file can be imported into the engineering tool used for application design. Data modules can be freely plugged into any slot from 1 to 11. This will define the organization of cyclic data in the AR (Application Relation). Unnecessary modules for the application may not be plugged. Inserting data provided by **eNod4** automatically implies the insertion of data consumed by **eNod4** if the concerned module contains consumed data.

Presentation of provided data in modules:

<i>Module ID</i>	<i>Module name</i>	<i>Provided size in bytes</i>	<i>Provided Data</i>
1	Status+Gross Measurement	6	Measurement status (2 bytes)
			Gross measurement (4 bytes)
2	I/OLevel+Net+Fact.	10	Logical I/O level (2 bytes)
			Net Measurement (4 bytes)
			Factory calibrated Meas. (4 bytes)
3	Flow rates/Speed	12	Instant flow rate (4 bytes)
			Average flow rate (4 bytes)
			Average speed (4 bytes)
4	Output control	6	Flow rate control output (4 bytes)
			Control output value (2 bytes)
5	Totalization	10	Totalization per belt revolution (4 bytes)
			Totalizer value (Great WU) (4 bytes)
			Complementary totalizer value (2 bytes)
6	Command/Response Reg	2	Response register
7	R/W request Reg.	6	Transaction status (2 bytes)
			Data read/written (4 bytes)
8	Status/Errors	12	Belt alarms register (2 bytes)
			Belt status register (2 bytes)
			Errors counter (2 bytes)
			Batch progression % (2 bytes)
			Dosing weight deviation (4 bytes)
9	Other totals	8	Grand total (Great WU) (4 bytes)
			General total (Great WU) (4 bytes)
10	Ana. Output	2	External value to control analog output (2 bytes)
11	1 ms counter	4	eNod4 1ms counter *

**for possible check of performances*

Presentation of consumed data in input/output modules:

<i>Module ID</i>	<i>Module name</i>	<i>Consumed size in bytes</i>	<i>Consumed Data</i>
6	Command/Response Reg	2	Command register
7	R/W request Reg.	6	Transaction request (2 bytes)
			Data to be written (4 bytes)
10	Ana. Output	2	External value to control analog output (2 bytes)

The module “Command/Response Reg” uses the mechanism of **eNod4** functional commands defined in another chapter. The only difference is for “reset” and “Restore default settings” commands which cannot be sent via cyclic exchanges immediately after a restart of **eNod4**. To be able to use these commands, it must first be processed another command (“cancel Tare” for example).

Note: The “Command register” data **must be** set to 0x0000 before each new command.

The module “R/W request Reg.” allows requesting read/write of Record (acyclic data). So this **substitute** read/write of Record via the RPC protocol. The protocol described below (which is the same than the one used on **eNod4** Profibus product) allows performing read/write operations:

<i>IN</i>	<i>OUT</i>
Transaction status (2 bytes)	Transaction request (2 bytes)
Data read/written (4 bytes)	Data to be written (4 bytes)

An IO-Controller can transmit a read or write request to **eNod4** by writing a specific code (see the codes listed in the appendix) into the transaction request register.

- ⇒ For a write request, the 4 following OUT bytes can be used so as to enter the new value.
- ⇒ **eNod4** IN are then updated :
 - Transaction status is set to 0xFFFF in case of an error otherwise it takes the same value as the one entered in the transaction request word.
 - For a read transaction, the value of the requested setting is set into the four IN following bytes.
 - For a write transaction the value of the data to be written is copied into the four IN following bytes.

Note: For 2-bytes size data, the data is read/written through the 2 least significant bytes. Ignore the 2 most significant bytes.

Note: The "Transaction request" register **must be** set to 0x0000 before every new transaction.

The module “Ana. Output” allows external device to drive eNod4 analog output *current* or *voltage*. To achieve that, analog output must be configured to “level on request” function.

8 ETHERCAT



EtherCAT® is registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

EtherCAT is the communication standard created by the EtherCAT Technology Group (ETG). It allows use of an industrial Ethernet network for the exchange of I/O data between a Master (e.g. PLC (Programmable Logic Controller)) that contains the intelligence of the application and Slaves. **eNod4 ETH EtherCAT** is an EtherCAT Slave.

8.1 Physical interface

eNod4 is fitted with two Ethernet ports on RJ45 connectors that are galvanically isolated. They support the switch or hub functions, specific functions of real time Ethernet systems and facilitate the implementation of line or ring topology (any topology type is possible for EtherCAT networks).

The speed is fixed at 100Mbit and operations at Full-Duplex (EtherCAT requirements).

The "In" port is the one in the center and the "Out" port is the one located at the edge (rear).

As EtherCAT communicates on Ethernet II type frames, **eNod4** is compatible with most of the existing network infrastructures (cards, connectors, network, hub and switches).

8.2 Network settings

The **eNod4** configuration tool, eNodView, is not necessary for the EtherCAT network setup. Nevertheless the identification of **eNod4 ETH EtherCAT** by eNodView is only supported from X version.

Device Identification Value: value of 2 Bytes length that is set locally on the device and allows an Explicit Device Identification of Slaves on EtherCAT network by the Master. This value can be set via rotary switches (ID-Selector) located in front of **eNod4**, the most significant byte is set to zero and the least significant byte is set according to value on rotary switches. This value must be different of zero and a reset must be done after each change to take effect.

8.3 Communication protocol

Data can be exchanged cyclically or acyclically. For acyclic data exchanges **eNod4** make use of a « mailbox » exchange protocol, CoE (CANopen application protocol over EtherCAT), which provides mechanisms to configure cyclic data exchange and parameters access (SDOs). Cyclical data are transmitted within Process Data Objects (PDOs). The data arrangement is described in a following chapter.

8.4 EtherCAT LEDs

State of the (RUN LED: green, ERR LED: red) labeled NS (Network Status) bicolor LED is described in the table below:

Color	State	Meaning
RUN LED Green	Off	INIT: The device is in state INIT.
	Blinking	PRE-OPERATIONAL: The device is in PRE-OPERATIONAL state.
	Single flash	SAFE-OPERATIONAL: The device is in SAFE-OPERATIONAL state.
	Always on	OPERATIONAL: The device is in OPERATIONAL state.
ERR LED Red	Blinking	Invalid Configuration: General Configuration Error. Possible reason: State change commanded by master is impossible due to register or object settings.
	Single flash	Local Error: Slave device application has changed the EtherCAT state autonomously. Possible reason 1: A host watchdog timeout has occurred. Possible reason 2: Synchronization Error, device enters Safe-Operational automatically.
	Double flash	Process Data Watchdog Timeout: A process data watchdog timeout has occurred. Possible reason: Sync Manager Watchdog timeout.
Red/Green/Off	Combinations of red and green: blinking, single and double flash	The status of the red and the green LED can be displayed combined. If for example the Ethernet cable is disconnected, then the following combination is displayed: Green single flash (SAFE-OPERATIONAL) and red double flash (Process Data Watchdog Timeout).

State of the SF (System Fault) labeled MS (Module Status) bicolor LED is described in the table below:

Color	State	Meaning
Green	Blinking	STANDBY: the device has not been configured
	Always on	DEVICE OPERATIONAL: Device is operating correctly
Red	Blinking	MINOR FAULT: the device detected a recoverable minor fault
	Always on	MAJOR FAULT: the device detected a non-recoverable major fault
Red/Green	Blinking	Self-test on power up
-	Always off	Device not powered or defective

State of the **ACT / LINK** ETH1 and ETH2 network RJ45 connector LED:

<i>Color</i>	<i>State</i>	<i>Meaning</i>
LINK (Eth1 & Eth2) Green	Always on	A link is established
	Flashing	The device sends/receives Ethernet frames
	Always off	No link established
ACT (Eth1 & Eth2) Yellow	This LED is not used.	

8.5 Data arrangement

The provision model of data is very similar to the one used in standard **eNod4 CANopen (eNod4 DIN)**.

8.5.1 Acyclic data (Objects)

Acyclic data are available in read-only or read/write access. Each data is an object or a sub-object included in an object. It is accessed using an index and a sub-index if it is a sub-object. Objects are stored in the **eNod4** object dictionary. The index/sub-index for **eNod4** application specific data are presented in the following chapters, they are similar to those used in **standard CANopen eNod4 (eNod4 DIN)**.

All objects of the object dictionary are described in the EtherCAT Slave Information File (ESI), an XML file that can be used by an EtherCAT network configuration tool.

8.5.2 Cyclic data (IO Data)

Data exchanged cyclically are either provided by the EtherCAT Slave and consumed by the Master (TxPDOs, Inputs) or provided by the Master and consumed by the EtherCAT Slave (RxPDOs, Outputs).

The data within PDOs are object dictionary objects (same as for acyclic exchanges). PDOs and their included objects are defined in the ESI file and are described in another chapter.

8.6 EtherCAT exchange of cyclic data

PDOs are described in ESI file. This file can be imported into the application design software. The designer can choose PDOs he needs and assign or disable de-assign them. In **eNod4** PDOs are of fixed size and cannot be remapped (change objects constituting them).

There may be no RxPDO data (Outputs, data consumed by **eNod4**) assigned for the cyclic exchange providing that there is at least one TxPDOs (Inputs, data produced by the **eNod4**) assigned. Similarly there may be no assigned TxPDOs for cyclic data exchange providing that there is at least one assigned RxPDO.

Every PDOs are not default assigned in the ESI file (see tables below).

It is recommended to de-assign RxPDOs if there are not used in application to avoid writing of inappropriate values in calibration parameters of **eNod4**.

Presentation of data provided in the TxPDOs (Inputs, data produced by the eNod4):

<i>Name</i>	<i>Size (bytes)</i>	<i>Data</i>	<i>Default assigned</i>
TPDO1	1	<i>Response register</i>	yes
TPDO2	6	<i>Gross measurement (4 bytes)</i>	yes
		<i>Measurement status (2 bytes)</i>	
TPDO3	6	<i>Net measurement (4 bytes)</i>	yes
		<i>Logical Inputs level (1 byte)</i>	
		<i>Logical Outputs level (1 byte)</i>	
		<i>Instant flow rate (4 bytes)</i>	
TPDO4	36	<i>Average flow rate (4 bytes)</i>	yes
		<i>Flow rate control output (4 bytes)</i>	
		<i>Control output value (2 bytes)</i>	
		<i>Total per belt revolution (4 bytes)</i>	
		<i>Totalizer value (Great WU) (4 bytes)</i>	
		<i>Complementary totalizer value (2 bytes)</i>	
		<i>Average flow rate (Great WU) (4 bytes)</i>	
		<i>Grand total (Great WU) (4 bytes)</i>	
		<i>General total (Great WU) (4 bytes)</i>	
		TPDO5	
<i>Alarms registers (2 bytes)</i>			
<i>Errors counter (2 bytes)</i>			
<i>Batch progression in percent (2 bytes)</i>			
<i>Dosing weight deviation (4 bytes)</i>			
<i>Weigh frame load (4 bytes)</i>			
<i>Average belt speed (4 bytes)</i>			
<i>Dosing quality factor (4 bytes)</i>			
TPDO6	4	eNod4 1ms counter*	yes

**for possible check of performances*

Presentation of data consumed in RxPDO modules (Outputs, data consumed by eNod4):

<i>Name</i>	<i>Size (bytes)</i>	<i>Data</i>	<i>Default assigned</i>
RPDO1	1	Command register	yes
RPDO2	4	Calibration load 1	no
RPDO3	8	Zero offset (4 bytes)	no
		Span adjusting coefficient (4 bytes)	
RPDO4	8	Maximum capacity (4 bytes)	no
		Sensor sensitivity (4 bytes)	
RPDO5	2	External value to control analog output	no

The Command register uses the mechanism of **eNod4** functional commands defined in another chapter. The only difference is for “reset” and “Restore default settings” commands which cannot be sent via cyclic exchanges immediately after a restart of **eNod4**. To be able to use these commands, it must first be processed another command (“cancel Tare” for example).

Note: The “Command register” data **must be** set to 0x00 before each new command.

The « External value to control analog output» allows writing directly the analog output value. This is only possible when the analog output function assignment is set to « Level on request ».

9 MEASUREMENT AND STATUS

Name	Modbus address	EtherNet/IP Class/Attribute (hex/dec)	Profinet Record Index	Profinet cyclic Req Code	EtherCAT index/sub-index	Type	Access
Measurement status	0x007D	/	0x009C	R:0x02C8 W: / + See modules list	0x5003 / 0x00 (M)	Uint	RO
Gross measurement	0x007E	/	0x009D	R:0x04CA W: / + See modules list	0x5001 / 0x00 (M)	Long	RO
Tare value	0x0080	/	0x0060	R:0x0470 W: /	0x5004 / 0x01	Long	RO
Net measurement	0x0082	/	0x009E	R:0x04CC W: / + See modules list	0x5000 / 0x00 (M)	Long	RO
Factory calibrated points	0x0084	/	0x009F	R:0x04CE W: / + See modules list	0x5002 / 0x00	Long	RO
Preset Tare	0x009C	0x65/16	0x0061	R:0x04C4 W:0x04C5	0x5004 / 0x02	Ulong	RW
Defective measurement debounced time	0x0A48	0x67/17	0x005D	R:0x0206 W:0x0207	0x4509 / 0x06	Uint	RW
Defective measurement alarm activation time	0x0A49	0x67/18	0x005E	R:0x0208 W:0x0209	0x4509 / 0x07	Uint	RW
Sensor input control reference	0x0A44	0x65/17	0x0062	R: 0x044C W: 0x044D	0x5004 / 0x03	long	RW
Sensor input control result	0x0A46	0x68/4	0x0063	R: 0x024E W: /	0x5004 / 0x04	Int	RO
Sensor input control result max. tolerance	0x0A47	0x65/18	0x0064	R: 0x020A W: 0x020B	0x5004 / 0x05	Uint	RW

9.1 Measurement transmission

The **eNod4** transmits measurement after signal and data processing through different protocols available. The accessible variables are:

9.1.1 Gross measurement

The 'gross measurement' stands for the digital value after measurement scaling. It is affected by all the 'zero' functions (power-up zero, zero tracking and zero requests).

9.1.2 Net measurement

The 'net measurement' stands for the digital value after measurement scaling and tare subtraction.

9.1.3 Tare value

The 'tare value' stores the calibrated value that is subtracted from the 'gross measurement' so as to give the 'net measurement'.

9.1.4 Factory calibrated points

The 'factory calibrated points' contains the measurement value without the user calibration layer. It is directly linked to the analog input voltage.

9.1.5 Preset Tare value

A previous calculated tare can be restored using this variable.

9.1.6 Measurement status

The measurement status contains information on eNod4 measurement parameters.

The 'measurement status' bytes contain information about every measurement processed by **eNod4**. See the flags meaning in the table below:

bits	Meaning	Note
b₁ b₀		
00	gross measurement	
01	net measurement	only in SCMBus/fast communication protocols
10	factory calibrated measurement	not significant otherwise (00)
11	tare value	
b₃ b₂		
00	measurement OK	
01	Defect: sensor input control result out of tolerances OR Sensor input control command in progress OR failed (timeout) OR Sensor input reference command in progress	causes a logical output assigned to the 'defective measurement' function to be set active. Causes the analog output assigned to a weight or flow rate image to be set in error mode.
10	gross meas. < (- max capacity) OR gross meas. > (max capacity)	
11	analog signal out of the A/D converter input range	
b₄		
0	motion	causes an output assigned to the 'motion' function to be set active
1	no motion	
b₅		
0	measurement out of the ¼ of division	
1	zero in the ¼ of division	

<i>bits</i>	<i>Meaning</i>	<i>Note</i>
<i>b₆</i>		
<i>0</i>	<i>EEPROM OK</i>	<i>See Note 1</i>
<i>1</i>	<i>EEPROM failure</i>	
<i>b₇</i>		
<i>0</i>	<i>reserved</i>	<i>1 in SCMBus and fast SCMBus, 0 otherwise</i>
<i>1</i>		
<i>b₈</i>		
<i>0</i>	<i>IN1 logical level</i>	
<i>1</i>		
<i>b₉</i>		
<i>0</i>	<i>IN2 logical level</i>	
<i>1</i>		
<i>b₁₀</i>		
<i>0</i>	<i>OUT1 logical level</i>	
<i>1</i>		
<i>b₁₁</i>		
<i>0</i>	<i>OUT2 logical level</i>	
<i>1</i>		
<i>b₁₂</i>		
<i>0</i>	<i>OUT3 logical level</i>	
<i>1</i>		
<i>b₁₃</i>		
<i>0</i>	<i>OUT4 logical level</i>	
<i>1</i>		
<i>b₁₄</i>		
<i>0</i>	<i>no tare</i>	
<i>1</i>	<i>at least a tare has been processed</i>	
<i>b₁₅</i>		
<i>0</i>	<i>reserved</i>	<i>1 in SCMBus and fast SCMBus, 0 otherwise</i>
<i>1</i>		

Note 1: Functioning and calibration parameters are stored in EEPROM. After every reset the entireness of parameters stored in EEPROM is checked. If a defect appears, measurements are set to 0xFFFF and defect is pointed out in measurement status. Causes a logical output assigned to the 'defective measurement' function to be set active. Causes the analog output assigned to a weight or flow rate image to be set in error mode.

[9.2 Weighing diagnosis](#)

[9.2.1 Global weighing diagnosis](#)

An internal alarm flag reflects the integrity of the whole measurement chain. It's used to set logical output active or optional analog output in an error mode in order to warn about any deflection on the measurement chain (defective measurement).

This variable is set active when at least one of the followings conditions occurs:

- all that set bit2 or bit3 of **Measurement status**:
 - sensor input control result out of tolerances
 - sensor input control command in progress
 - sensor input control command failed (timeout)
 - sensor input reference command in progress
 - gross meas. < (- max capacity)
 - gross meas. > (max capacity)
 - analog signal out of the A/D converter input range
- the one that set bit6 of **Measurement status**: EEPROM failure

This internal alarm flag is featured with adjustable specific de-bounced time and minimal activation time:

9.2.1.1 Defective measurement debounced time

The internal alarm flag is set active only after error conditions have always been true during this de-bounced time. It's expressed in ms.

9.2.1.2 Defective measurement alarm activation time

The internal alarm flag remains active for this minimal "*defective measurement alarm activation time*" when it come to be active and whatever the error conditions are during activation. It is expressed in ms.

9.2.2 Sensor input control

eNod4 features a weighing diagnosis system allowing to check the integrity of analog sensor input by electrically simulating a load, resulting to a simulated weight value. This diagnostic system can be used together with the others defects detection systems in order to achieve overall integrity check of the measurement chain. This system involves two phases initiated by the user:

- The first, just after user calibration, allows taking a simulated reference weight value when the measuring chain integrity is OK.
- The second, when the user wants to check the integrity of the system, allows to make the difference between a new simulated weight value and the reference. Then this difference can be compared with a dedicated maximum tolerance value.

9.2.2.1 Sensor input control reference

Reference value expressed in factory calibrated points for the sensor(s) input control test. The value is automatically determined and stored after executing the **sensor input reference** command. When the **sensor input reference** command is in progress the bits b3b2 in the **Measurement status** are set to 0b01. Its default value is zero.

9.2.2.2 Sensor input control result

Result of sensor(s) input control test expressed in 1/10 of user weight unit. Its value is automatically determined and stored after executing the **sensor input control** command. This test result represents the weight difference between the reference value and the current test value. It is set to **-1** when the **sensor input control** command is in progress or the command failed, these conditions cause the bits b3b2 in the **Measurement status** to be set to 0b01. Its default value is zero.

9.2.2.3 Sensor input control result max. tolerance

The **Sensor input control result** variable is compared with the **Sensor input control result max. tolerance** parameter which is expressed in 1/10 of user weight unit and has a default value of 30. If the **sensor input control result** value is greater than or equal to **Sensor input control result max. tolerance** then the bits b3b2 in the **Measurement status** are set to 0b01.

10 PROCESSING FUNCTIONAL COMMANDS

Name	Modbus address	EtherNet/IP Class/ Attribute (hex/dec)	Profinet Record Index	Profinet cyclic Req Code	EtherCAT index/sub-index	Type	Access
Command register	0x0090	0x68/1	/	See modules list	0x2003 / 0x00 (M)	Uint	RW
Response register	0x0091	0x68/2	/	See modules list	0x2004 / 0x00 (M)	Uint	RO

10.1 Principles

eNod4 device is able to handle several functional commands thanks to a couple of registers (except in SCMBus protocols):

the command register : dedicated to accept the functional commands

the response register : gives the state of the command currently being processed by **eNod4** (no command, in progress, finished, failed)

- **00_H** ⇒ free to accept a new command
- **01_H** ⇒ command execution in progress
- **02_H** ⇒ command execution complete
- **03_H** ⇒ error during command execution

Note 1: IMPORTANT except in SCMBus/fast SCMBus protocols, to accept a new command, the command register must be set to **00_H** first. This causes the response register to be set back to **00_H**.

10.2 Functional commands list

Functional command	Command code	Note
Set to idle (00 _H) response register	00 _H	See § above note 1
reset*	D0 _H	
EEPROM storage	D1 _H	
Restore default settings	D2 _H	
Zero*	D3 _H	
Tare*	D4 _H	
Cancel tare*	D5 _H	
Cancel current command	D6 _H	
Theoretical scaling	D7 _H	
Zero adjustment	D8 _H	
Start physical calibration	D9 _H	Physical calibration procedure
Calibration zero acquisition	DA _H	
Segment 1 acquisition	DB _H	
Segment 2 acquisition	DC _H	
Segment 3 acquisition	DD _H	
Store calibration	DE _H	end of calibration (physical/theoretical) procedure
OUT1 activation/deactivation*	E6 _H	only possible if the outputs are assigned to the associated function
OUT2 activation/deactivation*	E7 _H	
OUT3 activation/deactivation*	E8 _H	
OUT4 activation/deactivation*	E9 _H	
zero offset adjustment	F0 _H	
Dynamic zero	F1 _H	
Preset tare*	F2 _H	
Init speed sensor calibration	F3 _H	
End speed sensor calibration	F4 _H	
Init belt length calibration	F5 _H	
End belt length calibration	F6 _H	
Calibration of flow rate	F8 _H	
Flow rate correction	F7 _H	
PID parameters auto-adjustment	F9 _H	
STOP PID	C9 _H	
RESTART PID	CA _H	

Functional command	Command code	Note
<i>Sensor input reference</i>	<i>EF_H</i>	
<i>Sensor input control</i>	<i>FD_H</i>	
<i>Dosing / batch start/resume</i>	<i>E4_H</i>	
<i>Dosing / batch stop</i>	<i>E5_H</i>	
<i>Clear totalization and error counter</i>	<i>DF_H</i>	
<i>Clear great total</i>	<i>ED_H</i>	
<i>Clear general total</i>	<i>EE_H</i>	

Note: Only the commands with a * can be handled by **eNod4** in SCMBus and fast SCMBus protocols.

10.3 Functional commands description

10.3.1 Reset

The 'reset' functional command execution is similar to the device power-up. This reboot phase is necessary if the address or/and the baud rate are modified and some settings changes are only taken into account after an EEPROM storage followed by a reset.

10.3.2 EEPROM storage

eNod4 configuration and calibration are stored in a non-volatile memory (EEPROM). If changes are made in the device configuration, sending to **eNod4** the 'EEPROM storage' functional command will allow **eNod4** to keep these modifications after a power shutdown or the reception a 'reset' functional command.

Moreover the settings listed below need to be stored and will only be taken into account at the next device reboot:

- span adjusting coefficient
- calibration place **g** value
- place of use **g** value
- stability criterion
- legal for trade activation switch
- power-up zero
- A/D conversion rate
- Functioning mode and communication protocol

10.3.3 Restore default settings

The 'restore default settings' command causes **eNod4** to be set back to its default configuration. The default configuration corresponds to the one on delivery that means with factory settings. Be careful when using this command, all the default settings are recovered including the stored calibration and the legal for trade indicators.

Note: this functional command is not available in CANopen® communication protocol.

10.3.4 Zero

When receiving a 'zero' functional command, **eNod4** acquires a volatile zero (gross measurement is set to 0) value if the following conditions are respected:

- measurement is stable
- Current gross measurement is within a ±10% (±2% if the legal for trade option is enabled) range of the 'maximum capacity'.

Otherwise, after five seconds the command is cancelled and an execution error is reported.

10.3.5 Tare

When receiving a *'tare'* functional command, **eNod4** acquires a volatile tare (net measurement is set to 0) value if the measurement is stable otherwise, after five seconds the command is cancelled and an execution error is reported. If the tare acquisition is successful b₁₄ bit of the *'measurement status'* is set to 1.

10.3.6 Cancel tare

This command erases the current tare value if at least one tare has been previously processed. It also causes b₁₄ bit of the *'measurement status'* to be set back to 0.

10.3.7 Cancel last command

This command sets the response register to **00H** and allows **eNod4** to ignore the functional command previously received (for example to exit a sequential procedure like a physical calibration).

10.3.8 Theoretical scaling

The *'theoretical scaling'* functional command involves the *'maximum capacity'* and the *'sensor sensitivity'* settings. When used, this command realizes an automatic scaling to migrate from the factory calibration to the user calibration (see §8). This calibration must then be saved by sending to **eNod4** the *'store calibration'* functional command. Using the *'zero adjustment'* functional command is also recommended so as to completely adapt **eNod4** to the application.

10.3.9 Zero adjustment

The *'zero adjustment'* functional command allows the user to set his calibration zero value by asking **eNod4** to acquire the current factory calibrated measurement. This acquisition duration depends on the measurement stability; if stability is not reach after 10 seconds, *'zero adjustment'* command is cancelled and an execution error is reported. If it is correctly achieved, this calibration zero modification must then be saved by sending to **eNod4** the *'store calibration'* functional command. This functional command can be used any time and has no effect on the user-span that can have been previously configured through a physical or a theoretical calibration procedure.

10.3.10 Start physical calibration

In order to handle a physical calibration with 1 up to 3 know references, **eNod4** first must be told to enter the physical calibration mode. It is the first step of a sequential procedure.

10.3.11 Calibration zero acquisition

The *'calibration zero acquisition'* is the second step of the physical calibration procedure. It can only be used if the *'start physical calibration'* functional command has been previously received. This acquisition duration depends on the measurement stability; if stability is not reach after 10 seconds, *'calibration zero acquisition'* command is cancelled and an execution error is reported.

Note: In specific cases (silo for example), this step is not mandatory because it is possible to command a "zero adjustment" when the silo is empty.

10.3.12 Segment 1 acquisition

It consists in applying a known reference on the sensor then sending the *'segment 1 acquisition'* functional command. This acquisition duration depends on the measurement stability; if stability is not reach after 10 seconds, *'actual segment acquisition'* command is cancelled and an execution error is reported.

10.3.13 Segment 2/3 acquisition

Only if the *'calibration zero acquisition'* and *"Segment 1 acquisition"* are successful, next step consists in applying a known reference on the sensor then sending the *'segment X acquisition'* functional command where X depends on the value stored in the *'number of calibration segments'* register. This acquisition duration depends on the measurement stability; if stability is not reach after 10 seconds, *'actual segment acquisition'* command is cancelled and an execution error is reported.

10.3.14 Store calibration

Only if the *'segment 1/2/3 acquisition'* is successful, next step consists in validating the new calibration by storing the zero and the span that have been determined in EEPROM.

Note: This functional command has to be transmitted at the end of a physical calibration, after a *'zero adjustment'*, a *'theoretical scaling'* or a *'zero offset'*.

10.3.15 Logical outputs 1-4 activation/deactivation

If the corresponding logical outputs are assigned to the *'level on request'* function, they can be enabled/disabled by transmitting one of these functional commands. Upon first reception, the corresponding output is enabled and on next reception it will be disabled. If the requesting logical output is assigned to the wrong function, **eNod4** reports an error.

10.3.16 Zero offset

It is also possible to adjust the calibration zero value without acquiring a new one. By entering a positive or negative value into the *'delta zero'* register, the user can quantify the offset (in factory calibrated points) that has to be added or subtracted from the actual calibration zero. This calibration zero modification must then be saved by sending to **eNod4** the *'store calibration'* functional command.

10.3.17 Dynamic zero

In belt mode and when the system is running, after receiving a *"dynamic zero"* command **eNod4** calculates the average of integrated weight per length during the belt revolution time. A new zero is then used if it is within a *"dynamic zero band"* parameter range. For more accurate result, dynamic zero can be done within several belt revolutions specify by *"number of revolutions"* parameter.

- **Note 1:** Stability is not necessary
- **Note 2:** Dynamic zero acquisition can also be launch by an input assigned to this function.
- **Note 3:** Dynamic zero procedure can be interrupt by sending *"cancel current command"*.

10.3.18 Preset tare

With this command it is possible to retrieve a tare value defined previously.

Important: Preset tare value must be stored in corresponding parameter before to send this command.

10.3.19 Sensor input reference

Sensor input reference command will cause **eNod4** to handle special sequence to acquire **sensor input control reference** value of the load cell sensor input. This command must not be realized when any process cycle that use weight is in progress (because weight variables do not reflect the real weight whilst command is in progress). This command can fail (error in response register) in case of stability timeout on sensor input. The execution time of this command depends on the weight filtering settings. For any further information about this functionality and result variables see *"Weighing diagnosis"* § in the MEASUREMENT AND STATUS §.

10.3.20 Sensor input control

Sensor input control command will cause **eNod4** to handle special test on sensor input and to deliver a test result. This command must not be realized when any process cycle that use weight is in progress (because weight variables do not reflect the real weight whilst command is in progress). This command can fail (error in response register) in case of stability timeout on sensor input. The execution time of this command depends on the weight filtering settings. For any further information about this functionality and result variables see *"Weighing diagnosis"* § in the MEASUREMENT AND STATUS §.

10.3.21 Init speed sensor calibration

When the system is running empty, this command will cause **eNod4** to initiate belt speed calibration sequence.

An internal speed sensor pulses counter is restarting and the calibration procedure duration will depend of the current belt speed, the *"total belt length"* and the *"number of revolutions"* to handle.

Important: Before initiated speed calibration procedure, use has to configure the following parameters:

- *total belt length*
- *number of revolutions*

10.3.22 End speed sensor calibration

When the configured number of revolution is realized, this command will cause **eNod4** to achieve and to exit speed calibration sequence. The new "**Pulses factor for speed**" is calculated and the speed given by **eNod4** will match the real belt speed. Also, **eNod4** will know how long for the belt revolution.

10.3.23 Init belt length calibration

When the system is running empty, this command will cause **eNod4** to initiate belt length calibration sequence.

An internal timer is restarting and the calibration procedure duration will depend of the current belt speed, the belt length and the *number of revolutions* to handle.

Important: Before initiated belt length calibration procedure, user has to configure the following parameters:

- *Pulses factor for speed (could be found in speed sensor user manual or determinate by eNod4)*
- *number of revolutions*

10.3.24 End belt length calibration

When the configured number of revolution is realized, this command will cause **eNod4** to achieve and to exit belt length calibration sequence. The new "**total belt length**" is calculated and **eNod4** will know how long for the belt revolution.

10.3.25 Flow rate correction

Correction factor can be used to correct deviations in the total dosed amount by compensating for mechanical variations. At receiving a "*flow rate correction*" command **eNod4** recalculate a correction factor by calculating:

$$\text{New Correction} = \text{Checked Batch Total} * \text{Correction} / \text{Last batch total.}$$

The next batch the Batch Total and Checked Batch Total should be closer together.

Important: Before initiated this command, user has to configure the "*Checked Batch*" parameter.

10.3.26 Start (batch/system)

In *batch mode* this command launches or resumes a cycle. A cycle can also be launch by an input assigned to this function. If the start is given by the *command register*, **eNod4** responds through the *response register*, the state of the control cycle start. If the cycle has been started, then the bits of "*belt status word*" will be positioned (see § belt status word).

In *weigh feeder mode* and if **eNod4** analog output is assigned to "*flow rate control output*" and drives the "*conveyor speed*", this command will start the belt system at "*nominal speed*" configured. In that case, for security reason a logical output can be assigned to "*buzzer*" function and the duration is configured through "*conveyor starting alarm duration*" parameter.

10.3.27 Stop (batch/system)

In *batch mode* this command allows stopping the batch cycle. It is also possible to order a 'stopping of cycle' with an input set to this function. At receiving of this command, the scale material flow stops automatically.

In *weigh feeder mode* and if **eNod4** analog output is assigned to "*flow rate control output*" and drives the "*conveyor speed*", this command will also stop the belt system.

10.3.28 Clear totalization & errors counter

This command triggers the main totalizer reset. The two parts of the totalizer, the main in **weight unit** x 1000, and the complementary part in **weight unit** are then reset.

The variable **errors counter** is also reset.

10.3.29 Calibration of flow rate

So that **eNod4** can carry out an expected flow rate dosing in the best conditions possible, the flow rate output control calibration is required. This also applies when **eNod4** is used both as belt scale or belt weigh feeder.

From this calibration will depend the accuracy of the flow rate obtained and on the actuation time delay, if a PID regulator controls it. This calibration is carried out in minimum two segments by the variable **segments number for the calibration curve of flow rate**. In case the extraction device has a nonlinear response it is recommended to define maximum segments for the flow rate calibration.

If the control of extraction device is directly provided by **eNod4** through a control analog output in *current* or *voltage*, analog output of **eNod4** must be allocated to **level on request** function first.

For each calibration point of the variable **control output value**, read the appropriate *average flow rate*. Then provide each of the **Calibration of control output point n / analog output** and **Calibration of flow rate point n matching with control output value**. Validate the flow rate calibration by sending "**calibration of flow rate**" command.

Allocate in the end the *current* or *voltage* analog output of **eNod4** to **flow rate control output** function.

10.3.30 PID parameters auto-adjustment

The configuration of the plan of regulation can be made in a totally automatic way. The behavior of PID regulation (slow, fast or stable) must beforehand be configured. Also, you have to configure reference flow rate used in PID auto-adjustment.

So that this plan of regulation works, it is necessary that weight calibration indication as well as flowrate calibration is beforehand realized.

"*PID parameters auto-adjustment*" command will cause **eNod4** to perform special sequence on belt system and to calculate optimized PID coefficients **Kp**, **Ti** and **Td**. It is strongly recommended that **Td** parameter does not exceeded value 5.

10.3.31 STOP & RESTART PID

We can STOP and RESTART PID at each cycle step. When PID is stopped, analog output pilots belt to nominal value.

10.3.32 Clear great total

"*Clear great total*" command allows only resetting "**Grand total (in weight unit x1000)**" totalization result.

10.3.33 Clear general total

"*Clear general total*" command allows only resetting "**General total (in weight unit x1000)**" totalization result.

11 CALIBRATION SETTINGS AND PROCEDURES

Name	Modbus address	EtherNet/IP Class/ Attribute (hex/dec)	Profinet Record Index	Profinet cyclic Req Code	EtherCAT index/sub-index	Type	Access
Maximum capacity	0x000C	0x65/1	0x0020	R:0x0420 W:0x0421	0x3002 / 0x00 (M)	Ulong	RW
Number of calibration segments	0x000E	0x65/2	0x0021	R:0x0222 W:0x0223	0x3000 / 0x00	Uint	RW
Calibration load 1	0x000F	0x65/3	0x0022	R:0x0424 W:0x0425	0x3001 / 0x01 (M)	Ulong	RW
Calibration load 2	0x0011	0x65/4	0x0023	R:0x0426 W:0x0427	0x3001 / 0x02	Ulong	RW
Calibration load 3	0x0013	0x65/5	0x0024	R:0x0428 W:0x0429	0x3001 / 0x03	Ulong	RW
Sensor sensitivity	0x0015	0x65/6	0x0025	R:0x042A W:0x042B	0x3004 / 0x00 (M)	Ulong	RW
Scale interval	0x0017	0x65/7	0x0026	R:0x022C W:0x022D	0x3003 / 0x00	Uint	RW
Zero calibration	0x0018	0x65/8	0x0027	R:0x0434 W:0x0435	0x3005 / 0x00	Long	RW
Span coefficient 1	0x001A	0x65/9	0x002B	R:0x0436 W:0x0437	0x3006 / 0x04	Float	RW
Span coefficient 2	0x001C	0x65/10	0x002C	R:0x0438 W:0x0439	0x3006 / 0x05	Float	RW
Span coefficient 3	0x001E	0x65/11	0x002D	R:0x043A W:0x043B	0x3006 / 0x06	Float	RW
Span adjusting coefficient	0x0020	0x65/12	0x0028	R:0x042E W:0x042F	0x3006 / 0x01 (M)	Ulong	RW
Calibration place g value	0x0022	0x65/13	0x0029	R:0x0430 W:0x0431	0x3006 / 0x02	Ulong	RW
Place of use g value	0x0024	0x65/14	0x002A	R:0x0432 W:0x0433	0x3006 / 0x03	Ulong	RW
Zero offset	0x0092	0x65/15	0x002E	R:0x0472 W:0x0473	0x2500 / 0x00 (M)	Long	RW

11.1 Principles

eNod4 is factory calibrated to deliver **500 000 counts for 2mV/V** with a load cell on the **A3** input connector.

The measurement scaling in **eNod4** can be adapted to his application by the user. Some settings and the 2 calibration methods allow the user to define his specific span according to his sensors characteristics.



When using eNod4 for legal for trade purpose, it is imperatively required to activate the legal for trade switch BEFORE any calibration procedure (cf § legal for trade switch).

11.2 Calibration methods

Measurement scaling can be defined using one of the two following methods:

- **Theoretical calibration** involving the sensitivity of the sensor and a user-defined corresponding capacity
- **Physical calibration** involving 1, 2 or 3 know loads (for a load cell)

Both can be achieved thanks to the functional commands.

11.3 Settings description

11.3.1 Maximum capacity

The '*maximum capacity*' stands for the maximum sensor/load cell signal range. When the absolute value of the gross measurement exceeds its value plus 9 divisions, the b_3 bit (positive overloading) or the b_2 bit (negative overloading) of the measurement status is set to 1 (it can activate a logical output if it is assigned to the '*defective measurement*' function).

The zero acquisition (on request or at power-up) is done only if the gross measurement value is contained between a $\pm 10\%$ range of the '*maximum capacity*' ($\pm 2\%$ if the *legal for trade* option is active).

The '*maximum capacity*' setting also allows calibrating **eNod4** in case of a theoretical calibration in association with the sensor sensitivity. Measurement scaling will be automatically adapted so as to deliver a gross measurement value equivalent to the '*maximum capacity*' for an analog signal corresponding to the sensor sensitivity.

After a theoretical calibration, the maximum capacity can be changed to fit to the application.

Admitted values : from 1 up to 10000000.

11.3.2 Number of calibration segments

The '*number of calibration segments*' defines how many calibration segments are used during the physical calibration procedure. Linear installations only need one segment.

Admitted values : from 1 up to 3.

11.3.3 Calibration loads 1/2/3

Before starting a physical calibration procedure, each calibration segment must be given a corresponding user value (for example, 1000 points for a 1 kg load).

Admitted values : from 1 up to 10000000.

11.3.4 Sensor sensitivity

The '*sensor sensitivity*' setting is used to achieve a theoretical calibration. The stored value for this parameter is the load cell sensitivity in **mV/V**.

The user can adapt the value delivered by **eNod4** for the associated signal using the '*maximum capacity*' and the '*sensor sensitivity*'.

This setting is expressed with a 10^{-5} factor (197500 is equivalent to a 1.975 mV/V load cell sensitivity or a 1.975 V input voltage).

Admitted values : from 1 up to 1000000.

11.3.5 Scale interval

The '*scale interval*' is the minimal difference between two consecutive indicated values (either gross or net).

Modification of scale interval is taking into account after a new calibration.

Admitted values : 1/2/5/10/20/50/100

11.3.6 Zero calibration

Zero calibration value corresponds to the A/D converter points measured during the 'zero acquisition' step of a physical calibration.

For a theoretical calibration this value must be set. It can be set automatically with the 'zero adjustment' command.

Note: To be applied, any modification of this setting must be followed by an EEPROM back up and device reboots (hardware or software).

Admitted values : from 0 up to +-10000000

11.3.7 Span coefficients 1/2/3

These coefficients are computed and written during calibration process. Writing these coefficients could be done if you want to restore a previous calibration.

Note: To be applied, any modification of this setting must be followed by an EEPROM back up and device reboots (hardware or software).

Admitted values : different from 0.

11.3.8 Span adjusting coefficient

The 'span adjusting coefficient' allows adjusting initial calibration. Adjustment applies linearly on the whole calibration curve. This coefficient has a 10^{-6} factor (1000000 is equivalent to a span adjusting coefficient that is equal to 1).

Note: To be applied, any modification of this setting must be followed by an EEPROM back up and device reboots (hardware or software).

Admitted values : from 900000 up to 1100000.

11.3.9 Calibration place g value / place of use g value

When the calibration place and the place of use of a measuring chain are different, a deviation can appear due to the difference of g (gravity) between the 2 places.

The **eNod4** calculates a ratio applied to the measure which compensates the difference of gravity between the 2 places.

The g value are expressed in 10^{-6} m.s^{-2} (9805470 is equivalent to $g = 9.805470 \text{ m.s}^{-2}$).

The **eNodView** software can help to determine the g value of a place.

Note: To be applied, any modification of this setting must be followed by an EEPROM back up and device reboots (hardware or software).

Admitted values : different from 0.

11.3.10 Zero offset

The 'Zero offset' value contains the offset in factory calibrated points that can be added/subtracted (if its value is positive or negative) to the zero calibration value when using the 'zero offset' functional command. Once the command has been successfully achieved, this register is set to 0.

Note: The 'Zero offset' value is not stored into EEPROM memory and is always equal to 0 after a device power-up or a software reset

Admitted values: different from 0.

12 FILTERS

Name	Modbus address	EtherNet/IP Class/ Attribute (hex/dec)	Profinet Record Index	Profinet cyclic Req Code	EtherCAT index/sub-index	Type	Access
A/D conversion rate	0x0036	0x66/1	0x0030	R:0x0240 W:0x0241	0x4000 / 0x00	Uint	RW
filters activation	0x0037 LSB	0x66/2 LSB	0x0031 LSB	R:0x0242 LSB W:0x0243 LSB	0x4001 / 0x01 (byte)	Byte	RW
Low-pass order	0x0037 MSB	0x66/2 MSB	0x0031MSB	R:0x0242 MSB W:0x0243 MSB	0x4001 / 0x02 (byte)	Byte	RW
Low-pass cut-off frequency	0x0038	0x66/3	0x0032	R:0x0244 W:0x0245	0x4001 / 0x03	Uint	RW
Band-stop high cut-off frequency	0x0039	0x66/4	0x0033	R:0x0246 W:0x0247	0x4001 / 0x04	Uint	RW
Band-stop low cut-off frequency	0x003A	0x66/5	0x0034	R:0x0248 W:0x0249	0x4001 / 0x05	Uint	RW
Average weight filter depth	0x0058	0x66/6	0x0070	R:0x0274 W:0x0275	0x4001 / 0x06	Uint	RW
Average process data filter depth	0x0059	0x69/3	0x0072	R:0x0278 W:0x0279	0x4703 / 0x09	Uint	RW

12.1 Principles

eNod4 contains 4 filtering layers that are user-configurable :

- filtering related to the A/D conversion rate (with rejection of the mains frequency)
- a low-pass Bessel-type filter
- a band-stop filter
- a Moving average weight filter

Except for the A/D conversion rate that is always enabled, none of these filters is mandatory. However, to perform accurate measurements we recommend setting a combination of filters. **eNodView** software may be helpful in designing the best filter configuration for the application.

12.2 Settings list

Here is the list of the settings that have an impact on the filters configuration:

12.3 Settings description

12.3.1 A/D conversion rate

It contains a code which represents the A/D conversion rate and the rejection. See table below:

b_4	Rejection	
0	60 Hz	
1	50 Hz	

$b_3 b_2 b_1 b_0$	A/D conversion rate (measures/s)	
	50-Hz rejection	60-Hz rejection
0000	100	120
0001	50	60
0010	25	30
0011	12.5	15
0100	6.25	7.5
1001	1600	1920
1010	800	960
1011	400*	480*
1100	200	240

(*) In **belt mode**, A/D conversion rate is fixed to **400 measures/s** and cannot be modified.

Note: To be applied, any modification of this setting must be followed by an EEPROM back up and device reboots (hardware or software).

12.3.2 Filters activation & order

This setting allows to define what filters are enabled in **eNod4** signal processing chain.

Note: the filters activation & order setting can be accessed through a 16-bits register except in CANopen® communication protocol where this word is divided into 2 8-bits registers:

b_0	Meaning
0	band-stop filter disabled
1	band-stop filter enabled

b_1	Meaning
0	Reserved(not used)

$b_{10} b_9 b_8$	Meaning
000	low-pass filter disabled
010	2 nd order low-pass filter
011	3 rd order low-pass filter

Note: In CANopen® communication protocol (according to version), this word is divided into 2 bytes of 8-bits registers. Bits b8 to b15 are therefore equivalent to bits b0 to b7 of the corresponding address (see CANopen® Register table).

12.3.3 Low-pass filter cut-off frequency

This register contains the low-pass filter cut-off frequency expressed in Hz and multiplied by 100. That means that 690 is equivalent to 6.90 Hz. The value must be compliant with the table shown below.

Admitted values: from 10 up to 20000.

12.3.4 Limitations

Recursive filters like **eNod4** low-pass filters are computed according to the filter order, the desired cut-off frequency and the sampling rate. There are some limitations to respect in order to ensure a safe functioning of the signal processing. They are listed in the table below:

A/D conversion rate (meas/s)	min low-pass cut-off frequency (Hz)		A/D conversion rate (meas/s)	min low-pass cut-off frequency (Hz)	
	50 Hz rejection			60 Hz rejection	
	2nd order	3rd order		2nd order	3rd order
6.25	0.10	0.10	7.5	0.10	0.10
12.5	0.10	0.10	15	0.10	0.15
25	0.10	0.15	30	0.15	0.20
50	0.15	0.25	60	0.20	0.30
100	0.25	0.50	120	0.30	0.60
200	0.50	1.00	240	0.60	1.20
400*	1.00	2.00	480*	1.20	2.40
800	2.00	4.00	960	2.40	4.80
1600	4.00	8.00	1920	4.80	9.60

(*) In **belt mode**, A/D conversion rate is fixed to **400 meas./s** and cannot be modified.

12.3.5 Band-stop filter high cut-off frequency

This register contains the band-stop filter high cut-off frequency expressed in Hz and multiplied by 100. That means that 690 is equivalent to 6.90 Hz. **The value must be higher than the band-stop filter low cut-off frequency.**

Admitted values: from 10 up to 20000.

12.3.6 Band-stop filter low cut-off frequency

This register contains the band-stop filter low cut-off frequency expressed in Hz and multiplied by 100. That means that 690 is equivalent to 6.90 Hz. **The value must be lower than the band-stop filter high cut-off frequency.**

Admitted values: from 10 up to 20000.

12.3.7 Moving average weight filter depth

This filter can be set in cascade after previous filters. The Moving average filter is used to smooth the weight value in case of random interferences. This sliding average computes the mean of the 'n' last measures which are output of the previous filters, if enabled. A high filter depth will give a better stability, with a longer response time.

Filter depth admitted values: 0(disabled) up to 128.

12.3.8 Moving average flow rate/speed filter depth

Specific average filter might be applied on belt process data to have stable display. A high filter depth will give a better stability, with a longer response time.

Filter depth admitted values: 0(disabled) up to 128.

13 CONFIGURATION OF INPUT/OUTPUT

Name	Modbus address	EtherNet/IP Class/ Attribute (hex/dec)	Profinet Record Index	Profinet cyclic Req Code	EtherCAT index/sub-index	Type	Access
Analog output functioning (IO+ version)	0x0040	0x67/15	0x005B	R:0x026C W:0x026D	0x4509 / 0x05	Uint	RW
Logical input 3 functioning	0x0041 LSB	0x67/14 LSB	0x0042 LSB	R:0x026A LSB W:0x026B LSB	0x4501 / 0x04	Byte	RW
Logical input 4 functioning	0x0041 MSB	0x67/14 MSB	0x0042 MSB	R:0x026A LSB W:0x026B LSB	0x4501 / 0x05	Byte	RW
Logical input 1 functioning	0x0042 LSB	0x67/1 LSB	0x0040 LSB	R:0x0250 LSB W:0x0251 LSB	0x4501 / 0x02	Byte	RW
Logical input 2 functioning	0x0042 MSB	0x67/1 MSB	0x0040 MSB	R:0x0250 MSB W:0x0251 MSB	0x4501 / 0x03	Byte	RW
holding time	0x0043	0x67/2	0x0041	R:0x0252 W:0x0253	0x4501 / 0x01	Uint	RW
Output 1 functioning	0x0044 LSB	0x67/3 LSB	0x0050 LSB	R:0x0254 LSB W:0x0255 LSB	0x4509 / 0x01	Byte	RW
Output 2 functioning	0x0044 MSB	0x67/3 MSB	0x0050 MSB	R:0x0254 MSB W:0x0255 MSB	0x4509 / 0x02	Byte	RW
Output 3 functioning	0x0045 LSB	0x67/4 LSB	0x0051 LSB	R:0x0256 LSB W:0x0257 LSB	0x4509 / 0x03	Byte	RW
Output 4 functioning	0x0045 MSB	0x67/4 MSB	0x0051 MSB	R:0x0256 MSB W:0x0257 MSB	0x4509 / 0x04	Byte	RW
Set point 1 high value	0x0046	0x67/5	0x0052	R:0x045A W:0x045B	0x4601 / 0x02	Long	RW
Set point 1 low value	0x0048	0x67/6	0x0053	R:0x045C W:0x045D	0x4601 / 0x03	Long	RW
Set point 2 high value	0x004A	0x67/7	0x0054	R:0x045E W:0x045F	0x4601 / 0x04	Long	RW
Set point 2 low value	0x004C	0x67/8	0x0055	R:0x0460 W:0x0461	0x4601 / 0x05	Long	RW
Set point 3 high value	0x004E	0x67/9	0x0056	R:0x0462 W:0x0463	0x4609 / 0x02	Long	RW
Set point 3 low value	0x0050	0x67/10	0x0057	R:0x0464 W:0x0465	0x4609 / 0x03	Long	RW
Set point 4 high value	0x0052	0x67/11	0x0058	R:0x0466 W:0x0467	0x4609 / 0x04	Long	RW
Set point 4 low value	0x0054	0x67/12	0x0059	R:0x0468 W:0x0469	0x4609 / 0x05	Long	RW
1&2 Set points functioning	0x0056 LSB	0x67/13 LSB	0x005A LSB	R:0x0258 LSB W:0x0259 LSB	0x4601 / 0x01	Byte	RW
3&4 Set points functioning	0x0056 MSB	0x67/13 MSB	0x005A MSB	R:0x0258 MSB W:0x0259 MSB	0x4609 / 0x01	Byte	RW

Name	Modbus address	EtherNet/IP Class/ Attribute (hex/dec)	Profinet Record Index	Profinet cyclic Req Code	EtherCAT index/sub-index	Type	Access
External value for analog output (IO+ version)	0x0032	0x67/16	0x005C	R:0x023C W:0x023D + See modules list	0x5050 / 0x00 (M)	Uint	RW
Weight quantity per pulse on logical output	0x0057	0x69/1	0x008D	R:0x02AE W:0x02AF	0x4700 / 0x02	Uint	RW
Input level	0x0094 LSB	0x68/3 LSB	/	/	0x5100 / 0x00 (M)	Byte	RO
Output level	0x0094 MSB	0x68/3 MSB	/	/	0x5200 / 0x00 (M)	Byte	RO

13.1 Principles

eNod4 device is fitted with 2 logical inputs (4 logical inputs for IO+ version) and 4 logical outputs that are fully configurable.

13.1.1 Logical inputs

Each input can work individually in positive or negative logic. A holding time (de-bounced time) attached to all inputs can be configured.

Available functions see hereunder table:

Function	Operating mode		
	transmitter	Belt scale	Belt weigh feeder
none	•	•	•
tare	•	•	•
cancel tare	•	•	•
zero	•	•	•
transmit measurement	•		
measurement window	•		
dynamic zero		•	•
Start/Stop		•	•
Belt running detection		•	•
Clear totalization and errors counter		•	•
Sensor input control	•	•	•
Belt fault		•	•

Note: Most of functions set to logical inputs can also be sent by '*functional commands*'; for a precise description see § 'functional commands'.

- **None**

The input has no function

- **Tare**

A rising (positive logic) or a falling edge (negative logic) causes a tare function to be triggered.

- **Cancel tare**

A rising (positive logic) or a falling edge (negative logic) causes the current stored tare to be erased.

- **Zero**

A rising (positive logic) or a falling edge (negative logic) causes a zero function to be triggered.

- **Transmit measurement**

Only available in CANopen® and SCMBus/fast SCMBus protocols.

A rising (positive logic) or a falling edge (negative logic) triggers a measurement transmission.

- **Measurement window**

Only available in SCMBus/fast SCMBus protocols. Measurements are continuously transmitted at a rate defined by the 'sampling period' while the input is maintained at the chosen level.

- **Start/Stop (batch/system)**

If all the starting conditions are respected, a rising or a falling edge (according to the configured logic) on this input causes a new totalization cycle to be started.

In batch mode and when cleared totalization at starting new cycle option is enabled, the totalization result is set to zero at each start cycle.

If dosing cycle is running, the second edge of this command will stop the process.

- **Belt running motion detection**

If speed sensor is broken or if no speed sensor is connected to **eNod4** device, this logical input might be assigned to **motion detection** function to enable totalization function.

- **Clear/Reset totalization and errors counter**

Cleared totalization function can be assigned to logical input. You may clear total amount dosed and dosing errors counter at any time. At this input activation on rising or falling edge (according to the configured logic), the **main total** in **weight unit x1000** and the **complementary weight** value are reset to zero.

Also, **dosing errors counter** parameter is set to zero.

- **Dynamic zero**

When the belt is running empty, this input activation will cause **eNod4** to perform conveyor zero function by measuring rate of flow of material.

Run the conveyor for several minutes to ensure the belt is empty and supple. The conveyor should be operating at **normal speed** throughout the calibration. Dynamic zero function duration will depend upon the **number of revolution** chosen, and belt length and speed. The procedure can be left to complete its cycles or send **exit calibration** command to interrupt.

- Sensor input control

A rising (positive logic) or a falling edge (negative logic) triggers a test routine of the sensor input and produces a test result.

- Belt fault

Belt Fault function should be assigned to logical input. At this input activation on rising or falling edge (according to the configured logic), **Belt fault alarm** is activated.

13.1.2 Analog output (IO+ version)

An optional analog board in *current* and *voltage* might be used with **eNod4** to provide IO+ version. This must be asked when ordering **eNod4** product.

Voltage output might be set either 0-5V or 0-10V, and the current output to 4-20mA, 0-24mA , 0-20mA or 4-20mA with alarm at 3.6mA. Both output (current and voltage) might separately be enable. Settings are effective after **eNod4** reset.

Analog output affectation function is common to both *current* and *voltage* output and might be assigned to followings:

<i>function</i>	<i>Operating mode</i>		
	<i>transmitter</i>	<i>Belt scale</i>	<i>Belt weigh feeder</i>
<i>none</i>	•	•	•
<i>gross measurement</i>	•	•	•
<i>net measurement</i>	•	•	•
<i>level on request</i>	•	•	•
<i>flow rate control output</i>		•	•
<i>instant flow rate</i>	•	•	•
<i>average flow rate</i>	•	•	•
<i>average belt speed</i>	•	•	•

- **None** : analog outputs have no function.
- **Gross measurement** : analog outputs can be assigned to gross measurement copy. Maximal level value is related to **Maximum Capacity** parameter and works in mono-quadrant functioning. Bi-quadrant option can only be applied to gross measurement copy. When this option is activated, the lowest value of current and voltage levels corresponds to **-MC** and the highest value to **+MC**.
- **Net measurement** : analog outputs can be assigned to net measurement copy. Maximal value is related to **Maximum Capacity** parameter and works in mono-quadrant functioning only. The highest value of current and voltage levels corresponds to **+MC** in only one quadrant.
- **Level on request** : analog outputs are driven by master requests through the **external value to control analog output** variable (in 0.01% of the full scale of current or voltage analog outputs).
- **Flow rate control output** : PID controller output data (activated or not) drives current or voltage outputs generally coupled to the extraction device. Data is expressed in 0.01% of the high value of current or voltage analog outputs. Maximal level output value corresponds to the maximal flowrate (see § flow rate calibration).
- **Instant flow rate** : analog outputs can be assigned to instant flow rate copy. Maximal level output value corresponds to the maximal flowrate (see § flow rate calibration).
- **Average flow rate** : analog outputs can be assigned to average flow rate copy. Maximal level output value corresponds to the maximal flowrate (see § flow rate calibration).
- **Average belt speed** : analog outputs can be assigned to average belt speed copy. Maximal level output value corresponds to the maximal belt speed (see § BELT OPERATING MODES).

When analog output is assigned to “Gross measurement”, “Net measurement”, “Instant flow rate” or “Average flow rate” its value jumps to a special error value when the internal alarm flag described in “Weighing diagnosis” § in the MEASUREMENT AND STATUS § is activated. This allows to warn about defection of the measurement chain.

The error value on analog output is defined depending on voltage or current settings as described in following table:

<i>Setting</i>	<i>Analog output error mode value</i>
0 - 5V	5.5 V
0 - 10V	11 V
4 - 20mA	no output current
0 - 20mA*	no output current
0 - 24mA*	no output current
4 mA - 20 mA with alarm at 3.6 mA	3.6 mA, voltage output is deactivated (High-Z state)

* no error detection possible in this setting

13.1.3 Logical outputs

Each output can work individually in positive or negative logic

The available functions are:

<i>function</i>	<i>Operating mode</i>		
	<i>transmitter</i>	<i>Belt scale</i>	<i>Belt weigh feeder</i>
<i>none</i>	•	•	•
<i>set point</i>	•	•	•
<i>motion</i>	•	•	•
<i>defective measurement</i>	•	•	•
<i>input image</i>	•	•	•
<i>level on request</i>	•	•	•
<i>belt alarms</i>		•	•
<i>external totalizer</i>		•	•
<i>belt system running</i>		•	•
<i>batch in progress</i>		•	•
<i>batch result available</i>		•	•
<i>conveyor starting alarm</i>		•	•
<i>material TOR gate</i>		•	•

- **None**

The output has no function.

- **Motion**

The output is dedicated to copying the stability flag level.

- **Defective measurement**

The output level is set when the internal alarm flag described in “Weighing diagnosis” § in the MEASUREMENT AND STATUS § is activated. This allows to warn about defection of the measurement chain. Flowrate alarms are not considered as defective measurements.

- **Set point**

Each output can be assigned to a configurable set point (set point 1 corresponds to output 1, set point 2 to output 2, set point 3 to output 3 and set point 4 to output 4).

- **Input X image**

The output is dedicated to copying a logical input level (outputs 1 and 3 correspond to inputs 1 and 3, outputs 2 and 4 correspond to input 2 and 4).

- [Level on request](#)

The input level is driven by master requests.

- [Belt alarms](#)

The output is dedicated to copying alarm flags level. Alarms might be flow rate or belt speed or belt load or control output level or external totalizer overflow.

- [External totalizer](#)

This output is dedicated to deliver pulses for external totalizer device.

If a logical output is assigned to *external totalizer* function, *eNod4* will send a pulse every time totalization result will reach a multiple of weight value defined in “*weight quantity per pulse on logical output*” parameter.

- [Belt system running](#)

In belt mode, indicates that a totalization function is activated.

- [Batch in progress](#)

In batch mode, indicates that a batch cycle is in progress.

- [Batch result available](#)

In batch mode, indicates the end of a cycle (batch target is reached).

- [Conveyor starting alarm](#)

eNod4 analog output in current or voltage might be used to drive conveyor speed engine through inverter.

So that for security reason a logical output can be assigned to “*Conveyor starting alarm*” function and the duration is configured through “*conveyor starting alarm duration*” parameter.

- [Material TOR gate](#)

Depending application, this output is dedicated to open and to close the belt material two states gate.

13.2 Settings description

13.2.1 Logical inputs assignment

The following table describes the possible assignments.

<i>bits</i>	<i>meaning</i>	<i>note</i>
$b_3 b_2 b_1 b_0$	input 1&3 assignment	
0000	none	the input has no function
0001	tare	equivalent to the functions described in § functional commands
0010	zero	
0011	cancel tare	
0100	transmit measurement*/send TPDO2**	data is transmitted on the bus at every rising or falling edge (depending on the chosen logical) Transmitter mode only
0101	measurement window*	Data is transmitted on the bus while the input is maintained at the right level (depending on the chosen logical). Transmission rate is fixed by the 'sampling rate' setting
0110	Dynamic zero	Same like equivalent functional command describe in § functional commands
0111	Start / Stop	Belt mode
1000	Belt running detection	
1001	Clear totalization and errors counter	Same like equivalent functional command describe in § functional commands
1010	Sensor input control	Same like equivalent functional command describe in § functional commands
1011	Belt fault	In this case, the input is linked to fault sensor. This function triggers alarm.
b_4	input 1&3 logical	
0	negative logic	defines the edge (or level) that triggers input function
1	positive logic	
$b_6 b_5$	measurement to be transmitted	
00	gross	only for SCMBus/fast SCMBus protocols, no effect otherwise
01	net	
10	factory calibrated measurement	
<i>bits</i>	<i>meaning</i>	<i>note</i>
$b_{11} b_{10} b_9 b_8$ (or $b_3 b_2 b_1 b_0$ in CANopen®)	input 2&4 assignment	
0000	none	the input has no function

<i>bits</i>	<i>meaning</i>	<i>note</i>
0001	<i>tare</i>	
0010	<i>zero</i>	<i>equivalent to the functions described in § functional commands</i>
0011	<i>cancel tare</i>	
0100	<i>transmit measurement*/send TPDO3**</i>	
0101	<i>measurement window*</i>	<i>data is transmitted on the bus while the input is maintained at the right level (depending on the chosen logical). Transmission rate is fixed by the 'sampling rate' setting</i>
0110	<i>Dynamic zero</i>	<i>Same like equivalent functional command describe in § functional commands</i>
0111	<i>Start / Stop</i>	<i>Belt mode</i>
1000	<i>Belt running detection</i>	<i>Same like equivalent functional command describe in § functional commands</i>
1001	<i>Clear totalization and errors counter</i>	<i>Same like equivalent functional command describe in § functional commands</i>
1010	<i>Sensor input control</i>	<i>Same like equivalent functional command describe in § functional commands</i>
1011	<i>Belt fault</i>	<i>In this case, the input is linked to fault sensor. This function triggers alarm.</i>
<i>b₁₂</i> <i>(or b₄ in CANopen®)</i>	<i>input 2&4 logical</i>	
0	<i>negative logic</i>	<i>defines the edge (or level) that triggers input function</i>
1	<i>positive logic</i>	
<i>b₁₄ b₁₃</i> <i>(or b₆ b₅ in CANopen®)</i>	<i>measurement to be transmitted</i>	
00	<i>gross</i>	<i>only for SCMBus/fast SCMBus protocols, no effect otherwise</i>
01	<i>net</i>	
10	<i>factory calibrated measurement</i>	

- **Note 1:** the functions with a * only are possible in SCMBus and fast SCMBus protocols.
- **Note 2:** in CANopen® communication protocol, to use the 'send TPDOX' function, it is necessary to configure the TPDO communication parameters (and particularly the communication type) and the mapping for the corresponding TPDO.

13.2.2 Holding time (debounced time)

The holding time (de-bounced time) corresponds to the minimum required stabilization time of the logical inputs before their activation. If the input level varies within this interval, it is ignored.

13.2.3 Analog output(s) assignment (IO+ version)

The following tables describe the possible assignments.

<i>bits</i>	<i>meaning</i>	<i>note</i>
<i>b₃ b₂ b₁ b₀</i>	<i>analog output assignment</i>	
<i>0000</i>	<i>none</i>	<i>the output level does not vary</i>
<i>0001</i>	<i>copy gross weight</i>	<i>Adjustable polarity</i>
<i>0010</i>	<i>copy net weight</i>	
<i>0011</i>	<i>level on request</i>	<i>parameter External value to control analog output will drive analog output</i>
<i>0100</i>	<i>flow rate control output</i>	<i>in loss in weight feeder mode (for extraction device control)</i>
<i>0101</i>	<i>copy instantaneous flow rate</i>	
<i>0110</i>	<i>copy average flow rate</i>	
<i>0111</i>	<i>copy average speed</i>	
<i>b₄</i>	<i>polarity</i>	
<i>0</i>	<i>unipolar</i>	<i>could be set only with gross measurement</i>
<i>1</i>	<i>bipolar</i>	
<i>b₇ b₆ b₅</i>	<i>output voltage settings</i>	
<i>000</i>	<i>disable</i>	
<i>001</i>	<i>0 V - 5 V</i>	
<i>010</i>	<i>0 V - 10 V</i>	
<i>b₁₀ b₉ b₈</i>	<i>output current settings</i>	
<i>000</i>	<i>disable</i>	
<i>001</i>	<i>4 mA - 20 mA</i>	
<i>010</i>	<i>0 mA - 20 mA</i>	
<i>011</i>	<i>0 mA - 24 mA</i>	
<i>100</i>	<i>4 mA - 20 mA alarm 3.6 mA</i>	<i>voltage output is inactive (High-Z state)</i>

13.2.4 External value to control analog output (IO+ version)

If an external device (e.g. PLC) would like to control extraction command through **eNod4** analog output, so that output must be set on **level on request** function. In this configuration **eNod4** will copy **external value to control analog output** parameter on analog output in current and voltage.

The external value parameter is expressed in 0.01% of full scale of analog output current or voltage.

13.2.5 Logical outputs 1&2 assignment

The following table describes the possible assignments.

<i>bits</i>	<i>meaning</i>	<i>note</i>
$b_3 b_2 b_1 b_0$	output 1 assignment	
0000	<i>none</i>	<i>the output level does not vary</i>
0001	<i>set point 1</i>	<i>functioning described by the 'set point functioning' setting and by the 'set point 1 high and low values'</i>
0010	<i>motion</i>	<i>copies the motion flag of the status bytes</i>
0011	<i>defective measurement</i>	<i>reflect the internal alarm flag described in "Weighing diagnosis" § in the MEASUREMENT AND STATUS §</i>
0100	<i>input 1 image</i>	<i>copies input 1 level</i>
0101	<i>level on request</i>	<i>output 1 level is driven by the 'OUT1 activation/deactivation' functional command</i>
0110	<i>belt alarms</i>	<i>Belt mode (alarm flag representing the OR logical operation between the error bits of the alarms registers word)</i>
0111	<i>external totalizer</i>	<i>Belt mode</i>
1000	<i>belt system running</i>	<i>Belt mode</i>
1001	<i>batch in progress</i>	<i>Belt mode</i>
1010	<i>batch result available</i>	<i>Belt mode</i>
1011	<i>conveyor starting alarm</i>	<i>Belt mode</i>
1100	<i>material TOR gate</i>	<i>Belt mode</i>
b_4	output 1 logical	
0	<i>negative logic</i>	<i>defines the output level when enabled</i>
1	<i>positive logic</i>	
$b_{11} b_{10} b_9 b_8$ (or $b_3 b_2 b_1 b_0$ in CANopen®)	output 2 assignment	
0000	<i>none</i>	<i>the output level does not vary</i>
0001	<i>set point 2</i>	<i>functioning described by the 'set point functioning' setting and by the 'set point 2 high and low values'</i>
0010	<i>motion</i>	<i>copies the motion flag of the status bytes</i>
0011	<i>defective measurement</i>	<i>reflect the internal alarm flag described in "Weighing diagnosis" § in the MEASUREMENT AND STATUS §</i>
0100	<i>input 2 image</i>	<i>copies input 2 level</i>
0101	<i>level on request</i>	<i>output 2 level is driven by the 'OUT2 activation/deactivation' functional command</i>
0110	<i>belt alarms</i>	<i>Belt mode (alarm flag representing the OR logical operation between the error bits of the alarms registers word)</i>

<i>bits</i>	<i>meaning</i>	<i>note</i>
0111	<i>external totalizer</i>	<i>Belt mode</i>
1000	<i>belt system running</i>	<i>Belt mode</i>
1001	<i>batch in progress</i>	<i>Belt mode</i>
1010	<i>batch result available</i>	<i>Belt mode</i>
1011	<i>conveyor starting alarm</i>	<i>Belt mode</i>
1100	<i>material TOR gate</i>	<i>Belt mode</i>
<i>b₁₂</i> <i>(or b₄ in CANopen®)</i>	<i>output 2 logical</i>	
0	<i>negative logic</i>	<i>defines the output level when enabled</i>
1	<i>positive logic</i>	<i>defines the output level when enabled</i>

13.2.6 Logical outputs 3&4 assignment

Similar to the outputs 1&2 configuration parameter, see previous paragraph (replacing all references to output 1 by output 3 and all references to output 2 by output 4).

13.2.7 Weight quantity per pulse on logical output

When a logical output is assigned to **external totalizer**, a pulse is generated every time the totalization increases a multiple of a **weight quantity per pulse on logical output**. The maximum pulse frequency is 10 Hz and pulse duration is fixed at 50ms. The output pulse is not rounded (i.e. the pulse is issued only once **weight quantity per pulse on logical output** is strictly exceeded).

13.2.8 Set points functioning

The following table describes the possible assignments.

<i>bits</i>	<i>meaning</i>	<i>note</i>
b_0	set point 1 commutation mode	
0	<i>window</i>	<i>only if output 1 assigned to the 'set point' function</i>
1	<i>hysteresis</i>	
$b_2 b_1$	set point 1 comparison measurement	
00	<i>gross</i>	
01	<i>net</i>	
10	<i>Sensor input control result</i>	
11	<i>Batch</i>	
b_3	reserved (0)	
b_4	set point 2 commutation mode	
0	<i>window</i>	<i>only if output 2 assigned to the 'set point' function</i>
1	<i>hysteresis</i>	
$b_6 b_5$	set point 2 comparison measurement	
00	<i>gross</i>	
01	<i>net</i>	
10	<i>Sensor input control result</i>	
11	<i>Batch</i>	
b_7	reserved (0)	
b_8 (or b_0 in CANopen®)	set point 3 commutation mode	
0	<i>window</i>	<i>only if output 3 assigned to the 'set point' function</i>
1	<i>hysteresis</i>	
$b_{10} b_9$ (or $b_2 b_1$ in CANopen®)	set point 3 comparison measurement	
00	<i>gross</i>	
01	<i>net</i>	
10	<i>Sensor input control result</i>	
11	<i>Batch</i>	
b_{11} (or b_3 in CANopen®)	reserved (0)	

<i>bits</i>	<i>meaning</i>	<i>note</i>
b_{12} (or b_4 in CANopen®)	set point 4 commutation mode	
0	<i>window</i>	<i>only if output 4 assigned to the 'set point' function</i>
1	<i>hysteresis</i>	
$b_{14} b_{13}$ (or $b_6 b_5$ in CANopen®)	set point 4 comparison measurement	
00	<i>gross</i>	
01	<i>net</i>	
10	<i>Sensor input control result</i>	
11	<i>Batch</i>	
b_{15} (or b_7 in CANopen®)	reserved (0)	

13.2.9 Set points high and low values

Each set point is described by its commutation mode (hysteresis/window) and by a couple of values that are constantly compared to the gross or net measurement or to dosing result or dosing running total (depending on the configuration the set point has been given) in order to define the corresponding output logical level. For more details about the set points functioning, please refer to documentation ref. 236722.

Admitted values: from -1000000 to 1000000.

13.3 Input/output level

The level of the **eNod4** Input/output can be read according to the following table:

Bits	Meaning	Note
b0		
0	low	IN1 level
1	high	
b1		
0	low	IN2 level
1	high	
b2	With IO+ version only, else 0	
0	low	IN3 level
1	high	
b3	With IO+ version only, else 0	
0	low	IN4 level
1	high	
b7 ... b4		
0	reserved (0)	
b8 (note 1)		
0	low	OUT1 level
1	high	
b9 (note 1)		
0	low	OUT2 level
1	high	
b10 (note 1)		
0	low	OUT3 level
1	high	
b11 (note 1)		
0	low	OUT4 level
1	high	
b15 ... b12 (note 1)		
0	reserved (0)	

Note 1: In CANopen® communication protocol (according to version), this word is divided into 2 bytes of 8-bits registers. Bits b8 to b15 are therefore equivalent to bits b0 to b7 of the corresponding address (see CANopen® Register table).

14 LEGAL FOR TRADE OPTIONS

Name	Modbus address	EtherNet/IP Class/ Attribute (hex/dec)	Profinet Record Index	Profinet cyclic Req Code	EtherCAT index/sub-index	Type	Access
Legal for trade version	0x0004 LSB	0x64/3	0x0010 LSB	R: 0x0210 LSB W: /	0x3600 / 0x02	Byte	RO
Legal for trade switch	0x0004 MSB	0x64/4	0x0010 MSB	R: 0x0210 MSB W: 0x0211MSB	0x3600 / 0x01	Byte	RW
Legal for trade counter	0x0005	0x64/5	0x0011	R: 0x0212 W: /	0x3600 / 0x03	Byte	RO
Legal for trade checksum	0x0006	0x64/6	0x0012	R: 0x0214 W: /	0x3600 / 0x04	Uint	RO
Zero functions	0x0007	0x64/7	0x0013	R:0x0216 W:0x0217	0x3501 / 0x01	Byte	RW
Stability criterion	0x0008 LSB	0x64/8 LSB	0x0014 LSB	R:0x0218 LSB W:0x0219 LSB	0x3605 / 0x00	Byte	RW
decimal point position	0x0008 MSB	0x64/8 MSB	0x0014 MSB	R:0x0218 MSB W:0x0219 MSB	0x3700 / 0x02	Byte	RW
Weight unit	0x0009	0x64/9	0x0015	R:0x041A W:0x041B	0x3700 / 0x01	String	RW
Flow rate time unit	0x005A	0x64/9	0x0015	R:0x041A W:0x041B	0x4701 / 0x01	String	RW

14.1 Principles

The legal for trade options are a set of functions and indicators that are generally used in weighing applications. They have an impact on the device behavior regarding the metrological requirements and track every configuration change that may affect the measurement determination.

14.2 Settings description

14.2.1 Legal for trade switch

This setting activates (b_0 bit set to 1) or deactivates (b_0 bit set to 0) criteria and parameters related to the use of **eNod4** in OIML compliance.

The 'legal for trade' option activation leads to the following changes:

- the 'legal for trade counter' is incremented every time a storage into EEPROM is requested if one or several metrological settings have been modified.
- a new 'legal for trade checksum' value is calculated every time a storage into EEPROM is requested if one or several metrological settings have been modified.
- taring is now impossible if gross measurement is negative.
- the measurement value variations cannot be read during the 15 seconds that follow the device reset (error frame in Modbus RTU, value set to -1 in CANopen® and in Profibus DP) and during zero and tare acquisitions

14.2.2 Legal for trade software version

This RO value identifies the version of the part of the software that is dedicated to the metrology and the measurement exploitation.

14.2.3 Legal for trade counter

If the 'legal for trade' option is enabled, the legal for trade counter is incremented every time a backup into EEPROM is requested if at least one (or several) of these settings has been modified:

- legal for trade switch
- stability criterion
- decimal point position
- maximum capacity
- number of calibration segments
- calibration loads 1/2/3
- scale interval
- span adjusting coefficient
- calibration place/place of use g values
- sensitivity
- A/D conversion rate
- filtering configuration (activation option, order and cut-off frequencies)
- weight unit
- flow rate time unit
- zero functions

14.2.4 Legal for trade checksum

If the 'legal for trade' option is enabled, a new legal for trade checksum is calculated every time a backup into EEPROM is requested if at least one (or several) of the settings listed above has been modified.

14.2.5 Zero functions

The zero tracking and the initial zero setting can be respectively enabled by setting b_0 bit or b_1 bit to 1. When activated, both options are effective on a $\pm 10\%$ range of the 'maximum capacity' ($\pm 2\%$ if the 'legal for trade' option is enabled).



When the initial zero is used, you must use a stability criterion other than 0 to be not affected by transient effects at power-up.

14.2.6 Stability criterion

The stability criterion defines the interval on which measurements are considered as stable. Motion is indicated by b_4 bit of the measurement status register. A measurement is stable if X consecutive measurements following the reference measurement are included in the stability interval (see following table) else the current measurement becomes the new reference measurement. X depends on the A/D conversion rate.

Bits b_2 b_1 b_0	Stability criterion	Note
000	no motion detection (always stable)	
001	0,25d	
010	0,5d	
011	1d	
100	2d	1d = 1 scale interval

A/D conversion rate (meas/s)		X
50-Hz rejection	60-Hz rejection	
6,25	7,5	1
12,5	15	2
25	30	3
50	60	5
100	120	9
200	240	17
400	480	33
800	960	65
1600	1920	129

14.2.7 Decimal point position

Although **eNod4** measurements are integer values it is however possible to store a 'decimal point position' so as to design a display related to the application. Its value represents the number of decimal digits. If the variable is set to Zero, it means that decimal point is not used.

Note: the decimal point is directly integrated to SCMBus protocol frames (see § SCMBus).

Admitted values: from 0 up to 7.

14.2.8 Weight unit

It is possible to store the display weight unit into the **eNod4**.

In **transmitter mode**, weight unit is a combination of 4 characters and there is no automatic calculation to adjust weight values if modified.

In **belt mode**, following values are permitted for weight unit parameter:

- gram (**g**)
- kilogram (**kg**)
- ton (**t**)

Note: the unit is directly integrated to SCMBus protocol frames (see § SCMBus).

14.2.9 Flow rate time unit

It is possible to store the display *flow rate time unit* into the **eNod4**.

Flow rate time unit is a combination of 2 characters and there is no automatic calculation to adjust flow rate value if modified.

In belt mode, following values are permitted for *flow rate time unit* parameter:

- second (**s**)
- hour (**h**)

Note: *weight and flow rate time units* lead **eNod4** to handle the following flow rate units:

- Gram per second (**g/s**)
- Kilogram per second(**kg/s**)
- Kilogram per hour (**kg/h**)
- Ton per hour (**t/h**)

14.2.10 Save Tare and Zero in non-volatile memory

There are two options for saving TARE or ZERO request value in non-volatile memory. These options are accessible through the “dosing cycle options” Object.

15 BELT OPERATING MODES

Name	Modbus address	EtherNet/IP Class/Attribut (hex/dec)	Profinet Record Index	Profinet cycliques Req Code	EtherCAT index/sub-index	Type	Access
Weight quantity per pulse on logical output	0x0057	0x69/1	0x008D	R : 0x02AE W : 0x02AF	0x4700 / 0x02	Uint	RW
Average flow rate/speed determination depth	0x0059	0x69/3	0x0072	R : 0x0278 W : 0279	0x4703 / 0x09	Uint	RW
Minimum weight to totalize x100	0x005B	0x69/4	0x0073	R : 0x027A W : 0x027B	0x4700 / 0x06	Uint	RW
Conveyor starting alarm duration	0x005C	0x69/5	0x0074	R : 0x027C W : 0x027D	0x4702 / 0x04	Uint	RW
Conveyor routing material time	0x005D	0x69/6	0x0075	R : 0x027E W : 0x027F	0x4702 / 0x05	Uint	RW
Conveyor speed stabilization time	0x005E	0x69/7	0x0077	R : 0x0282 W : 0x0283	0x4702 / 0x06	Uint	RW
Cycle and alarm options	0x005F	0x69/8	0x0076	R : 0x0280 W : 0x0281	0x4700 / 0x01	Uint	RW
Nominal flow rate	0x0060	0x69/9	0x008C	R : 0x04AC W : 0x04AD	0x4701 / 0x02	Float	RW
Min permissible flow rate	0x0062	0x69/10	0x0082	R : 0x0298 W : 0x0299	0x4701 / 0x04	Uint	RW
Max permissible flow rate	0x0063	0x69/11	0x0083	R : 0x029A W : 0x029B	0x4701 / 0x05	Uint	RW
Instant flow rate correction factor	0x002C	0x69/2	0x0071	R : 0x0476 W : 0x0477	0x4701 / 0x03	Float	RW
Dynamic conveyor zero band	0x0064	0x69/12	0x00AA	R : 0x0200 W : 0x0201	0x4702 / 0x08	Uint	RW
User fixed belt speed x100	0x0067	0x69/13	0x007D	R : 0x028E W : 0x028F	0x4703 / 0x01	Uint	RW
Weight section length	0x0068	0x69/14	0x0079	R : 0x0286 W : 0x0287	0x4702 / 0x07	Uint	RW
Belt number of revolutions	0x0069	0x69/15	0x007A	R : 0x0288 W : 0x0289	0x4702 / 0x03	Uint	RW
Belt total length	0x006A	0x69/16	0x0078	R : 0x0484 W : 0x0485	0x4702 / 0x01	Float	RW
Max permissible flow rate control output	0x006C	0x69/17	0x0085	R : 0x029E W : 0x029F	0x4701 / 0x09	Uint	RW
Min permissible flow rate control output	0x006D	0x69/18	0x0084	R : 0x029C W : 0x029D	0x4701 / 0x08	Uint	RW

<i>Name</i>	<i>Modbus address</i>	<i>EtherNet/IP Class/Attribut (hex/dec)</i>	<i>Profinet Record Index</i>	<i>Profinet cycliques Req Code</i>	<i>EtherCAT index/sub-index</i>	<i>Type</i>	<i>Access</i>
Belt inclination x100	0x006E	0x69/19	0x007B	R : 0x028A W : 0x028B	0x4702 / 0x02	Uint	RW
Flow rate/belt load control inhibit time at start	0x006F	0x69/20	0x0086	R : 0x02A0 W : 0x02A1	0x4701 / 0x06	Uint	RW
Flow rate/belt load control inhibit time in service	0x0070	0x69/21	0x0087	R : 0x02A2 W : 0x02A3	0x4701 / 0x07	Uint	RW
Speed sensor maximum number of pulses per meter	0x0071	0x69/22	0x008E	R : 0x02B0 W : 0x02B1	0x4703 / 0x02	Uint	RW
Speed determination time factor	0x0072	0x69/23	0x0088	R : 0x02A4 W : 0x02A5	0x4703 / 0x03	Uint	RW
Nominal belt speed x100	0x0073	0x69/24	0x007C	R : 0x028C W : 0x028D	0x4703 / 0x04	Uint	RW
Min permissible belt speed	0x0074	0x69/25	0x007E	R : 0x0290 W : 0x0291	0x4703 / 0x05	Uint	RW
Max permissible belt speed	0x0075	0x69/26	0x007F	R : 0x0292 W : 0x0293	0x4703 / 0x06	Uint	RW
Belt speed control inhibit time at start	0x0076	0x69/27	0x0080	R : 0x0294 W : 0x0295	0x4703 / 0x07	Uint	RW
Belt speed control inhibit time in service	0x0077	0x69/28	0x0081	R : 0x0296 W : 0x0297	0x4703 / 0x08	Uint	RW
Weight to totalize (Great WU)	0x0078	0x69/29	0x0089	R : 0x04A6 W : 0x04A7	0x4700 / 0x03	Ulong	RW
Complementary weight to totalize	0x007A	0x69/30	0x008A	R : 0x02A8 W : 0x02A9	0x4700 / 0x04	Uint	RW
Weight to totalize inflight value	0x007B	0x69/31	0x008B	R : 0x04AA W : 0x04AB	0x4700 / 0x05	long	RW
Calibration point 1 for the control output (output value)	0x0A00	0x69/37	0x0090	R : 0x02B4 W : 0x02B5	0x470A / 0x01	Uint	RW
Calibration point 2 for the control output (output value)	0x0A01	0x69/38	0x0091	R : 0x02B6 W : 0x02B7	0x470A / 0x02	Uint	RW
Calibration point 3 for the control output (output value)	0x0A02	0x69/39	0x0092	R : 0x02B8 W : 0x02B9	0x470A / 0x03	Uint	RW
Calibration point 4 for the control output (output value)	0x0A03	0x69/40	0x0093	R : 0x02BA W : 0x02BB	0x470A / 0x04	Uint	RW
Calibration point 5 for the control output (output value)	0x0A04	0x69/41	0x0094	R : 0x02BC W : 0x02BD	0x470A / 0x05	Uint	RW
Calibration point 6 for the control output (output value)	0x0A05	0x69/42	0x0095	R : 0x02BE W : 0x02BF	0x470A / 0x06	Uint	RW
Calibration point 7 for the control output (output value)	0x0A06	0x69/43	0x0096	R : 0x02C0 W : 0x02C1	0x470A / 0x07	Uint	RW

<i>Name</i>	<i>Modbus address</i>	<i>EtherNet/IP Class/Attribut (hex/dec)</i>	<i>Profinet Record Index</i>	<i>Profinet cycliques Req Code</i>	<i>EtherCAT index/sub-index</i>	<i>Type</i>	<i>Access</i>
Calibration point 8 for the control output (output value)	0x0A07	0x69/44	0x0097	R : 0x02C2 W : 0x02C3	0x470A / 0x08	Uint	RW
Calibration point 9 for the control output (output value)	0x0A08	0x69/45	0x0098	R : 0x02C6 W : 0x02C7	0x470A / 0x09	Uint	RW
Calibration point 10 for the control output (output value)	0x0A09	0x64/46	0x0099	R : 0x02C8 W : 0x02C9	0x470A / 0x0A	Uint	RW
Calibration point 1 of the control output (flow rate value) corresponding to value of the control output	0x0A0A	0x69/47	0x009A	R : 0x04CA W : 0x04CB	0x470B / 0x01	Float	RW
Calibration point 2 of the control output (flow rate value) corresponding to value of the control output	0x0A0C	0x69/48	0x009B	R : 0x04CC W : 0x04CD	0x470B / 0x02	Float	RW
Calibration point 3 of the control output (flow rate value) corresponding to value of the control output	0x0A0E	0x69/49	0x009C	R : 0x04CE W : 0x04CF	0x470B / 0x03	Float	RW
Calibration point 4 of the control output (flow rate value) corresponding to value of the control output	0x0A10	0x69/50	0x009D	R : 0x04D0 W : 0x04D1	0x470B / 0x04	Float	RW
Calibration point 5 of the control output (flow rate value) corresponding to value of the control output	0x0A12	0x69/51	0x009E	R : 0x04D2 W : 0x04D3	0x470B / 0x05	Float	RW
Calibration point 6 of the control output (flow rate value) corresponding to value of the control output	0x0A14	0x69/52	0x009F	R : 0x04D4 W : 0x04D5	0x470B / 0x06	Float	RW
Calibration point 7 of the control output (flow rate value) corresponding to value of the control output	0x0A16	0x69/53	0x00A0	R : 0x04D6 W : 0x04D7	0x470B / 0x07	Float	RW
Calibration point 8 of the control output (flow rate value) corresponding to value of the control output	0x0A18	0x69/54	0x00A1	R : 0x04D8 W : 0x04D9	0x470B / 0x08	Float	RW
Calibration point 9 of the control output (flow rate value) corresponding to value of the control output	0x0A1A	0x69/55	0x00A2	R : 0x04DA W : 0x04DB	0x470B / 0x09	Float	RW
Calibration point 10 of the control output (flow rate value) corresponding to value of the control output	0x0A1C	0x69/56	0x00A3	R : 0x04DC W : 0x04DD	0x470B / 0x0A	Float	RW
Segments number for the Calibration curve of the control output	0x0A1E	0x69/36	0x008F	R : 0x02B2 W : 0x02B3	0x4709 / 0x00	Uint	RW

Name	Modbus address	EtherNet/IP Class/Attribut (hex/dec)	Profinet Record Index	Profinet cycliques Req Code	EtherCAT index/sub-index	Type	Access
Weigh frame zero reference	0x0A31	0x69/35	0x00AE	R : 0x044A W : 0x044B	0x4702 / 0x0B	Float	RW
Min permissible belt load	0x0A33	0x69/32	0x00AB	R : 0x0202 W : 0x0203	0x4702 / 0x09	Uint	RW
Max permissible belt load	0x0A34	0x69/33	0x00AC	R : 0x0204 W : 0x0205	0x4702 / 0x0A	Uint	RW
Kp	0x0A35	0x69/57	0x00A4	R : 0x04DE W : 0x04DF	0x470C / 0x01	Float	RW
Ti	0x0A37	0x69/58	0x00A5	R : 0x04E0 W : 0x04E1	0x470C / 0x02	Ulong	RW
Td	0x0A39	0x69/59	0x00A6	R : 0x04E2 W : 0x04E3	0x470C / 0x03	Ulong	RW
PID behavior	0x0A3B	0x69/60	0x00A7	R : 0x02E4 W : 0x02E5	0x470C / 0x04	Uint	RW
Reference flow rate for PID adjustment	0x0A3C	0x69/61	0x00A8	R : 0x04E6 W : 0x04E7	0x470C / 0x05	Float	RW
Checked batch	0x0A3E	0x69/34	0x00AD	R : 0x040C W : 0x040D	0x4700 / 0x07	Ulong	RW
Belt fault control inhibit time at start	0x0A50	0x69/62	0x00E1	R : 0x02F8 W : 0x02F9	0x4703 / 0x0A	Uint	RW
Belt fault control inhibit time in service	0x0A51	0x69/63	0x00E2	R : 0x02FA W : 0x02FB	0x4703 / 0x0B	Uint	RW
Cut-off frequency for average flow rate (x100)	0x0A52	0x69/64	0x00E3		0x4701 / 0x0A	Uint	RW
Time unit for average flow rate	0x0A53	0x69/65	0x00E4		0x4701 / 0x0B	Uint	RW
Weight unit for average flow rate	0x0A54	0x69/66	0x00E5		0x4701 / 0x0C	Ulong	RW
Instant flow rate	0x0086	/	0x00C0	R: 0x040E W: / + See modules list	0x5005 / 0x01 (M)	Float	RO
Average flow rate	0x0088	/	0x00B0	R: 0x046E W: / + See modules list	0x5005 / 0x02 (M)	Float	RO
Average belt speed	0x008A	/	0x00B8	R: 0x04F8 W: / + See modules list	0x5005 / 0x04 (M)	Float	RO
Belt alarms registers	0x008C	/	0x00BB	R: 0x02FE W: / + See modules list	0x5007 / 0x01 (M)	Uint	RO

Name	Modbus address	EtherNet/IP Class/Attribut (hex/dec)	Profinet Record Index	Profinet cycliques Req Code	EtherCAT index/sub-index	Type	Access
Totalizer value (Great WU)	0x008D	/	0x00B4	R: 0x04F0 W: / + See modules list	0x5006 / 0x01 (M)	Ulong	RO
Complementary totalizer value	0x008F	/	0x00B5	R: 0x02F2 W: / + See modules list	0x5006 / 0x02 (M)	Uint	RO
Dosing weight deviation	0x0095	/	0x00B9	R: 0x04FA W: / + See modules list	0x5007 / 0x04 (M)	Float	RO
Flow rate control output	0x009A	/	0x00B1	R: 0x04EA W: / + See modules list	0x5005 / 0x05 (M)	Float	RO
Dosing quality factor	0x009C	/	/	/	0x5005 / 0x07 (M)	Float	RO
Errors counter	0x009E	/	0x00BC	R: 0x023E W: / + See modules list	0x5007 / 0x03 (M)	Uint	RO
Weigh frame load	0x009F	/	0x00BD	R: 0x0406 W: /	0x5005 / 0x03 (M)	Float	RO
Control output value	0x00A1	/	0x00B2	R: 0x02EC W: / + See modules list	0x5005 / 0x06 (M)	Uint	RO
Belt status register	0x00A3	/	0x00BA	R: 0x02FC W: / + See modules list	0x5007 / 0x02 (M)	Uint	RO
Total per belt revolution	0x00A4	/	0x00BF	R: 0x040A W: / + See modules list	0x5006 / 0x03 (M)	Float	RO
Average flow rate Great Unit	0x00A6	/	0x00B3	R: 0x04EE W: /	0x5005 / 0x08 (M)	Float	RO
Batch progression in percent	0x00A8	/	0x00BE	R: 0x0208 W: / + See modules list	0x5006 / 0x04 (M)	Uint	RO
Grand total	0x00A9	/	0x00B6	R: 0x04F4 W: / + See modules list	0x5006 / 0x05 (M)	Ulong	RO
General total	0x00AB	/	0x00B7	R: 0x04F6 W: / + See modules list	0x5006 / 0x06 (M)	Ulong	RO

15.1 Settings description

- **Weight quantity per pulse on logical output:** For external totalization purpose, *eNod4* sends a pulse on logical output when the total value reaches multiple of this parameter. When an overflow is occurred on pulses output an alarm is set.
- **Average flow rate/speed determination depth:** Defines the samples “n” numbers for moving average filter on flow rate and belt speed.
- **Minimum weight to totalize:** *eNod4* enables totalization when “minimum weight to totalize” divided by “weight section length” is greater than the **minimum load to totalize**.
- **Conveyor starting alarm duration:** For security reason, *eNod4* provides buzzer function on logical output at belt start. The buzzer duration depends on this parameter value in second.
- **Conveyor routing material time:** Defines time for materials to travel distance from shear gate to weigh section at normal speed.
- **Conveyor speed stabilization time:** In weigh feeder mode and if PID function is done through the belt speed, this is the stabilization time before PID activation.
- **Cycle and alarm options:** This register defines cycle and alarms functioning. The table below shows the bits definitions.

• bits	Function	Note
bit b0	PID activation ON/OFF	
0	<i>PID function inhibited</i>	<i>In weigh feeder mode if batch option</i>
1	<i>PID function activated</i>	
bits b2 b1	feeder regulation function	
01	<i>Through materials flow</i>	<i>In weigh feeder mode</i>
10	<i>Through conveyor speed</i>	
bit b3	Batch activation ON/OFF	
0	<i>Batch dosing not activated</i>	
1	<i>Batch dosing activated</i>	
bit b4	Clear totalization at start cycle option	
0	<i>Clear totalization at start cycle not activated</i>	
1	<i>Clear totalization at start cycle activated</i>	
bit b5	Auto-stop conveyor at end batch	
0	<i>Auto-stop conveyor at end batch not activated</i>	
1	<i>Auto-stop conveyor at end batch activated</i>	
bit b6	Dynamic zero auto-correction	
0	<i>Dynamic zero auto-correction not activated</i>	
1	<i>Dynamic zero auto-correction activated</i>	
bit b7	Reserved(do not used)	
/	/	
bit b8	Totalization function if alarm occurred	
0	<i>Totalization continuously running if alarm occurred</i>	
1	<i>Stop totalization function if alarm occurred</i>	
bit b9	Save Tare in non-volatile memory	
0	<i>Save tare in volatile memory (RAM)</i>	
1	<i>Save tare in non-volatile memory (FRAM)</i>	
bit b10	Save Zero in non-volatile memory	
0	<i>Save zero in volatile memory (RAM)</i>	
1	<i>Save zero in non-volatile memory (FRAM)</i>	
bits b15b11	Reserved	
/	/	

- **Nominal flow rate:** Set point flow rate expressed in **weight unit per time unit**. **eNod4** determines **nominal belt load** from **nominal speed** and **nominal flow rate**.

- **Min permissible flow rate:** Minimum value for flow rate for alarm function. Expressed in 0.1% of nominal flow rate.
- **Max permissible flow rate:** Maximum value for flow rate for alarm function. Expressed in 0.1% of nominal flow rate.
- **Instant flow rate correction factor:** Correction factor to apply after material test.
- **Dynamic conveyor zero band:** Defines limit values for dynamic zero correction function. Zero function is cancelled when the weight is out of these limits.
- **User fixed belt speed x100:** Defines the belt speed in **m/s** if no speed sensor is connected to **eNod4**. The value of 500 corresponds to 5 m/s.
- **Weight section length:** Represents the effective belt weigh frame length expressed in millimeters.
- **Belt number of revolutions:** Specifies the real belt revolutions to realize during speed/length calibrations and dynamic zero procedure.
- **Belt total length:** Defines the total length of the belt in meters.
- **Max permissible flow rate control output:** Maximum value for control output for alarm function. Expressed in 0.1% of nominal flow rate.
- **Min permissible flow rate control output:** Minimum value for control output for alarm function. Expressed in 0.1% of nominal flow rate.
- **Belt inclination x100:** Defines the belt title angle in degrees. The value of 1500 corresponds with inclination of 15 degrees.
- **Flow rate/belt load controls inhibit time at start:** Monitoring the flow rate or belt load is only activated after this delay time when the belt is started. It is expressed in second.
- **Flow rate/belt load controls inhibit time in service:** When the flow rate or belt load is below/above the min/max value, the alarm is activated after this delay elapsed. It is expressed in second.
- **Speed sensor maximum number of pulses per meter:** Defines constant maximum pulses number of speed sensor.
- **Speed determination time factor:** Specifies the belt speed determination time in multiple of 250ms.
- **Nominal belt speed x100:** Defines the nominal speed in **m/s** and the value of 500 corresponds to 5 m/s. **eNod4** determines **nominal belt load** from **nominal speed** and **nominal flow rate**.
- **Min permissible belt speed:** Minimum value for belt speed for alarm function.
- **Max permissible belt speed:** Maximum value for belt speed for alarm function.
- **Belt speed control inhibit time at start:** Inhibition time at belt start of speed monitoring in second.
- **Belt speed control inhibit time in service:** Inhibition time in service of speed monitoring in second.
- **Weight to totalize (Great WU):** The main part of batch target in **weight unit** x1000.
- **Complementary weight to totalize:** The complementary part of batch target in **weight unit**.
- **Weight to totalize inflight value:** The batch target inflight value in **weight unit**.
- **Calibration point n for the control output (output value):** Expressed in 0.01% of maximum output current or voltage. Up to 10 calibrations points can be configured. See calibration of flow rate section.
- **Calibration point n of the control output (flow rate value):** Expressed in **weight unit** per **time unit**. Up to 10 calibrations points can be configured. See calibration of flow rate section.

- **Segments number for the Calibration curve of the control output:** Defines calibration number of points of flow rate and output value.
- **Weigh frame zero reference:** reference value for zero per length unit. *eNod4* determines this value during dynamic zero procedure.
- **Min permissible belt load:** Minimum value for belt load for alarm function.
- **Max permissible belt load:** Maximum value for belt load for alarm function.
- **Kp:** A proportional controller (Kp) will have the effect of reducing the rise time and will reduce but never eliminate the steady-state error.
- **Ti:** An integral control (Ti) will have the effect of eliminating the steady-state error for a constant or step input, but it may make the transient response slower.
- **Td:** A derivative control (Td) will have the effect of increasing the stability of the system, reducing the overshoot, and improving the transient response.
- **PID behavior:** *eNod4* allows auto-adjustment of PID parameters (kp, Ti and Td). The PID behavior (fast or stable) must be set before to realize an auto-adjustment.
- **Reference flow rate for PID adjustment:** This is the reference flow rate value for auto-adjustment. It must be set before sending adjustment command.
- **Checked batch:** After material test, user must fill in this register the real batch measuring by measurement instrument before sending flow rate correction command.
- **Instant flow rate:** Instant flow rate expressed in **weight unit** per **time unit** and based on current belt load and speed.
- **Average flow rate:** The flow rate result of moving average filter on “n” Instant flow rate samples and low-pass filter. It has its own unity for external display purpose (remote display or HMI).
- **Average belt speed:** The speed result of moving average filter on “n” Instant belt speed samples.
- **Belt alarms registers:** This register defines the status of alarms. The table below shows the bits definitions.

<i>b₁₅ ... b₀</i> <i>bits set to 1</i>	<i>Meaning</i>
<i>b₀</i>	<i>Instant flow rate > Max permissible flow rate</i>
<i>b₁</i>	<i>Instant flow rate < Min permissible flow rate</i>
<i>b₂</i>	<i>Instant belt speed > Max permissible speed</i>
<i>b₃</i>	<i>Instant belt speed < Min permissible speed</i>
<i>b₄</i>	<i>Instant belt load > Max permissible belt load</i>
<i>b₅</i>	<i>Instant belt load < Min permissible belt load</i>
<i>b₆</i>	<i>Control output value > Max permissible control output</i>
<i>b₇</i>	<i>Control output value < Min permissible control output</i>
<i>b₈</i>	<i>Conveyor starting alarm flag</i>
<i>b₉</i>	<i>Conveyor calibration in progress</i>
<i>b₁₀</i>	<i>External totalizer output overflow</i>
<i>b₁₅ ... b₁₁</i>	<i>Reserved (0)</i>

- **Totalizer value (Great WU):** Main totalization result in **weight unit** x1000.

- **Complementary totalizer value:** Complementary totalization result in **weight unit**.
- **Dosing weight deviation:** This represents the weight deviation of belt system at current flow rate and at nominal flow rate.
- **Flow rate control output:** This is the flow rate to control extraction module (feeder or conveyor motors). Expressed in **weight unit per time unit**, it can be the fixed value or output of PID function if enabled.
- **Dosing quality factor:** Represents the standard deviation on “n” successive instant flow rate
- **Errors counter:** Each error occurred during totalization cycle is recognized in this register. Errors counter is set to zero at power up or at receiving of clear totalization command.
- **Weight frame load unit:** The weight per length unit is the effective load on the **weight section**.
- **Control output value:** This value expressed in 0.01% of maximum output current or voltage is to control the analog output.
- **Belt status register:** This register defines the status of belt system. The table below shows the bits definitions.

<i>b₁₅ ... b₀</i>	<i>Meaning</i>
<i>b₇ ... b₀ (LSB)</i>	<i>Dosing step</i>
1	<i>Stop</i>
3	<i>Material routing time</i>
5	<i>Conveyor starting alarm initialization</i>
7	<i>Conveyor starting alarm running</i>
9	<i>Flow rate stabilization time</i>
10	<i>Conveyor last revolution to stop</i>
12	<i>Batch in progress</i>
13	<i>Batch initialization</i>
32	<i>Batch suspended</i>
128	<i>PID coefficients auto-adjustment</i>
<i>b₁₅ ... b₈ (MSB) bits set to 1</i>	<i>Status</i>
b₈	<i>Belt system is running</i>
b₉	<i>Material TOR gate</i>
b₁₀	<i>Minimum totalization load targeted</i>
b₁₁	<i>Conveyor in dynamic zero band</i>
b₁₂	<i>Dynamic zero function in progress</i>
b₁₃	<i>Faulty dynamic zero function</i>
b₁₄	<i>Batch in progress</i>
b₁₅	<i>Batch result available</i>

- **Total per belt revolution:** Represents the amount of materials going through the belt conveyor scale at each revolution. The value is expressed in **weight unit** and is refreshed at each revolution. In perfect belt system, after dynamic zero procedure, the total per revolution is set to zero when the conveyor is running empty.
- **Average flow rate Great Unit:** This is the average flow rate value in 0.001% of weight unit per time unit.
- **Batch progression in percent:** Represents the global view progression in percent of batch process.
- **Grand total (Great Unit):** High level totalization result expressed in **weight unit** x1000. This totalization result can be separately set to zero with **Clear Great total** functional command. The data of this totalizer is being permanently backed up after modification.
- **General total (Great Unit):** High level totalization result expressed in **weight unit** x1000. This totalization result can be separately set to zero with **Clear General total** functional command. The data of this totalizer is being permanently backed up after modification.

16 PROFINET IO

<i>Chapter</i>	<i>Name</i>	<i>Access</i>	<i>Size in bytes</i>	<i>Standard for Read Write Parameter via Profinet RPC Record Index</i>	<i>Substitute for Read Parameters via Profinet Cyclic Transaction Req</i>	<i>Substitute for Write Parameters via Profinet Cyclic Transaction Req</i>
Legal for trade	Legal for trade switch and version	RW	2	0x0010	0x0210	0x0211
Legal for trade	Legal for trade counter	RO	2	0x0011	0x0212	/
Legal for trade	Legal for trade checksum	RO	2	0x0012	0x0214	/
Legal for trade	Zero functions	RW	2	0x0013	0x0216	0x0217
Legal for trade	Stability criterion / decimal point position	RW	2	0x0014	0x0218	0x0219
Legal for trade	Weight unit	RW	4	0x0015	0x041A	0x041B
Legal for trade	Flow time unit	RW	2	0x0016	0x021E	0x021F
Calibration	Maximum capacity	RW	4	0x0020	0x0420	0x0421
Calibration	Number of calibration segments	RW	2	0x0021	0x0222	0x0223
Calibration	Calibration load 1	RW	4	0x0022	0x0424	0x0425
Calibration	Calibration load 2	RW	4	0x0023	0x0426	0x0427
Calibration	Calibration load 3	RW	4	0x0024	0x0428	0x0429
Calibration	Sensor sensitivity	RW	4	0x0025	0x042A	0x042B
Calibration	Scale interval	RW	2	0x0026	0x022C	0x022D
Calibration	Zero calibration	RW	4	0x0027	0x0434	0x0435
Calibration	Span adjusting coefficient	RW	4	0x0028	0x042E	0x042F
Calibration	Calibration place g value	RW	4	0x0029	0x0430	0x0431
Calibration	Place of use g value	RW	4	0x002A	0x0432	0x0433
Calibration	Span coefficient 1	RW	4	0x002B	0x0436	0x0437
Calibration	Span coefficient 2	RW	4	0x002C	0x0438	0x0439
Calibration	Span coefficient 3	RW	4	0x002D	0x043A	0x043B
Calibration	Zero offset	RW	4	0x002E	0x0472	0x0473
Filter	A/D conversion rate	RW	2	0x0030	0x0240	0x0241
Filter	Low-pass order / filters activation	RW	2	0x0031	0x0242	0x0243
Filter	Low-pass cut-off frequency	RW	2	0x0032	0x0244	0x0245
Filter	Band-stop high cut-off frequency	RW	2	0x0033	0x0246	0x0247
Filter	Band-stop low cut-off frequency	RW	2	0x0034	0x0248	0x0249
Filter	Depth of moving average filter on weight	RW	2	0x0070	0x0274	0x0275
I/O	Logical inputs 1&2 functioning	RW	2	0x0040	0x0250	0x0251

I/O	holding time	RW	2	0x0041	0x0252	0x0253
I/O	Logical inputs 3&4 functioning (optional)	RW	2	0x0042	0x026A	0x026B
I/O	Outputs 1 & 2 functioning	RW	2	0x0050	0x0254	0x0255
I/O	Outputs 3 & 4 functioning	RW	2	0x0051	0x0256	0x0257
I/O	Set point 1 high value	RW	4	0x0052	0x045A	0x045B
I/O	Set point 1 low value	RW	4	0x0053	0x045C	0x045D
I/O	Set point 2 high value	RW	4	0x0054	0x045E	0x045F
I/O	Set point 2 low value	RW	4	0x0055	0x0460	0x0461
I/O	Set point 3 high value	RW	4	0x0056	0x0462	0x0463
I/O	Set point 3 low value	RW	4	0x0057	0x0464	0x0465
I/O	Set point 4 high value	RW	4	0x0058	0x0466	0x0467
I/O	Set point 4 low value	RW	4	0x0059	0x0468	0x0469
I/O	Set points functioning	RW	2	0x005A	0x0258	0x0259
I/O	Analog output functioning (optional)	RW	2	0x005B	0x026C	0x026D
I/O	Defective measurement debounced time	RW	2	0x005D	0x02EC	0x02ED
I/O	Defective measurement alarm activation time	RW	2	0x005E	0x02EE	0x02EF
I/O	External value to control analog output	RW	2	0x005C	0x023C	0x023D
Measurement	Tare value	RO	4	0x0060	0x0470	/
Measurement	Preset tare value	RW	4	0x0061	0x04C4	0x04C5
Measurement	Sensor input control reference	RW	4	0x0062	0x044C	0x044D
Measurement	Sensor input control result	RO	2	0x0063	0x024E	/
Measurement	Sensor input control result max. tolerance	RW	2	0x0064	0x0206	0x0207
Belt	Instant flow rate correction factor	RW	4	0x0071	0x0476	0x0477
Belt	Average flow rate/speed determination depth	RW	2	0x0072	0x0278	0x0279
Belt	Minimum weight to totalize x100	RW	2	0x0073	0x027A	0x027B
Belt	Conveyor starting alarm duration	RW	2	0x0074	0x027C	0x027D
Belt	Conveyor routing material time	RW	2	0x0075	0x027E	0x027F
Belt	Cycle and alarm options	RW	2	0x0076	0x0280	0x0281
Belt	Conveyor speed stabilization time	RW	2	0x0077	0x0282	0x0283
Belt	Belt total length	RW	4	0x0078	0x0484	0x0485
Belt	Weight section length	RW	2	0x0079	0x0286	0x0287
Belt	Belt number of revolutions	RW	2	0x007A	0x0288	0x0289
Belt	Belt inclination x100	RW	2	0x007B	0x028A	0x028B
Belt	Nominal belt speed x100	RW	2	0x007C	0x028C	0x028D
Belt	User fixed belt speed x100	RW	2	0x007D	0x028E	0x028F

Belt	Min permissible belt speed	RW	2	0x007E	0x0290	0x0291
Belt	Max permissible belt speed	RW	2	0x007F	0x0292	0x0293
Belt	Belt speed control inhibit time at start	RW	2	0x0080	0x0294	0x0295
Belt	Belt speed control inhibit time in service	RW	2	0x0081	0x0296	0x0297
Belt	Min permissible instant flow rate	RW	2	0x0082	0x0298	0x0299
Belt	Max permissible instant flow rate	RW	2	0x0083	0x029A	0x029B
Belt	Min permissible flow rate control output	RW	2	0x0084	0x029C	0x029D
Belt	Max permissible flow rate control output	RW	2	0x0085	0x029E	0x029F
Belt	Inhibit time of flow rate/load alarms at start	RW	2	0x0086	0x02A0	0x02A1
Belt	Inhibit time of flow rate/load alarms in service	RW	2	0x0087	0x02A2	0x02A3
Belt	Speed determination time factor	RW	2	0x0088	0x02A4	0x02A5
Belt	Weight to totalize (weight unit x1000)	RW	4	0x0089	0x04A6	0x04A7
Belt	Complementary weight to totalize	RW	2	0x008A	0x02A8	0x02A9
Belt	Weight to totalize inflight value	RW	4	0x008B	0x04AA	0x04AB
Belt	Nominal flow rate	RW	4	0x008C	0x04AC	0x04AD
Belt	Weight quantity per pulse on logical output	RW	2	0x008D	0x02AE	0x02AF
Belt	Speed sensor maximum number of pulses per meter	RW	2	0x008E	0x02B0	0x02B1
Belt	Segments number for the calibration curve of flow rate	RW	2	0x008F	0x02B2	0x02B3
Belt	Calibration point 1 for the control output / analog output	RW	2	0x0090	0x02B4	0x02B5
Belt	Calibration point 2 for the control output / analog output	RW	2	0x0091	0x02B6	0x02B7
Belt	Calibration point 3 for the control output / analog output	RW	2	0x0092	0x02B8	0x02B9
Belt	Calibration point 4 for the control output / analog output	RW	2	0x0093	0x02BA	0x02BB
Belt	Calibration point 5 for the control output / analog output	RW	2	0x0094	0x02BC	0x02BD
Belt	Calibration point 6 for the control output / analog output	RW	2	0x0095	0x02BE	0x02BF
Belt	Calibration point 7 for the control output / analog output	RW	2	0x0096	0x02C0	0x02C1
Belt	Calibration point 7 for the control output / analog output	RW	2	0x0097	0x02C2	0x02C3
Belt	Calibration point 8 for the control output / analog output	RW	2	0x0098	0x02C6	0x02C7
Belt	Calibration point 9 for the control output / analog output	RW	2	0x0099	0x02C8	0x02C9
Belt	Calibration point 10 for the control output / analog output	RW	2	0x0084	0x029C	0x029D
Belt	Calibration point 1 of flow rate	RW	4	0x009A	0x04CA	0x04CB
Belt	Calibration point 2 of flow rate	RW	4	0x009B	0x04CC	0x04CD

Belt	Calibration point 3 of flow rate	RW	4	0x009C	0x04CE	0x04CF
Belt	Calibration point 4 of flow rate	RW	4	0x009D	0x04D0	0x04D1
Belt	Calibration point 5 of flow rate	RW	4	0x009E	0x04D2	0x04D3
Belt	Calibration point 6 of flow rate	RW	4	0x009F	0x04D4	0x04D5
Belt	Calibration point 7 of flow rate	RW	4	0x00A0	0x04D6	0x04D7
Belt	Calibration point 8 of flow rate	RW	4	0x00A1	0x04D8	0x04D9
Belt	Calibration point 9 of flow rate	RW	4	0x00A2	0x04DA	0x04DB
Belt	Calibration point 10 of flow rate	RW	4	0x00A3	0x04DC	0x04DD
Belt	Kp	RW	4	0x00A4	0x04DE	0x04DF
Belt	Ti	RW	4	0x00A5	0x04E0	0x04E1
Belt	Td	RW	4	0x00A6	0x04E2	0x04E3
Belt	PID behavior	RW	2	0x00A7	0x02E4	0x02E5
Belt	PID adjustment Flow rate	RW	4	0x00A8	0x04E6	0x04E7
Protocol and Modes	Functioning mode / Serial protocol	RW	2	0x00A9	0x02E8	0x02E9
Belt	Dynamic conveyor zero band	RW	2	0x00AA	0x0200	0x0201
Belt	Min permissible belt load	RW	2	0x00AB	0x0202	0x0203
Belt	Max permissible belt load	RW	2	0x00AC	0x0204	0x0205
Belt	Checked batch	RW	4	0x00AD	0x040C	0x040D
Belt	Average flow rate	RO	4	0x00B0	0x046E	/
Belt	Flow rate control output	RO	4	0x00B1	0x04EA	/
Belt	Control output value	RO	2	0x00B2	0x02EC	/
Belt	Average flow rate (Great WU)	RO	4	0x00B3	0x04EE	/
Belt	Totalizer value (weight unit x1000)	RO	4	0x00B4	0x04F0	/
Belt	Complementary totalizer value	RO	2	0x00B5	0x02F2	/
Belt	Great total (Great WU)	RO	4	0x00B6	0x04F4	/
Belt	General total (Great WU)	RO	4	0x00B7	0x04F6	/
Belt	Average speed	RO	4	0x00B8	0x04F8	/
Belt	Dosing weight deviation	RO	4	0x00B9	0x04FA	/
Belt	Belt status	RO	2	0x00BA	0x02FC	/
Belt	Alarms register	RO	2	0x00BB	0x02FE	/
Belt	Errors counter	RO	2	0x00BC	0x023E	/
Belt	Weigh frame load	RO	4	0x00BD	0x0406	/
Belt	Batch progression in percent	RO	2	0x00BE	0x0208	/
Belt	Total per belt revolution	RO	4	0x00BF	0x040A	/
Belt	Instant flow rate	RO	4	0x00C0	0x040E	/
Belt	Belt fault control inhibit time at start	RW	2	0x00E1	0x02F8	0x02F9
Belt	Belt fault control inhibit time in service	RW	2	0x00E2	0x02FA	0x02FB
Belt	Cut-off frequency for average flow rate (x100)	RW	2	0x00E3	/	/

Belt	Time unit for average flow rate	RW	2	0x00E4	/	/
Belt	Weight unit for average flow rate	RW	4	0x00E5	/	/
HMI	HMI name	RW	4	0x00E0	/	/

<i>Error Type</i>	<i>Diagnostic Name</i>	<i>Diagnostic Help</i>
4197	<i>Input analog signal out of the A/D conversion range (negative quadrant)</i>	<i>Possible Cause: Short circuit on sensor connection.</i>
4198	<i>Input analog signal out of the A/D conversion range (positive quadrant)</i>	<i>Possible Cause: Short circuit on sensor connection.</i>
4199	<i>Gross meas. < (- max capacity)</i>	<i>Cause: The value of the gross measurement exceeds the opposed maximum capacity minus 9 divisions.</i>
4200	<i>Gross meas. > (max capacity)</i>	<i>Cause: The value of the gross measurement exceeds the maximum capacity plus 9 divisions.</i>
4201	<i>Default EEPROM</i>	<i>Cause: Error of checksum while reading EEPROM after reset.</i>

17 ETHERNET/IP REGISTER MAP

<i>Chapter</i>	<i>Name</i>	<i>EtherNet/IP Class</i>	<i>EtherNet/IP Attribute (dec)</i>	<i>Type</i>	<i>Service</i>
Class 0x64 (100d) / Instance 1					Get Attribute All
Modbus	Firmware revision	0x64	1	Uint	Get Attribute Single
Modbus	Node number / baud rate	0x64	2	Uint	Get Attribute Single
Legal for trade	Legal for trade version	0x64	3	Byte	Get Attribute Single
Legal for trade	Legal for trade switch	0x64	4	Byte	Get Attribute Single / Set Attribute Single
Legal for trade	Legal for trade counter	0x64	5	Byte	Get Attribute Single
Legal for trade	Legal for trade checksum	0x64	6	Uint	Get Attribute Single
Legal for trade	Zero functions	0x64	7	Uint	Get Attribute Single / Set Attribute Single
Legal for trade	Stability criterion	0x64	8 LSB	Byte	Get Attribute Single / Set Attribute Single
Legal for trade	decimal point position	0x64	8 MSB	Byte	Get Attribute Single / Set Attribute Single
Legal for trade	Weight unit	0x64	9	String	Get Attribute Single / Set Attribute Single
Protocols and Modes	Functioning mode	0x64	10	Byte	Get Attribute Single / Set Attribute Single
Legal for trade	Flow time unit	0x64	11	String	Get Attribute Single / Set Attribute Single
HMI	HMI name	0x64	21	String	Get Attribute Single / Set Attribute Single
0x65 (101d) / Instance 1					Get Attribute All / Set Attribute All
Calibration	Maximum capacity	0x65	1	Ulong	Get Attribute Single / Set Attribute Single
Calibration	Number of calibration segments	0x65	2	Uint	Get Attribute Single / Set Attribute Single
Calibration	Calibration load 1	0x65	3	Ulong	Get Attribute Single / Set Attribute Single
Calibration	Calibration load 2	0x65	4	Ulong	Get Attribute Single / Set Attribute Single
Calibration	Calibration load 3	0x65	5	Ulong	Get Attribute Single / Set Attribute Single
Calibration	Sensor sensitivity	0x65	6	Ulong	Get Attribute Single / Set Attribute Single
Calibration	Scale interval	0x65	7	Uint	Get Attribute Single / Set Attribute Single
Calibration	Zero calibration	0x65	8	Long	Get Attribute Single / Set Attribute Single
Calibration	Span coefficient 1	0x65	9	Float	Get Attribute Single / Set Attribute Single
Calibration	Span coefficient 2	0x65	10	Float	Get Attribute Single / Set Attribute Single
Calibration	Span coefficient 3	0x65	11	Float	Get Attribute Single / Set Attribute Single
Calibration	Span adjusting coefficient	0x65	12	Ulong	Get Attribute Single / Set Attribute Single
Calibration	Calibration place g value	0x65	13	Ulong	Get Attribute Single / Set Attribute Single
Calibration	Place of use g value	0x65	14	Ulong	Get Attribute Single / Set Attribute Single
Calibration	Zero offset	0x65	15	Long	Get Attribute Single / Set Attribute Single
State Register	Preset tare value	0x65	16	Ulong	Get Attribute Single / Set Attribute Single
State Register	Sensor input control reference	0x65	17	Long	Get Attribute Single / Set Attribute Single
State Register	Sensor input control result max. tolerance	0x65	18	Uint	Get Attribute Single / Set Attribute Single
0x66 (102d) / Instance 1					Get Attribute All / Set Attribute All

<i>Chapter</i>	<i>Name</i>	<i>EtherNet/IP Class</i>	<i>EtherNet/IP Attribute (dec)</i>	<i>Type</i>	<i>Service</i>
Filter	A/D conversion rate	0x66	1	Uint	Get Attribute Single / Set Attribute Single
Filter	filters activation	0x66	2 LSB	Byte	Get Attribute Single / Set Attribute Single
Fjiter	Low-pass order	0x66	2 MSB	Byte	Get Attribute Single / Set Attribute Single
Filter	Low-pass cut-off frequency	0x66	3	Uint	Get Attribute Single / Set Attribute Single
Filter	Band-stop high cut-off frequency	0x66	4	Uint	Get Attribute Single / Set Attribute Single
Filter	Band-stop low cut-off frequency	0x66	5	Uint	Get Attribute Single / Set Attribute Single
Filter	Moving average filter depth	0x66	6	Uint	Get Attribute Single / Set Attribute Single
<i>Class 0x67 (103d) / Instance 1</i>					<i>Get Attribute All / Set Attribute All</i>
I/O	Logical input 1 functioning	0x67	1 LSB	Byte	Get Attribute Single / Set Attribute Single
I/O	Logical input 2 functioning	0x67	1 MSB	Byte	Get Attribute Single / Set Attribute Single
I/O	holding time	0x67	2	Uint	Get Attribute Single / Set Attribute Single
I/O	Output 1 functioning	0x67	3 LSB	Byte	Get Attribute Single / Set Attribute Single
I/O	Output 2 functioning	0x67	3 MSB	Byte	Get Attribute Single / Set Attribute Single
I/O	Output 3 functioning	0x67	4 LSB	Byte	Get Attribute Single / Set Attribute Single
I/O	Output 4 functioning	0x67	4 MSB	Byte	Get Attribute Single / Set Attribute Single
I/O	Set point 1 high value	0x67	5	Long	Get Attribute Single / Set Attribute Single
I/O	Set point 1 low value	0x67	6	Long	Get Attribute Single / Set Attribute Single
I/O	Set point 2 high value	0x67	7	Long	Get Attribute Single / Set Attribute Single
I/O	Set point 2 low value	0x67	8	Long	Get Attribute Single / Set Attribute Single
I/O	Set point 3 high value	0x67	9	Long	Get Attribute Single / Set Attribute Single
I/O	Set point 3 low value	0x67	10	Long	Get Attribute Single / Set Attribute Single
I/O	Set point 4 high value	0x67	11	Long	Get Attribute Single / Set Attribute Single
I/O	Set point 4 low value	0x67	12	Long	Get Attribute Single / Set Attribute Single
I/O	1&2 Set points functioning	0x67	13 LSB	Byte	Get Attribute Single / Set Attribute Single
I/O	3&4 Set points functioning	0x67	13 MSB	Byte	Get Attribute Single / Set Attribute Single
I/O	Logical input 3 functioning (optional)	0x67	14 LSB	Byte	Get Attribute Single / Set Attribute Single
I/O	Logical input 4 functioning (optional)	0x67	14 MSB	Byte	Get Attribute Single / Set Attribute Single
I/O	Analog output functioning (optional)	0x67	15	Uint	Get Attribute Single / Set Attribute Single
I/O	External value to control analog output	0x67	16	Uint	Get Attribute Single / Set Attribute Single
I/O	Defective measurement debounced time	0x67	17	Uint	Get Attribute Single / Set Attribute Single
I/O	Defective measurement alarm activation time	0x67	18	Uint	Get Attribute Single / Set Attribute Single
I/O	Input level	/	/	Byte	
I/O	Output level	/	/	Byte	

<i>Chapter</i>	<i>Name</i>	<i>EtherNet/IP Class</i>	<i>EtherNet/IP Attribute (dec)</i>	<i>Type</i>	<i>Service</i>
0x68 (104d) / Instance 1					Get Attribute All
Command	command register	0x68	1	Uint	Get Attribute Single / Set Attribute Single
Command	response register	0x68	2	Uint	Get Attribute Single
Command	Input / output levels	0x68	3	Uint	Get Attribute Single
Command	Sensor input control result	0x68	4	Int	Get Attribute Single
0x69 (105d) / Instance 1					Get Attribute All / Set Attribute All
Belt	Weight quantity per pulse on logical output	0x69	1	Uint	Get Attribute Single / Set Attribute Single
Belt	Instant flow rate correction factor	0x69	2	Float	Get Attribute Single / Set Attribute Single
Belt	Average flow rate/Speed determination depth	0x69	3	Uint	Get Attribute Single / Set Attribute Single
Belt	Minimum weight to totalize x100	0x69	4	Uint	Get Attribute Single / Set Attribute Single
Belt	Conveyor starting alarm duration	0x69	5	Uint	Get Attribute Single / Set Attribute Single
Belt	Conveyor routing material time	0x69	6	Uint	Get Attribute Single / Set Attribute Single
Belt	Conveyor speed stabilization time	0x69	7	Uint	Get Attribute Single / Set Attribute Single
Belt	Cycle and alarm options	0x69	8	Uint	Get Attribute Single / Set Attribute Single
Belt	Nominal flow rate	0x69	9	Float	Get Attribute Single / Set Attribute Single
Belt	Min permissible flow rate	0x69	10	Uint	Get Attribute Single / Set Attribute Single
Belt	Max permissible flow rate	0x69	11	Uint	Get Attribute Single / Set Attribute Single
Belt	Dynamic conveyor zero band	0x69	12	Uint	Get Attribute Single / Set Attribute Single
Belt	User fixed belt speed x100	0x69	13	Uint	Get Attribute Single / Set Attribute Single
Belt	Weight section length	0x69	14	Uint	Get Attribute Single / Set Attribute Single
Belt	Belt number of revolutions	0x69	15	Uint	Get Attribute Single / Set Attribute Single
Belt	Belt total length	0x69	16	Float	Get Attribute Single / Set Attribute Single
Belt	Max permissible flow rate control output	0x69	17	Uint	Get Attribute Single / Set Attribute Single
Belt	Min permissible flow rate control output	0x69	18	Uint	Get Attribute Single / Set Attribute Single
Belt	Belt inclination x100	0x69	19	Uint	Get Attribute Single / Set Attribute Single
Belt	Flow rate/load control inhibit time at start	0x69	20	Uint	Get Attribute Single / Set Attribute Single
Belt	Flow rate/load control inhibit time in service	0x69	21	Uint	Get Attribute Single / Set Attribute Single
Belt	Speed sensor maximum number of pulses per meter	0x69	22	Uint	Get Attribute Single / Set Attribute Single
Belt	Speed determination time factor	0x69	23	Uint	Get Attribute Single / Set Attribute Single
Belt	Nominal belt speed x100	0x69	24	Uint	Get Attribute Single / Set Attribute Single
Belt	Min permissible belt speed	0x69	25	Uint	Get Attribute Single / Set Attribute Single
Belt	Max permissible belt speed	0x69	26	Uint	Get Attribute Single / Set Attribute Single
Belt	Belt speed control inhibit time at start	0x69	27	Uint	Get Attribute Single / Set Attribute Single

<i>Chapter</i>	<i>Name</i>	<i>EtherNet/IP Class</i>	<i>EtherNet/IP Attribute (dec)</i>	<i>Type</i>	<i>Service</i>
Belt	Belt speed control inhibit time in service	0x69	28	Uint	Get Attribute Single / Set Attribute Single
Belt	Weight to totalize (weight unit x1000)	0x69	29	Ulong	Get Attribute Single / Set Attribute Single
Belt	Complementary weight to totalize	0x69	30	Uint	Get Attribute Single / Set Attribute Single
Belt	Weight to totalize inflight value	0x69	31	Ulong	Get Attribute Single / Set Attribute Single
Belt	Min permissible belt load	0x69	32	Uint	Get Attribute Single / Set Attribute Single
Belt	Max permissible belt load	0x69	33	Uint	Get Attribute Single / Set Attribute Single
Belt	Checked batch	0x69	34	Ulong	Get Attribute Single / Set Attribute Single
Belt	Weigh frame zero reference	0x69	35	Float	Get Attribute Single / Set Attribute Single
Belt	Segments number for the calibration curve of flow rate	0x69	36	Uint	Get Attribute Single / Set Attribute Single
Belt	Calibration of flow rate point 1 (control output value)	0x69	37	Uint	Get Attribute Single / Set Attribute Single
Belt	Calibration of flow rate point 2 (control output value)	0x69	38	Uint	Get Attribute Single / Set Attribute Single
Belt	Calibration of flow rate point 3 (control output value)	0x69	39	Uint	Get Attribute Single / Set Attribute Single
Belt	Calibration of flow rate point 4 (control output value)	0x69	40	Uint	Get Attribute Single / Set Attribute Single
Belt	Calibration of flow rate point 5 (control output value)	0x69	41	Uint	Get Attribute Single / Set Attribute Single
Belt	Calibration of flow rate point 6 (control output value)	0x69	42	Uint	Get Attribute Single / Set Attribute Single
Belt	Calibration of flow rate point 7 (control output value)	0x69	43	Uint	Get Attribute Single / Set Attribute Single
Belt	Calibration of flow rate point 8 (control output value)	0x69	44	Uint	Get Attribute Single / Set Attribute Single
Belt	Calibration of flow rate point 9 (control output value)	0x69	45	Uint	Get Attribute Single / Set Attribute Single
Belt	Calibration of flow rate point 10 (control output value)	0x69	46	Uint	Get Attribute Single / Set Attribute Single
Belt	Calibration of flow rate point 1 (flow rate value)	0x69	47	Float	Get Attribute Single / Set Attribute Single
Belt	Calibration of flow rate point 2 (flow rate value)	0x69	48	Float	Get Attribute Single / Set Attribute Single
Belt	Calibration of flow rate point 3 (flow rate value)	0x69	49	Float	Get Attribute Single / Set Attribute Single
Belt	Calibration of flow rate point 4 (flow rate value)	0x69	50	Float	Get Attribute Single / Set Attribute Single
Belt	Calibration of flow rate point 5 (flow rate value)	0x69	51	Float	Get Attribute Single / Set Attribute Single
Belt	Calibration of flow rate point 6 (flow rate value)	0x69	52	Float	Get Attribute Single / Set Attribute Single
Belt	Calibration of flow rate point 7 (flow rate value)	0x69	53	Float	Get Attribute Single / Set Attribute Single
Belt	Calibration of flow rate point 8 (flow rate value)	0x69	54	Float	Get Attribute Single / Set Attribute Single

Chapter	Name	EtherNet/IP Class	EtherNet/IP Attribute (dec)	Type	Service
	(flow rate value)				
Belt	Calibration of flow rate point 9 (flow rate value)	0x69	55	Float	Get Attribute Single / Set Attribute Single
Belt	Calibration of flow rate point 10 (flow rate value)	0x69	56	Float	Get Attribute Single / Set Attribute Single
Belt	Kp	0x69	57	Float	Get Attribute Single / Set Attribute Single
Belt	Ti	0x69	58	Ulong	Get Attribute Single / Set Attribute Single
Belt	Td	0x69	59	Ulong	Get Attribute Single / Set Attribute Single
Belt	PID behavior	0x69	60	Uint	Get Attribute Single / Set Attribute Single
Belt	PID adjustment Flow rate	0x69	61	Float	Get Attribute Single / Set Attribute Single
Belt	Belt fault control inhibit time at start	0x69	62	Uint	Get Attribute Single / Set Attribute Single
Belt	Belt fault control inhibit time in service	0x69	63	Uint	Get Attribute Single / Set Attribute Single
Belt	Cut-off frequency for average flow rate (x100)	0x69	64	Uint	Get Attribute Single / Set Attribute Single
Belt	Time unit for average flow rate	0x69	65	Uint	Get Attribute Single / Set Attribute Single
Belt	Weight unit for average flow rate	0x69	66	Ulong	Get Attribute Single / Set Attribute Single

The register “Command register” uses the mechanism of *eNod4* functional commands defined in another chapter.

Note: “reset” and “Restore default settings” commands cannot be sent via cyclic and acyclic exchanges immediately after a restart of *eNod4*. To be able to use these commands, it must first be processed another command (“cancel Tare” for example).

Note: The “Command register” data **must be** set to 0x0000 before each new command.

18 ETHERNET/IP ODVA COMMONLY DEFINED REGISTER MAP

Name	EtherNet/IP Class	EtherNet/IP Attribute	Type	Service
Identity Object Class 0x01 (01a) / Instance 0				Get Attribute All
Class Revision	0x01	1	Uint	Get Attribute Single
Max. Class Instance	0x01	2	Uint	Get Attribute Single
Class Max. Attributes	0x01	6	Uint	Get Attribute Single
Class Max. Instance Attributes	0x01	7	Uint	Get Attribute Single
Identity Object Class 0x01 (01a) / Instance 1				Get Attribute All
Vendor ID	0x01	1	Uint	Get Attribute Single / Reset
Device type	0x01	2	Uint	Get Attribute Single / Reset
Product Code	0x01	3	Uint	Get Attribute Single / Reset
Major Revision / Minor Revision	0x01	4	Uint	Get Attribute Single / Reset
status	0x01	5	Uint	Get Attribute Single / Reset
Serial Number	0x01	6	Ulong	Get Attribute Single / Reset
Length (bytes) / Product Name	0x01	7	string (14 bytes)	Get Attribute Single / Reset
State	0x01	8	byte	Get Attribute Single / Reset
Conf. Consist. Value	0x01	9	Uint	Get Attribute Single / Reset
Heart Interval	0x01	10	Uint	/
Assembly Object Class 0x04 (04a) / Instance 0				
Class Revision	0x04	1	Uint	Get Attribute Single
Max. Class Instance	0x04	2	Uint	Get Attribute Single
Connection Manager Object Class 0x06 (06a) / Instance 0				
Class Revision	0x06	1	Uint	Get Attribute Single
Max. Class Instance	0x06	2	Uint	Get Attribute Single
Connection Manager Object Class 0x06 (06a) / Instance 1				Forward Close / Forward Open
DLR (Device Level Ring) 0x47 (71a) / Instance 0				
Class Revision	0x47	1	Uint	Get Attribute Single
DLR (Device Level Ring) Object Class 0x47 (71a) / Instance 1				Get Attribute All
Network Topology	0x47	1	Byte	Get Attribute Single
Network Status	0x47	2	Byte	Get Attribute Single
Active Supervisor Address	0x47	10	Array of 10 bytes	Get Attribute Single
Capability Flags	0x47	12	Ulong	/
QoS (Quality of Service) Object Class 0x48 (72a) / Instance 0				
Class Revision	0x48	1	Uint	Get Attribute Single
Max. Class Instance	0x48	2	Uint	Get Attribute Single
QoS (Quality of Service) Object Class 0x48 (72d) / Instance 0				
Class Revision	0x48	1	Uint	Get Attribute Single
Max. Class Instance	0x48	2	Uint	Get Attribute Single

Name	EtherNet/IP Class	EtherNet/IP Attribute	Type	Service
QoS (Quality of Service Object Class 0x48 (72_d) / Instance 1				
802.1Q Tag Enable	0x48	1	Byte	Get Attribute Single
DSCP Urgent	0x48	4	Byte	Get Attribute Single
DSCP Scheduled	0x48	5	Byte	Get Attribute Single
DSCP High	0x48	6	Byte	Get Attribute Single
DSCP Low	0x48	7	Byte	Get Attribute Single
DSCP Explicit	0x48	8	Byte	Get Attribute Single
TCP/IP Interface Object Class 0xF5 (245_d) / Instance 0				
Class Revision	0xF5	1	Uint	Get Attribute Single
Max. Class Instance	0xF5	2	Uint	Get Attribute Single
TCP/IP Interface Object Class 0xF5 (245_d) / Instance 1				Get Attribute All
Status	0xF5	1	Ulong	Get Attribute Single
Configuration Capability	0xF5	2	Ulong	Get Attribute Single
Configuration Control	0xF5	3	Ulong	Get Attribute Single
Physical Link Object: Struct Path size Uint Path Padded Epath	0xF5	4	Array of n bytes	Get Attribute Single
Interface Configuration: Struct IP address Uint Network mask Uint Gateway address Uint Name server Uint Name server Ulong Domain name String	0xF5	5	Array of n bytes	Get Attribute Single
Host Name	0xF5	6	Array of n bytes	Get Attribute Single
Safety Network Number	0xF5	7	Array of n bytes	/
Time To Live value	0xF5	8	Array of n bytes	/
Multicast configuration	0xF5	9	Array of n bytes	/
Select ACD	0xF5	10	Array of n bytes	Get Attribute Single (01 _H)
Last Conflict Detected	0xF5	11	Array of n bytes	Get Attribute Single (01 _H)
Ethernet Link Object Class 0xF6 (246_d) / Instance 0				
Class Revision	0xF6	1	Uint	Get Attribute Single
Max. Class Instance	0xF6	2	Uint	Get Attribute Single
Ethernet Link Object Class 0xF6 (246_d) / Instance 1				
Interface Speed	0xF6	1	Ulong	Get Attribute Single
Interface Flags	0xF6	2	Ulong	Get Attribute Single
Physical Address	0xF6	3	Array of 6 bytes	Get Attribute Single
Interface Control	0xF6	6	Ulong	Get Attribute Single
Length (byte) / Interface Label	0xF6	10	string	Get Attribute Single

Note:

- Get attribute All: **0x01**, Get attribute Single: **0x0E**
- Set attribute All: **0x02**, Set Attribute Single: **0x10**
- Reset: **0x05**
- Forward open: **0x54**, Forward close: **0x4E**

19 MODBUS RTU AND MODBUS TCP REGISTERS TABLE

Chapter	Name	Modbus Address	Type	Access
Modbus	Firmware revision	0x0000	Uint	RO
Modbus	Node number / baud rate	0x0001	Uint	RO
Legal for trade	Legal for trade version	0x0004 LSB	Byte	RO
Legal for trade	Legal for trade switch	0x0004 MSB	Byte	RW
Legal for trade	Legal for trade counter	0x0005	Byte	RO
Legal for trade	Legal for trade checksum	0x0006	Uint	RO
Legal for trade	Zero functions	0x0007	Uint	RW
Legal for trade	Stability criterion	0x0008 LSB	Byte	RW
Legal for trade	decimal point position	0x0008 MSB	Byte	RW
Legal for trade	Weight unit	0x0009	String	RW
Calibration	Maximum capacity	0x000C	Ulong	RW
Calibration	Number of calibration segments	0x000E	Uint	RW
Calibration	Calibration load 1	0x000F	Ulong	RW
Calibration	Calibration load 2	0x0011	Ulong	RW
Calibration	Calibration load 3	0x0013	Ulong	RW
Calibration	Sensor sensitivity	0x0015	Ulong	RW
Calibration	Scale interval	0x0017	Uint	RW
Calibration	Zero calibration	0x0018	Long	RW
Calibration	Span coefficient 1	0x001A	Float	RW
Calibration	Span coefficient 2	0x001C	Float	RW
Calibration	Span coefficient 3	0x001E	Float	RW
Calibration	Span adjusting coefficient	0x0020	Ulong	RW
Calibration	Calibration place g value	0x0022	Ulong	RW
Calibration	Place of use g value	0x0024	Ulong	RW
Calibration	Number of divisions at maximum capacity	0x0028	Ulong	RW
Calibration	Instant flow rate correction factor	0x002C	Float	RW
I/O	External value to control analog output	0x0032	Uint	RW
HMI	HMI name	0x0034	String	RW
Filter	A/D conversion rate	0x0036	Uint	RW
Filter	filters activation	0x0037 LSB	Byte	RW
Filter	Low-pass order	0x0037 MSB	Byte	RW
Filter	Low-pass cut-off frequency	0x0038	Uint	RW
Filter	Band-stop high cut-off frequency	0x0039	Uint	RW
Filter	Band-stop low cut-off frequency	0x003A	Uint	RW
Protocol	Functioning mode / Serial protocol	0x003E	Uint	RW

<i>Chapter</i>	<i>Name</i>	<i>Modbus Address</i>	<i>Type</i>	<i>Access</i>
SCMbus	SCMbus transmission period	0x003F	Uint	RW
I/O	Analog output functioning (optional)	0x0040	Uint	RW
I/O	Logical inputs 3 functioning (optional)	0x0041 LSB	Byte	RW
I/O	Logical inputs 4 functioning (optional)	0x0041 MSB	Byte	RW
I/O	Logical input 1 functioning	0x0042 LSB	Byte	RW
I/O	Logical input 2 functioning	0x0042 MSB	Byte	RW
I/O	holding time	0x0043	Uint	RW
I/O	Output 1 functioning	0x0044 LSB	Byte	RW
I/O	Output 2 functioning	0x0044 MSB	Byte	RW
I/O	Output 3 functioning	0x0045 LSB	Byte	RW
I/O	Output 4 functioning	0x0045 MSB	Byte	RW
I/O	Set point 1 high value	0x0046	Long	RW
I/O	Set point 1 low value	0x0048	Long	RW
I/O	Set point 2 high value	0x004A	Long	RW
I/O	Set point 2 low value	0x004C	Long	RW
I/O	Set point 3 high value	0x004E	Long	RW
I/O	Set point 3 low value	0x0050	Long	RW
I/O	Set point 4 high value	0x0052	Long	RW
I/O	Set point 4 low value	0x0054	Long	RW
I/O	1&2 Set points functioning	0x0056 LSB	Byte	RW
I/O	3&4 Set points functioning	0x0056 MSB	Byte	RW
Belt	Weight quantity per pulse on logical output	0x0057	Uint	RW
Filter	Depth of moving average filter on weights	0x0058	Uint	RW
Filter	Average flow rate/Speed determination depth	0x0059	Uint	RW
Belt	Flow rate time unit	0x005A	Uint	RW
Belt	Minimum weight to totalize x100	0x005B	Uint	RW
Belt	Conveyor starting alarm duration	0x005C	Uint	RW
Belt	Conveyor routing material time	0x005D	Uint	RW
Belt	Conveyor speed stabilization time	0x005E	Uint	RW
Belt	Cycle and alarm options	0x005F	Uint	RW
Belt	Nominal flow rate	0x0060	Float	RW
Belt	Min permissible flow rate	0x0062	Uint	RW
Belt	Max permissible flow rate	0x0063	Uint	RW
Belt	Dynamic conveyor zero band	0x0064	Uint	RW
Belt	User fixed belt speed x100	0x0067	Uint	RW
Belt	Weight section length	0x0068	Uint	RW
Belt	Belt number of revolutions	0x0069	Uint	RW
Belt	Belt total length	0x006A	Float	RW

<i>Chapter</i>	<i>Name</i>	<i>Modbus Address</i>	<i>Type</i>	<i>Access</i>
Belt	Max permissible flow rate control output	0x006C	Uint	RW
Belt	Min permissible flow rate control output	0x006D	Uint	RW
Belt	Belt inclination x100	0x006E	Uint	RW
Belt	Flow rate/load control inhibit time at start	0x006F	Uint	RW
Belt	Flow rate/load control inhibit time in service	0x0070	Uint	RW
Belt	Speed sensor maximum number of pulses per meter	0x0071	Uint	RW
Belt	Speed determination time factor	0x0072	Uint	RW
Belt	Nominal belt speed	0x0073	Uint	RW
Belt	Min permissible belt speed	0x0074	Uint	RW
Belt	Max permissible belt speed	0x0075	Uint	RW
Belt	Belt speed control inhibit time at start	0x0076	Uint	RW
Belt	Belt speed control inhibit time in service	0x0077	Uint	RW
Belt	Weight to totalize (Great WU)	0x0078	Ulong	RW
Belt	Complementary weight to totalize	0x007A	Uint	RW
Belt	Weight to totalize inflight value	0x007B	long	RW
State Register	Measurement status	0x007D	Uint	RO
State Register	Gross measurement	0x007E	Long	RO
State Register	Tare value	0x0080	Long	RO
State Register	Net measurement	0x0082	Long	RO
State Register	Factory calibrated points	0x0084	Long	RO
Belt	Instant flow rate	0x0086	Float	RO
Belt	Average flow rate	0x0088	Float	RO
Belt	Average belt speed	0x008A	Float	RO
Belt	Belt alarms registers	0x008C	Uint	RO
Belt	Totalizer value (weight unit x1000)	0x008D	Ulong	RO
Belt	Complementary totalizer value	0x008F	Uint	RO
Command	command register	0x0090	Uint	RW
Command	response register	0x0091	Uint	RO
Calibration	Zero offset	0x0092	Long	RW
State Register	Input levels	0x0094 LSB	Byte	RO
I/O	Input levels	0x0094 LSB	Byte	RO
State Register	output levels	0x0094 MSB	Byte	RO
I/O	output levels	0x0094 MSB	Byte	RO
Belt	Dosing weight deviation	0x0095	Float	RO
State Register	Preset tare value	0x0097	Ulong	RW
Belt	Flow rate control output	0x009A	Float	RO
Belt	Dosing quality factor	0x009C	Float	RO
Belt	Errors counter	0x009E	Uint	RO

<i>Chapter</i>	<i>Name</i>	<i>Modbus Address</i>	<i>Type</i>	<i>Access</i>
Belt	Weigh frame load	0x009F	Float	RO
Belt	Control output value	0x00A1	Uint	RO
Belt	Belt status register	0x00A3	Uint	RO
Belt	Total per belt revolution	0x00A4	Float	RO
Belt	Average flow rate Great Unit	0x00A6	Float	RO
Belt	Batch progression in percent	0x00A8	Uint	RO

***** *JUMP TO EXTENSION MODBUS REGISTERS* *****

<i>Chapter</i>	<i>Name</i>	<i>Modbus address</i>	<i>Type</i>	<i>Access</i>
Belt	Calibration point 1 for the control output (output value)	0x0A00	Uint	RW
Belt	Calibration point 2 for the control output (output value)	0x0A01	Uint	RW
Belt	Calibration point 3 for the control output (output value)	0x0A02	Uint	RW
Belt	Calibration point 4 for the control output (output value)	0x0A03	Uint	RW
Belt	Calibration point 5 for the control output (output value)	0x0A04	Uint	RW
Belt	Calibration point 6 for the control output (output value)	0x0A05	Uint	RW
Belt	Calibration point 7 for the control output (output value)	0x0A06	Uint	RW
Belt	Calibration point 8 for the control output (output value)	0x0A07	Uint	RW
Belt	Calibration point 9 for the control output (output value)	0x0A08	Uint	RW
Belt	Calibration point 10 for the control output (output value)	0x0A09	Uint	RW
Belt	Calibration point 1 of the control output (flow rate value) corresponding to value of the control output	0x0A0A	Float	RW
Belt	Calibration point 2 of the control output (flow rate value) corresponding to value of the control output	0x0A0C	Float	RW
Belt	Calibration point 3 of the control output (flow rate value) corresponding to value of the control output	0x0A0E	Float	RW
Belt	Calibration point 4 of the control output (flow rate value) corresponding to value of the control output	0x0A10	Float	RW
Belt	Calibration point 5 of the control output (flow rate value) corresponding to value of the control output	0x0A12	Float	RW
Belt	Calibration point 6 of the control output (flow rate value) corresponding to value of the control output	0x0A14	Float	RW
Belt	Calibration point 7 of the control output (flow rate value) corresponding to value of the control output	0x0A16	Float	RW
Belt	Calibration point 8 of the control output (flow rate value) corresponding to value of the control output	0x0A18	Float	RW
Belt	Calibration point 9 of the control output (flow rate value) corresponding to value of the control output	0x0A1A	Float	RW
Belt	Calibration point 10 of the control output (flow rate value) corresponding to value of the control output	0x0A1C	Float	RW
Belt	Segments number for the Calibration curve of the control output	0x0A1E	Uint	RW
Belt	Weigh frame zero reference	0x0A31	Float	RW
Belt	Min permissible belt load	0x0A33	Uint	RW
Belt	Max permissible belt load	0x0A34	Uint	RW
Belt	Kp	0x0A35	Float	RW
Belt	Ti	0x0A37	Ulong	RW
Belt	Td	0x0A39	Ulong	RW
Belt	PID behavior	0x0A3B	Uint	RW
Belt	Reference flow rate for PID adjustment	0x0A3C	Float	RW
Belt	Checked batch	0x0A3E	Ulong	RW
State Register	Sensor input control reference	0x0A44	long	RW
State Register	Sensor input control result	0x0A46	Int	RO
State Register	Sensor input control result max. tolerance	0x0A47	Uint	RW

<i>Chapter</i>	<i>Name</i>	<i>Modbus address</i>	<i>Type</i>	<i>Access</i>
State Register & I/O	Defective measurement debounced time	0x0A48	Uint	RW
State Register & I/O	Defective measurement alarm activation time	0x0A49	Uint	RW
Belt	Belt fault control inhibit time at start	0x0A50	Uint	RW
Belt	Belt fault control inhibit time in service	0x0A51	Uint	RW
Belt	Cut-off frequency for average flow rate (x100)	0x0A52	Uint	RW
Belt	Time unit for average flow rate	0x0A53	Uint	RW
Belt	Weight unit for average flow rate	0x0A54	Ulong	RW

20 CRC-16 CALCULATION ALGORITHM

